

SmartGen

MAKING CONTROL SMARTER

HMAT880
MEDIUM VOLTAGE BYPASS ATS CONTROLLER
COMMUNICATION PROTOCOL



郑州众智科技股份有限公司
SMARTGEN(ZHENGZHOU)TECHNOLOGY CO.,LTD.

SmartGen 众智 Chinese trademark

SmartGen English trademark

SmartGen – make your generator *smart*

SmartGen Technology Co., Ltd.

No.28 Jinsuo Road

Zhengzhou City

Henan Province

P. R. China

Tel: +86-371-67988888/67981888/67992951

+86-371-67981000(overseas)

Fax: +86-371-67992952

Web: www.smartgen.com.cn/

www.smartgen.cn/

Email: sales@smartgen.cn

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to SmartGen Technology at the address above.

Any reference to trademarked product names used within this publication is owned by their respective companies.

SmartGen Technology reserves the right to change the contents of this document without prior notice.

Table 1 – Software Version

| Date | Version | Content |
|------------|---------|-------------------|
| 2022-05-25 | V1.0 | Original release. |
| | | |
| | | |
| | | |

CONTENT

| | | |
|-----|---|----|
| 1. | DESCRIPTION | 4 |
| 2. | WIRING DIAGRAM | 4 |
| 3. | CONTROLLER INTERNAL REGISTER ADDRESS AND DATA..... | 5 |
| 3.1 | ILLUSTRATION..... | 5 |
| 3.2 | ALARM, STATUS COIL DATA FIELD CORRESPONDING TO FUNCTION CODE 03H..... | 5 |
| 3.3 | VALUE DATA FIELD CORRESPONDING TO FUNCTION CODE 03H..... | 24 |
| 3.4 | REMOTE COIL FIELD CORRESPONDING TO FUNCTION CODE 05H | 34 |
| 3.5 | S1 POWER STATUS DESCRIPTION | 36 |
| 3.6 | S2 POWER STATUS DESCRIPTION | 37 |
| 3.7 | GENSET STATUS DESCRIPTION | 37 |
| 3.8 | ATS STATUS DESCRIPTION..... | 38 |
| 4. | COMMUNICATION PARAMETER VIEW AND CONFIGURATION..... | 39 |
| 4.1 | VIEW CURRENT COMMUNICATION PARAMETERS..... | 39 |
| 4.2 | COMMUNICATION PARAMETERS CONFIGURATION | 39 |
| 5. | FAQ..... | 40 |
| 5.1 | COMMUNICATION LINE SHIELDING LAYER GROUNDED..... | 40 |
| 5.2 | TERMINAL RESISTOR..... | 40 |
| 5.3 | RS485 TO USB COMMUNICATION ADAPTOR..... | 40 |
| 5.4 | EXTENDED COMMUNICATION DISTANCE..... | 40 |
| 5.5 | COMMON SOLUTIONS OF COMMUNICATION FAILURE | 40 |

1. DESCRIPTION

This protocol describes read and write command format of RS485 half-duplex serial port communication and definition of internal information data for the third-party to develop and use.

HMAT880 controller has 2 RS485 interfaces with same communication protocol.

The controller is used as a slave, using Modbus-RTU protocol, and does not support other protocols such as Modbus-ASCII.

Communication address: 1~254 (default: 1)

Baud rate: 2400/4800/9600/19200bps (default: 9600bps)

Start bit: 1-bit

Data bit: 8-bit

Parity bit: No/Odd/Even Parity (default: no parity)

Stop bit: 1 or 2 bits (default: 1-bit)

Supported function code: 03H, 05H. Function code 03H is used for reading controller alarm, status information and various electricity data; while function code 05H is used for sending remote command.

Data check mode: CRC16.

Internal registers of controller are in the unit of "word (double bytes)".

Communication timeout period: over 200ms.

Communication distance: 9600 baud rate, the longest distance can reach 1,000m when using 120Ω shielding twisted pair.

Once maximum 120 data of word register can be read.

Up to 32 controllers can be connected together for network communication.

When RS485 is connected, 120Ω twisted pair with shielding layer shall be used, and the shielding layer shall be grounded at one end.

2. WIRING DIAGRAM




Fig.1 Single Unit Communication Wiring Diagram

NOTE1: 2 120Ω impedance resistors can be connected automatically according to site situation, details refer to the following description.

NOTE2: This figure is RS485-1 wiring diagram, RS485-2 wiring diagram is as above.




Fig.2 Multi-unit Communication Wiring Diagram

NOTE1: Please set each controller’s communication module address before networking. Same module address is inhibited in the same network.

NOTE2: The shielding layer of communication line is single-end grounded on the host side.

3. CONTROLLER INTERNAL REGISTER ADDRESS AND DATA

3.1 ILLUSTRATION

In the following table, S1 refers to 1# power, S2 refers to 2# power, “/” means this item is reserved.

3.2 ALARM, STATUS COIL DATA FIELD CORRESPONDING TO FUNCTION CODE 03H

Table 2 – Alarm, Status Coil Data Field

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|--------------------|--|
| 500.0 | 40501.0 | Common Alarm | 0 means no common alarm occurs; 1 means there is common alarm. (500.0 is the boolean value of bit 0 of address 500) The following contents in turn. |
| 500.1 | 40501.1 | Common Warn Alarm | |
| 500.2 | 40501.2 | Common Fault Alarm | |
| 500.3 | 40501.3 | / | |
| 500.4 | 40501.4 | / | |
| 500.5 | 40501.5 | / | |
| 500.6 | 40501.6 | Audible Alarm | |
| 500.7 | 40501.7 | / | |
| 500.8 | 40501.8 | Auto Mode | 0: Manual Mode 1: Auto Mode |
| 500.9 | 40501.9 | / | |
| 500.10 | 40501.1 | S1 Master | S1 refers to 1# power. 1 means 1# power as common power; 0 means 1# power as backup power. |
| 500.11 | 40501.11 | S2 Master | S2 refers to 2# power. 1 means 2# power as common power; 0 means 2# power as backup power. |
| 500.12 | 40501.12 | / | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|---------------------------|---|
| 500.13 | 40501.13 | / | |
| 500.14 | 40501.14 | / | |
| 500.15 | 40501.15 | Genset Start Output | 0 means genset start signal not output; 1 means genset start signal outputs. |
| 501.0 | 40502.0 | S1 Voltage Normal | |
| 501.1 | 40502.1 | S1 Voltage Abnormal | |
| 501.2 | 40502.2 | S1 Volt Instant. Abnormal | |
| 501.3 | 40502.3 | / | |
| 501.4 | 40502.4 | / | |
| 501.5 | 40502.5 | / | |
| 501.6 | 40502.6 | / | |
| 501.7 | 40502.7 | S1 Genset Start Output | |
| 501.8 | 40502.8 | S1 Blackout | |
| 501.9 | 40502.9 | S1 Over Voltage | |
| 501.10 | 40502.1 | S1 Under Voltage | |
| 501.11 | 40502.11 | S1 Over Frequency | |
| 501.12 | 40502.12 | S1 Under Frequency | |
| 501.13 | 40502.13 | S1 Loss of Phase | |
| 501.14 | 40502.14 | S1 Reverse Phase Seq. | |
| 501.15 | 40502.15 | / | |
| 502.0 | 40503.0 | S2 Voltage Normal | |
| 502.1 | 40503.1 | S2 Voltage Abnormal | |
| 502.2 | 40503.2 | S2 Volt Instant. Abnormal | |
| 502.3 | 40503.3 | / | |
| 502.4 | 40503.4 | / | |
| 502.5 | 40503.5 | / | |
| 502.6 | 40503.6 | / | |
| 502.7 | 40503.7 | S2 Genset Start Output | |
| 502.8 | 40503.8 | S2 Blackout | |
| 502.9 | 40503.9 | S2 Over Voltage | |
| 502.10 | 40503.1 | S2 Under Voltage | |
| 502.11 | 40503.11 | S2 Over Frequency | |
| 502.12 | 40503.12 | S2 Under Frequency | |
| 502.13 | 40503.13 | S2 Loss of Phase | |
| 502.14 | 40503.14 | S2 Reverse Phase Seq. | |
| 502.15 | 40503.15 | / | |
| 503.0 | 40504.0 | ATS Transfer Failure | |
| 503.1 | 40504.1 | S1 Close Failure | |
| 503.2 | 40504.2 | S1 Open Failure | |
| 503.3 | 40504.3 | / | |
| 503.4 | 40504.4 | S2 Close Failure | |
| 503.5 | 40504.5 | S2 Open Failure | |
| 503.6 | 40504.6 | S1 Load End No Power | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|--|-------------|
| 503.7 | 40504.7 | S1 Load End No Power | |
| 503.8 | 40504.8 | S1 Load Overcurrent Trip | |
| 503.9 | 40504.9 | S2 Load Overcurrent Trip | |
| 503.10 | 40504.10 | Forced Open Fault Alarm | |
| 503.11 | 40504.11 | S1 Genset Fault | |
| 503.12 | 40504.12 | S2 Genset Fault | |
| 503.13 | 40504.13 | S1 Breaker Trip Alarm | |
| 503.14 | 40504.14 | Sync. Failure Fault | |
| 503.15 | 40504.15 | S2 Breaker Trip Alarm | |
| 504.0 | 40505.0 | Load Switch Overtime Fault | |
| 504.1 | 40505.1 | Earth Fault | |
| 504.2 | 40505.2 | QTIE Close Failure | |
| 504.3 | 40505.3 | QTIE Open Failure | |
| 504.4 | 40505.4 | QTIE Breaker Trip Alarm | |
| 504.5 | 40505.5 | / | |
| 504.6 | 40505.6 | / | |
| 504.7 | 40505.7 | / | |
| 504.8 | 40505.8 | / | |
| 504.9 | 40505.9 | / | |
| 504.10 | 40505.10 | / | |
| 504.11 | 40505.11 | / | |
| 504.12 | 40505.12 | / | |
| 504.13 | 40505.13 | / | |
| 504.14 | 40505.14 | / | |
| 504.15 | 40505.15 | / | |
| 505.0 | 40506.0 | S1 Load Overcurrent Warn | |
| 505.1 | 40506.1 | S1 Load Overcurrent Warn | |
| 505.2 | 40506.2 | Forced Open Warn | |
| 505.3 | 40506.3 | Battery Undervoltage Warn | |
| 505.4 | 40506.4 | Battery Overvoltage Warn | |
| 505.5 | 40506.5 | Sync. Failure Warn | |
| 505.6 | 40506.6 | / | |
| 505.7 | 40506.7 | Same-side Power Parallel Warn | |
| 505.8 | 40506.8 | S1 PT Break | |
| 505.9 | 40506.9 | S2 PT Break | |
| 505.10 | 40506.10 | Integrated Protection 1 Comm. Failure Warn | |
| 505.11 | 40506.11 | Integrated Protection 2 Comm. Failure Warn | |
| 505.12 | 40506.12 | / | |
| 505.13 | 40506.13 | Load Breaker Trip Warn | |
| 505.14 | 40506.14 | Load Switch Overtime Warn | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|---------------------------------------|---|
| 505.15 | 40506.15 | Earth Fault | |
| 506.0 | 40507.0 | Expand Input Module 1 Comm. Fault | Expand Module Comm. Failure Alarm |
| 506.1 | 40507.1 | Expand Input Module 2 Comm. Fault | |
| 506.2 | 40507.2 | Expand Input Module 3 Comm. Fault | |
| 506.3 | 40507.3 | / | |
| 506.4 | 40507.4 | Expand Input Module 1 Comm. Warn | |
| 506.5 | 40507.5 | Expand Input Module 2 Comm. Warn | |
| 506.6 | 40507.6 | Expand Input Module 3 Comm. Warn | |
| 506.7 | 40507.7 | / | |
| 506.8 | 40507.8 | Expand Output Module 1 Comm. Fault | |
| 506.9 | 40507.9 | Expand Output Module 2 Comm. Fault | |
| 506.10 | 40507.10 | Expand Output Module 3 Comm. Fault | |
| 506.11 | 40507.11 | / | |
| 506.12 | 40507.12 | Expand Output Module 1 Comm. Warn | |
| 506.13 | 40507.13 | Expand Output Module 2 Comm. Warn | |
| 506.14 | 40507.14 | Expand Output Module 3 Comm. Warn | |
| 506.15 | 40507.15 | / | |
| 507.0 | 40508.0 | Aux. Input 1 Status | 0 means there is no input; 1 means there is input. |
| 507.1 | 40508.1 | Aux. Input 2 Status | |
| 507.2 | 40508.2 | Aux. Input 3 Status | |
| 507.3 | 40508.3 | Aux. Input 4 Status | |
| 507.4 | 40508.4 | Aux. Input 5 Status | |
| 507.5 | 40508.5 | Aux. Input 6 Status | |
| 507.6 | 40508.6 | Aux. Input 7 Status | |
| 507.7 | 40508.7 | Aux. Input 8 Status | |
| 507.8 | 40508.8 | Aux. Input 9 Status | |
| 507.9 | 40508.9 | Aux. Input 10 Status | |
| 507.10 | 40508.10 | Aux. Input 11 Status | |
| 507.11 | 40508.11 | Aux. Input 12 Status | |
| 507.12 | 40508.12 | / | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|-------------------------|---|
| 507.13 | 40508.13 | / | |
| 507.14 | 40508.14 | / | |
| 507.15 | 40508.15 | / | |
| 508.0 | 40509.0 | Aux. Output 1 Status | 1 means there is output; 0 means there is no output. |
| 508.1 | 40509.1 | Aux. Output 2 Status | |
| 508.2 | 40509.2 | Aux. Output 3 Status | |
| 508.3 | 40509.3 | Aux. Output 4 Status | |
| 508.4 | 40509.4 | Aux. Output 5 Status | |
| 508.5 | 40509.5 | Aux. Output 6 Status | |
| 508.6 | 40509.6 | Aux. Output 7 Status | |
| 508.7 | 40509.7 | Aux. Output 8 Status | |
| 508.8 | 40509.8 | Aux. Output 9 Status | |
| 508.9 | 40509.9 | Aux. Output 10 Status | |
| 508.10 | 40509.10 | Aux. Output 11 Status | |
| 508.11 | 40509.11 | Aux. Output 12 Status | |
| 508.12 | 40509.12 | Aux. Output 13 Status | |
| 508.13 | 40509.13 | / | |
| 508.14 | 40509.14 | / | |
| 508.15 | 40509.15 | / | |
| 509.0 | 40510.0 | S1 Close Control Output | |
| 509.1 | 40510.1 | S1 Open Control Output | |
| 509.2 | 40510.2 | S2 Close Control Output | |
| 509.3 | 40510.3 | S2 Open Control Output | |
| 509.4 | 40510.4 | S1 Close Status | |
| 509.5 | 40510.5 | S1 Open Status | |
| 509.6 | 40510.6 | S2 Close Status | |
| 509.7 | 40510.7 | S2 Open Status | |
| 509.8 | 40510.8 | Manual Test (S1) | |
| 509.9 | 40510.9 | Manual Test (S2) | |
| 509.10 | 40510.10 | / | |
| 509.11 | 40510.11 | / | |
| 509.12 | 40510.12 | Remote Start On-load | |
| 509.13 | 40510.13 | Remote Start Off-load | |
| 509.14 | 40510.14 | Genset Start Mains NG | |
| 509.15 | 40510.15 | Scheduled Run | |
| 510.0 | 40511.0 | Cycle Run | |
| 510.1 | 40511.1 | Balanced Time Run | |
| 510.2 | 40511.2 | Master Run | |
| 510.3 | 40511.3 | / | |
| 510.4 | 40511.4 | Scheduled Not Run | |
| 510.5 | 40511.5 | / | |
| 510.6 | 40511.6 | / | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|----------------------------------|-------------|
| 510.7 | 40511.7 | / | |
| 510.8 | 40511.8 | / | |
| 510.9 | 40511.9 | / | |
| 510.10 | 40511.10 | Start Inhibit | |
| 510.11 | 40511.11 | / | |
| 510.12 | 40511.12 | S1 Close Inhibit | |
| 510.13 | 40511.13 | S2 Close Inhibit | |
| 510.14 | 40511.14 | Wait S1 Close PF Input | |
| 510.15 | 40511.15 | Wait S2 Close PF Input | |
| 511.0 | 40512.0 | NEL1 Trip | |
| 511.1 | 40512.1 | NEL2 Trip | |
| 511.2 | 40512.2 | NEL3 Trip | |
| 511.3 | 40512.3 | / | |
| 511.4 | 40512.4 | / | |
| 511.5 | 40512.5 | Elevator Control | |
| 511.6 | 40512.6 | / | |
| 511.7 | 40512.7 | / | |
| 511.8 | 40512.8 | Bustie Breaker Close Inhibit | |
| 511.9 | 40512.9 | / | |
| 511.10 | 40512.10 | Bustie Breaker Ready PF Input | |
| 511.11 | 40512.11 | Auto Trans./Restore | |
| 511.12 | 40512.12 | Remote Input Inhibit | |
| 511.13 | 40512.13 | Stepwise Switch Pop-up | |
| 511.14 | 40512.14 | / | |
| 511.15 | 40512.15 | / | |
| 512.0 | 40513.0 | QS1 Close Status at Contact Side | |
| 512.1 | 40513.1 | QS2 Close Status at Contact Side | |
| 512.2 | 40513.2 | Bustie Breaker Close Output | |
| 512.3 | 40513.3 | Bustie Breaker Open Output | |
| 512.4 | 40513.4 | / | |
| 512.5 | 40513.5 | / | |
| 512.6 | 40513.6 | / | |
| 512.7 | 40513.7 | Bustie Breaker Closed Input | |
| 512.8 | 40513.8 | / | |
| 512.9 | 40513.9 | / | |
| 512.10 | 40513.10 | / | |
| 512.11 | 40513.11 | / | |
| 512.12 | 40513.12 | / | |
| 512.13 | 40513.13 | / | |
| 512.14 | 40513.14 | / | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|------------------------|---|
| 512.15 | 40513.15 | / | |
| 513.0 | 40514.0 | / | |
| 513.1 | 40514.1 | / | |
| 513.2 | 40514.2 | / | |
| 513.3 | 40514.3 | / | |
| 513.4 | 40514.4 | / | |
| 513.5 | 40514.5 | / | |
| 513.6 | 40514.6 | / | |
| 513.7 | 40514.7 | / | |
| 513.8 | 40514.8 | / | |
| 513.9 | 40514.9 | / | |
| 513.10 | 40514.10 | / | |
| 513.11 | 40514.11 | / | |
| 513.12 | 40514.12 | / | |
| 513.13 | 40514.13 | / | |
| 513.14 | 40514.14 | / | |
| 513.15 | 40514.15 | Bypass in Auto Mode | |
| 514.0 | 40515.0 | Expand Input 1 Status | Input 1-16 status of expand input module 1. |
| 514.1 | 40515.1 | Expand Input 2 Status | |
| 514.2 | 40515.2 | Expand Input 3 Status | |
| 514.3 | 40515.3 | Expand Input 4 Status | |
| 514.4 | 40515.4 | Expand Input 5 Status | |
| 514.5 | 40515.5 | Expand Input 6 Status | |
| 514.6 | 40515.6 | Expand Input 7 Status | |
| 514.7 | 40515.7 | Expand Input 8 Status | |
| 514.8 | 40515.8 | Expand Input 9 Status | |
| 514.9 | 40515.9 | Expand Input 10 Status | |
| 514.10 | 40515.10 | Expand Input 11 Status | |
| 514.11 | 40515.11 | Expand Input 12 Status | |
| 514.12 | 40515.12 | Expand Input 13 Status | |
| 514.13 | 40515.13 | Expand Input 14 Status | |
| 514.14 | 40515.14 | Expand Input 15 Status | |
| 514.15 | 40515.15 | Expand Input 16 Status | |
| 515.0 | 40516.0 | Expand Input 1 Status | Input 1-16 status of expand input module 2. |
| 515.1 | 40516.1 | Expand Input 2 Status | |
| 515.2 | 40516.2 | Expand Input 3 Status | |
| 515.3 | 40516.3 | Expand Input 4 Status | |
| 515.4 | 40516.4 | Expand Input 5 Status | |
| 515.5 | 40516.5 | Expand Input 6 Status | |
| 515.6 | 40516.6 | Expand Input 7 Status | |
| 515.7 | 40516.7 | Expand Input 8 Status | |
| 515.8 | 40516.8 | Expand Input 9 Status | |
| 515.9 | 40516.9 | Expand Input 10 Status | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|-------------------------|---|
| 515.10 | 40516.10 | Expand Input 11 Status | |
| 515.11 | 40516.11 | Expand Input 12 Status | |
| 515.12 | 40516.12 | Expand Input 13 Status | |
| 515.13 | 40516.13 | Expand Input 14 Status | |
| 515.14 | 40516.14 | Expand Input 15 Status | |
| 515.15 | 40516.15 | Expand Input 16 Status | |
| 516.0 | 40517.0 | Expand Input 1 Status | Input 1-16 status of expand input module 3. |
| 516.1 | 40517.1 | Expand Input 2 Status | |
| 516.2 | 40517.2 | Expand Input 3 Status | |
| 516.3 | 40517.3 | Expand Input 4 Status | |
| 516.4 | 40517.4 | Expand Input 5 Status | |
| 516.5 | 40517.5 | Expand Input 6 Status | |
| 516.6 | 40517.6 | Expand Input 7 Status | |
| 516.7 | 40517.7 | Expand Input 8 Status | |
| 516.8 | 40517.8 | Expand Input 9 Status | |
| 516.9 | 40517.9 | Expand Input 10 Status | |
| 516.10 | 40517.10 | Expand Input 11 Status | |
| 516.11 | 40517.11 | Expand Input 12 Status | |
| 516.12 | 40517.12 | Expand Input 13 Status | |
| 516.13 | 40517.13 | Expand Input 14 Status | |
| 516.14 | 40517.14 | Expand Input 15 Status | |
| 516.15 | 40517.15 | Expand Input 16 Status | |
| 517.0 | 40518.0 | Expand Output 1 Status | Output 1-16 status of expand output module 1. |
| 517.1 | 40518.1 | Expand Output 2 Status | |
| 517.2 | 40518.2 | Expand Output 3 Status | |
| 517.3 | 40518.3 | Expand Output 4 Status | |
| 517.4 | 40518.4 | Expand Output 5 Status | |
| 517.5 | 40518.5 | Expand Output 6 Status | |
| 517.6 | 40518.6 | Expand Output 7 Status | |
| 517.7 | 40518.7 | Expand Output 8 Status | |
| 517.8 | 40518.8 | Expand Output 9 Status | |
| 517.9 | 40518.9 | Expand Output 10 Status | |
| 517.10 | 40518.10 | Expand Output 11 Status | |
| 517.11 | 40518.11 | Expand Output 12 Status | |
| 517.12 | 40518.12 | Expand Output 13 Status | |
| 517.13 | 40518.13 | Expand Output 14 Status | |
| 517.14 | 40518.14 | Expand Output 15 Status | |
| 517.15 | 40518.15 | Expand Output 16 Status | |
| 518.0 | 40519.0 | Expand Output 1 Status | Output 1-16 status of expand output module 2. |
| 518.1 | 40519.1 | Expand Output 2 Status | |
| 518.2 | 40519.2 | Expand Output 3 Status | |
| 518.3 | 40519.3 | Expand Output 4 Status | |
| 518.4 | 40519.4 | Expand Output 5 Status | |

| Modbus Address | PLC Address | Name | Description | |
|----------------|-------------|-------------------------|---|---|
| 518.5 | 40519.5 | Expand Output 6 Status | | |
| 518.6 | 40519.6 | Expand Output 7 Status | | |
| 518.7 | 40519.7 | Expand Output 8 Status | | |
| 518.8 | 40519.8 | Expand Output 9 Status | | |
| 518.9 | 40519.9 | Expand Output 10 Status | | |
| 518.10 | 40519.10 | Expand Output 11 Status | | |
| 518.11 | 40519.11 | Expand Output 12 Status | | |
| 518.12 | 40519.12 | Expand Output 13 Status | | |
| 518.13 | 40519.13 | Expand Output 14 Status | | |
| 518.14 | 40519.14 | Expand Output 15 Status | | |
| 518.15 | 40519.15 | Expand Output 16 Status | | |
| 519.0 | 40520.0 | Expand Output 1 Status | | Output 1-16 status of expand output module 3. |
| 519.1 | 40520.1 | Expand Output 2 Status | | |
| 519.2 | 40520.2 | Expand Output 3 Status | | |
| 519.3 | 40520.3 | Expand Output 4 Status | | |
| 519.4 | 40520.4 | Expand Output 5 Status | | |
| 519.5 | 40520.5 | Expand Output 6 Status | | |
| 519.6 | 40520.6 | Expand Output 7 Status | | |
| 519.7 | 40520.7 | Expand Output 8 Status | | |
| 519.8 | 40520.8 | Expand Output 9 Status | | |
| 519.9 | 40520.9 | Expand Output 10 Status | | |
| 519.10 | 40520.10 | Expand Output 11 Status | | |
| 519.11 | 40520.11 | Expand Output 12 Status | | |
| 519.12 | 40520.12 | Expand Output 13 Status | | |
| 519.13 | 40520.13 | Expand Output 14 Status | | |
| 519.14 | 40520.14 | Expand Output 15 Status | | |
| 519.15 | 40520.15 | Expand Output 16 Status | | |
| 520.0 | 40521.0 | Expand Input 1 Status | Input 1-16 status of expand input module 4. | |
| 520.1 | 40521.1 | Expand Input 2 Status | | |
| 520.2 | 40521.2 | Expand Input 3 Status | | |
| 520.3 | 40521.3 | Expand Input 4 Status | | |
| 520.4 | 40521.4 | Expand Input 5 Status | | |
| 520.5 | 40521.5 | Expand Input 6 Status | | |
| 520.6 | 40521.6 | Expand Input 7 Status | | |
| 520.7 | 40521.7 | Expand Input 8 Status | | |
| 520.8 | 40521.8 | Expand Input 9 Status | | |
| 520.9 | 40521.9 | Expand Input 10 Status | | |
| 520.10 | 40521.10 | Expand Input 11 Status | | |
| 520.11 | 40521.11 | Expand Input 12 Status | | |
| 520.12 | 40521.12 | Expand Input 13 Status | | |
| 520.13 | 40521.13 | Expand Input 14 Status | | |
| 520.14 | 40521.14 | Expand Input 15 Status | | |
| 520.15 | 40521.15 | Expand Input 16 Status | | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|-----------------------------------|---|
| 521.0 | 40522.0 | Expand Input 1 Status | Input 1-16 status of expand input module 5. |
| 521.1 | 40522.1 | Expand Input 2 Status | |
| 521.2 | 40522.2 | Expand Input 3 Status | |
| 521.3 | 40522.3 | Expand Input 4 Status | |
| 521.4 | 40522.4 | Expand Input 5 Status | |
| 521.5 | 40522.5 | Expand Input 6 Status | |
| 521.6 | 40522.6 | Expand Input 7 Status | |
| 521.7 | 40522.7 | Expand Input 8 Status | |
| 521.8 | 40522.8 | Expand Input 9 Status | |
| 521.9 | 40522.9 | Expand Input 10 Status | |
| 521.10 | 40522.10 | Expand Input 11 Status | |
| 521.11 | 40522.11 | Expand Input 12 Status | |
| 521.12 | 40522.12 | Expand Input 13 Status | |
| 521.13 | 40522.13 | Expand Input 14 Status | |
| 521.14 | 40522.14 | Expand Input 15 Status | |
| 521.15 | 40522.15 | Expand Input 16 Status | |
| 522.0 | 40523.0 | Expand Input 1 Status | Input 1-16 status of expand input module 6. |
| 522.1 | 40523.1 | Expand Input 2 Status | |
| 522.2 | 40523.2 | Expand Input 3 Status | |
| 522.3 | 40523.3 | Expand Input 4 Status | |
| 522.4 | 40523.4 | Expand Input 5 Status | |
| 522.5 | 40523.5 | Expand Input 6 Status | |
| 522.6 | 40523.6 | Expand Input 7 Status | |
| 522.7 | 40523.7 | Expand Input 8 Status | |
| 522.8 | 40523.8 | Expand Input 9 Status | |
| 522.9 | 40523.9 | Expand Input 10 Status | |
| 522.10 | 40523.10 | Expand Input 11 Status | |
| 522.11 | 40523.11 | Expand Input 12 Status | |
| 522.12 | 40523.12 | Expand Input 13 Status | |
| 522.13 | 40523.13 | Expand Input 14 Status | |
| 522.14 | 40523.14 | Expand Input 15 Status | |
| 522.15 | 40523.15 | Expand Input 16 Status | |
| 523.0 | 40524.0 | Expand Input Module 4 Comm. Fault | Communication failure alarm of expand module (expand input module 4-6). |
| 523.1 | 40524.1 | Expand Input Module 5 Comm. Fault | |
| 523.2 | 40524.2 | Expand Input Module 6 Comm. Fault | |
| 523.3 | 40524.3 | | |
| 523.4 | 40524.4 | Expand Input Module 4 Comm. Warn | |
| 523.5 | 40524.5 | Expand Input Module 5 Comm. Warn | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|-------------------------------------|-------------|
| 523.6 | 40524.6 | Expand Input Module 6 Comm. Warn | |
| 523.7 | 40524.7 | / | |
| 523.8 | 40524.8 | / | |
| 523.9 | 40524.9 | / | |
| 523.10 | 40524.10 | / | |
| 523.11 | 40524.11 | / | |
| 523.12 | 40524.12 | / | |
| 523.13 | 40524.13 | / | |
| 523.14 | 40524.14 | / | |
| 523.15 | 40524.15 | / | |
| 524.0 | 40525.0 | / | |
| 524.1 | 40525.1 | / | |
| 524.2 | 40525.2 | / | |
| 524.3 | 40525.3 | / | |
| 524.4 | 40525.4 | / | |
| 524.5 | 40525.5 | / | |
| 524.6 | 40525.6 | / | |
| 524.7 | 40525.7 | / | |
| 524.8 | 40525.8 | / | |
| 524.9 | 40525.9 | / | |
| 524.10 | 40525.10 | / | |
| 524.11 | 40525.11 | / | |
| 524.12 | 40525.12 | / | |
| 524.13 | 40525.13 | / | |
| 524.14 | 40525.14 | / | |
| 524.15 | 40525.15 | / | |
| 525.0 | 40526.0 | Load Breaker 1 Close Failure | |
| 525.1 | 40526.1 | Load Breaker 2 Close Failure | |
| 525.2 | 40526.2 | Load Breaker 3 Close Failure | |
| 525.3 | 40526.3 | Load Breaker 4 Close Failure | |
| 525.4 | 40526.4 | Load Breaker 5 Close Failure | |
| 525.5 | 40526.5 | Load Breaker 6 Close Failure | |
| 525.6 | 40526.6 | Load Breaker 7 Close Failure | |
| 525.7 | 40526.7 | Load Breaker 8 Close Failure | |
| 525.8 | 40526.8 | Load Breaker 9 Close Failure | |
| 525.9 | 40526.9 | Load Breaker 10 Close Failure | |
| 525.10 | 40526.10 | Load Breaker 11 Close Failure | |
| 525.11 | 40526.11 | Load Breaker 12 Close Failure | |
| 525.12 | 40526.12 | Load Breaker 13 Close | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|-------------------------------|-------------|
| | | Failure | |
| 525.13 | 40526.13 | Load Breaker 14 Close Failure | |
| 525.14 | 40526.14 | Load Breaker 15 Close Failure | |
| 525.15 | 40526.15 | Load Breaker 16 Close Failure | |
| 526.0 | 40527.0 | Load Breaker 17 Close Failure | |
| 526.1 | 40527.1 | Load Breaker 18 Close Failure | |
| 526.2 | 40527.2 | Load Breaker 19 Close Failure | |
| 526.3 | 40527.3 | Load Breaker 20 Close Failure | |
| 526.4 | 40527.4 | Load Breaker 21 Close Failure | |
| 526.5 | 40527.5 | Load Breaker 22 Close Failure | |
| 526.6 | 40527.6 | Load Breaker 23 Close Failure | |
| 526.7 | 40527.7 | Load Breaker 24 Close Failure | |
| 526.8 | 40527.8 | / | |
| 526.9 | 40527.9 | / | |
| 526.10 | 40527.10 | / | |
| 526.11 | 40527.11 | / | |
| 526.12 | 40527.12 | / | |
| 526.13 | 40527.13 | / | |
| 526.14 | 40527.14 | / | |
| 526.15 | 40527.15 | / | |
| 527.0 | 40528.0 | Load Breaker 1 Open Failure | |
| 527.1 | 40528.1 | Load Breaker 2 Open Failure | |
| 527.2 | 40528.2 | Load Breaker 3 Open Failure | |
| 527.3 | 40528.3 | Load Breaker 4 Open Failure | |
| 527.4 | 40528.4 | Load Breaker 5 Open Failure | |
| 527.5 | 40528.5 | Load Breaker 6 Open Failure | |
| 527.6 | 40528.6 | Load Breaker 7 Open Failure | |
| 527.7 | 40528.7 | Load Breaker 8 Open Failure | |
| 527.8 | 40528.8 | Load Breaker 9 Open Failure | |
| 527.9 | 40528.9 | Load Breaker 10 Open Failure | |
| 527.10 | 40528.10 | Load Breaker 11 Open Failure | |
| 527.11 | 40528.11 | Load Breaker 12 Open Failure | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|------------------------------|-------------|
| 527.12 | 40528.12 | Load Breaker 13 Open Failure | |
| 527.13 | 40528.13 | Load Breaker 14 Open Failure | |
| 527.14 | 40528.14 | Load Breaker 15 Open Failure | |
| 527.15 | 40528.15 | Load Breaker 16 Open Failure | |
| 528.0 | 40529.0 | Load Breaker 17 Open Failure | |
| 528.1 | 40529.1 | Load Breaker 18 Open Failure | |
| 528.2 | 40529.2 | Load Breaker 19 Open Failure | |
| 528.3 | 40529.3 | Load Breaker 20 Open Failure | |
| 528.4 | 40529.4 | Load Breaker 21 Open Failure | |
| 528.5 | 40529.5 | Load Breaker 22 Open Failure | |
| 528.6 | 40529.6 | Load Breaker 23 Open Failure | |
| 528.7 | 40529.7 | Load Breaker 24 Open Failure | |
| 528.8 | 40529.8 | / | |
| 528.9 | 40529.9 | / | |
| 528.10 | 40529.10 | / | |
| 528.11 | 40529.11 | / | |
| 528.12 | 40529.12 | / | |
| 528.13 | 40529.13 | / | |
| 528.14 | 40529.14 | / | |
| 528.15 | 40529.15 | / | |
| 529.0 | 40530.0 | Load Breaker 1 Trip | |
| 529.1 | 40530.1 | Load Breaker 2 Trip | |
| 529.2 | 40530.2 | Load Breaker 3 Trip | |
| 529.3 | 40530.3 | Load Breaker 4 Trip | |
| 529.4 | 40530.4 | Load Breaker 5 Trip | |
| 529.5 | 40530.5 | Load Breaker 6 Trip | |
| 529.6 | 40530.6 | Load Breaker 7 Trip | |
| 529.7 | 40530.7 | Load Breaker 8 Trip | |
| 529.8 | 40530.8 | Load Breaker 9 Trip | |
| 529.9 | 40530.9 | Load Breaker 10 Trip | |
| 529.10 | 40530.10 | Load Breaker 11 Trip | |
| 529.11 | 40530.11 | Load Breaker 12 Trip | |
| 529.12 | 40530.12 | Load Breaker 13 Trip | |
| 529.13 | 40530.13 | Load Breaker 14 Trip | |
| 529.14 | 40530.14 | Load Breaker 15 Trip | |
| 529.15 | 40530.15 | Load Breaker 16 Trip | |
| 530.0 | 40531.0 | Load Breaker 17 Trip | |
| 530.1 | 40531.1 | Load Breaker 18 Trip | |
| 530.2 | 40531.2 | Load Breaker 19 Trip | |
| 530.3 | 40531.3 | Load Breaker 20 Trip | |
| 530.4 | 40531.4 | Load Breaker 21 Trip | |
| 530.5 | 40531.5 | Load Breaker 22 Trip | |
| 530.6 | 40531.6 | Load Breaker 23 Trip | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|------------------------------|-------------|
| 530.7 | 40531.7 | Load Breaker 24 Trip | |
| 530.8 | 40531.8 | / | |
| 530.9 | 40531.9 | / | |
| 530.10 | 40531.10 | / | |
| 530.11 | 40531.11 | / | |
| 530.12 | 40531.12 | / | |
| 530.13 | 40531.13 | / | |
| 530.14 | 40531.14 | / | |
| 530.15 | 40531.15 | / | |
| 531.0 | 40532.0 | Load Breaker 1 Close Output | |
| 531.1 | 40532.1 | Load Breaker 2 Close Output | |
| 531.2 | 40532.2 | Load Breaker 3 Close Output | |
| 531.3 | 40532.3 | Load Breaker 4 Close Output | |
| 531.4 | 40532.4 | Load Breaker 5 Close Output | |
| 531.5 | 40532.5 | Load Breaker 6 Close Output | |
| 531.6 | 40532.6 | Load Breaker 7 Close Output | |
| 531.7 | 40532.7 | Load Breaker 8 Close Output | |
| 531.8 | 40532.8 | Load Breaker 9 Close Output | |
| 531.9 | 40532.9 | Load Breaker 10 Close Output | |
| 531.10 | 40532.10 | Load Breaker 11 Close Output | |
| 531.11 | 40532.11 | Load Breaker 12 Close Output | |
| 531.12 | 40532.12 | Load Breaker 13 Close Output | |
| 531.13 | 40532.13 | Load Breaker 14 Close Output | |
| 531.14 | 40532.14 | Load Breaker 15 Close Output | |
| 531.15 | 40532.15 | Load Breaker 16 Close Output | |
| 532.0 | 40533.0 | Load Breaker 17 Close Output | |
| 532.1 | 40533.1 | Load Breaker 18 Close Output | |
| 532.2 | 40533.2 | Load Breaker 19 Close Output | |
| 532.3 | 40533.3 | Load Breaker 20 Close Output | |
| 532.4 | 40533.4 | Load Breaker 21 Close Output | |
| 532.5 | 40533.5 | Load Breaker 22 Close | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|------------------------------|-------------|
| | | Output | |
| 532.6 | 40533.6 | Load Breaker 23 Close Output | |
| 532.7 | 40533.7 | Load Breaker 24 Close Output | |
| 532.8 | 40533.8 | / | |
| 532.9 | 40533.9 | / | |
| 532.10 | 40533.10 | / | |
| 532.11 | 40533.11 | / | |
| 532.12 | 40533.12 | / | |
| 532.13 | 40533.13 | / | |
| 532.14 | 40533.14 | / | |
| 532.15 | 40533.15 | / | |
| 533.0 | 40534.0 | Load Breaker 1 Open Output | |
| 533.1 | 40534.1 | Load Breaker 2 Open Output | |
| 533.2 | 40534.2 | Load Breaker 3 Open Output | |
| 533.3 | 40534.3 | Load Breaker 4 Open Output | |
| 533.4 | 40534.4 | Load Breaker 5 Open Output | |
| 533.5 | 40534.5 | Load Breaker 6 Open Output | |
| 533.6 | 40534.6 | Load Breaker 7 Open Output | |
| 533.7 | 40534.7 | Load Breaker 8 Open Output | |
| 533.8 | 40534.8 | Load Breaker 9 Open Output | |
| 533.9 | 40534.9 | Load Breaker 10 Open Output | |
| 533.10 | 40534.10 | Load Breaker 11 Open Output | |
| 533.11 | 40534.11 | Load Breaker 12 Open Output | |
| 533.12 | 40534.12 | Load Breaker 13 Open Output | |
| 533.13 | 40534.13 | Load Breaker 14 Open Output | |
| 533.14 | 40534.14 | Load Breaker 15 Open Output | |
| 533.15 | 40534.15 | Load Breaker 16 Open Output | |
| 534.0 | 40535.0 | Load Breaker 17 Open Output | |
| 534.1 | 40535.1 | Load Breaker 18 Open Output | |
| 534.2 | 40535.2 | Load Breaker 19 Open Output | |
| 534.3 | 40535.3 | Load Breaker 20 Open Output | |
| 534.4 | 40535.4 | Load Breaker 21 Open Output | |
| 534.5 | 40535.5 | Load Breaker 22 Open Output | |
| 534.6 | 40535.6 | Load Breaker 23 Open Output | |
| 534.7 | 40535.7 | Load Breaker 24 Open Output | |
| 534.8 | 40535.8 | / | |
| 534.9 | 40535.9 | / | |
| 534.10 | 40535.10 | / | |
| 534.11 | 40535.11 | / | |
| 534.12 | 40535.12 | / | |
| 534.13 | 40535.13 | / | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|---------------------------------|-------------|
| 534.14 | 40535.14 | / | |
| 534.15 | 40535.15 | / | |
| 535.0 | 40536.0 | Load Breaker 1 Close Status | |
| 535.1 | 40536.1 | Load Breaker 2 Close Status | |
| 535.2 | 40536.2 | Load Breaker 3 Close Status | |
| 535.3 | 40536.3 | Load Breaker 4 Close Status | |
| 535.4 | 40536.4 | Load Breaker 5 Close Status | |
| 535.5 | 40536.5 | Load Breaker 6 Close Status | |
| 535.6 | 40536.6 | Load Breaker 7 Close Status | |
| 535.7 | 40536.7 | Load Breaker 8 Close Status | |
| 535.8 | 40536.8 | Load Breaker 9 Close Status | |
| 535.9 | 40536.9 | Load Breaker 10 Close Status | |
| 535.10 | 40536.10 | Load Breaker 11 Close Status | |
| 535.11 | 40536.11 | Load Breaker 12 Close Status | |
| 535.12 | 40536.12 | Load Breaker 13 Close Status | |
| 535.13 | 40536.13 | Load Breaker 14 Close Status | |
| 535.14 | 40536.14 | Load Breaker 15 Close Status | |
| 535.15 | 40536.15 | Load Breaker 16 Close Status | |
| 536.0 | 40537.0 | Load Breaker 17 Close Status | |
| 536.1 | 40537.1 | Load Breaker 18 Close Status | |
| 536.2 | 40537.2 | Load Breaker 19 Close Status | |
| 536.3 | 40537.3 | Load Breaker 20 Close Status | |
| 536.4 | 40537.4 | Load Breaker 21 Close Status | |
| 536.5 | 40537.5 | Load Breaker 22 Close Status | |
| 536.6 | 40537.6 | Load Breaker 23 Close Status | |
| 536.7 | 40537.7 | Load Breaker 24 Close Status | |
| 536.8 | 40537.8 | / | |
| 536.9 | 40537.9 | / | |
| 536.10 | 40537.10 | / | |
| 536.11 | 40537.11 | / | |
| 536.12 | 40537.12 | / | |
| 536.13 | 40537.13 | / | |
| 536.14 | 40537.14 | / | |
| 536.15 | 40537.15 | / | |
| 537.0 | 40538.0 | Load Breaker 1 in Work Position | |
| 537.1 | 40538.1 | Load Breaker 2 in Work Position | |
| 537.2 | 40538.2 | Load Breaker 3 in Work Position | |
| 537.3 | 40538.3 | Load Breaker 4 in Work Position | |
| 537.4 | 40538.4 | Load Breaker 5 in Work | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|----------------------------------|-------------|
| | | Position | |
| 537.5 | 40538.5 | Load Breaker 6 in Work Position | |
| 537.6 | 40538.6 | Load Breaker 7 in Work Position | |
| 537.7 | 40538.7 | Load Breaker 8 in Work Position | |
| 537.8 | 40538.8 | Load Breaker 9 in Work Position | |
| 537.9 | 40538.9 | Load Breaker 10 in Work Position | |
| 537.10 | 40538.10 | Load Breaker 11 in Work Position | |
| 537.11 | 40538.11 | Load Breaker 12 in Work Position | |
| 537.12 | 40538.12 | Load Breaker 13 in Work Position | |
| 537.13 | 40538.13 | Load Breaker 14 in Work Position | |
| 537.14 | 40538.14 | Load Breaker 15 in Work Position | |
| 537.15 | 40538.15 | Load Breaker 16 in Work Position | |
| 538.0 | 40539.0 | Load Breaker 17 in Work Position | |
| 538.1 | 40539.1 | Load Breaker 18 in Work Position | |
| 538.2 | 40539.2 | Load Breaker 19 in Work Position | |
| 538.3 | 40539.3 | Load Breaker 20 in Work Position | |
| 538.4 | 40539.4 | Load Breaker 21 in Work Position | |
| 538.5 | 40539.5 | Load Breaker 22 in Work Position | |
| 538.6 | 40539.6 | Load Breaker 23 in Work Position | |
| 538.7 | 40539.7 | Load Breaker 24 in Work Position | |
| 538.8 | 40539.8 | / | |
| 538.9 | 40539.9 | / | |
| 538.10 | 40539.10 | / | |
| 538.11 | 40539.11 | / | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|----------------------------------|-------------|
| 538.12 | 40539.12 | / | |
| 538.13 | 40539.13 | / | |
| 538.14 | 40539.14 | / | |
| 538.15 | 40539.15 | / | |
| 539.0 | 40540.0 | Load Breaker 1 in Test Position | |
| 539.1 | 40540.1 | Load Breaker 2 in Test Position | |
| 539.2 | 40540.2 | Load Breaker 3 in Test Position | |
| 539.3 | 40540.3 | Load Breaker 4 in Test Position | |
| 539.4 | 40540.4 | Load Breaker 5 in Test Position | |
| 539.5 | 40540.5 | Load Breaker 6 in Test Position | |
| 539.6 | 40540.6 | Load Breaker 7 in Test Position | |
| 539.7 | 40540.7 | Load Breaker 8 in Test Position | |
| 539.8 | 40540.8 | Load Breaker 9 in Test Position | |
| 539.9 | 40540.9 | Load Breaker 10 in Test Position | |
| 539.10 | 40540.10 | Load Breaker 11 in Test Position | |
| 539.11 | 40540.11 | Load Breaker 12 in Test Position | |
| 539.12 | 40540.12 | Load Breaker 13 in Test Position | |
| 539.13 | 40540.13 | Load Breaker 14 in Test Position | |
| 539.14 | 40540.14 | Load Breaker 15 in Test Position | |
| 539.15 | 40540.15 | Load Breaker 16 in Test Position | |
| 540.0 | 40541.0 | Load Breaker 17 in Test Position | |
| 540.1 | 40541.1 | Load Breaker 18 in Test Position | |
| 540.2 | 40541.2 | Load Breaker 19 in Test Position | |
| 540.3 | 40541.3 | Load Breaker 20 in Test Position | |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|-------------------------------------|-------------|
| | | Position | |
| 540.4 | 40541.4 | Load Breaker 21 in Test Position | |
| 540.5 | 40541.5 | Load Breaker 22 in Test Position | |
| 540.6 | 40541.6 | Load Breaker 23 in Test Position | |
| 540.7 | 40541.7 | Load Breaker 24 in Test Position | |
| 540.8 | 40541.8 | / | |
| 540.9 | 40541.9 | / | |
| 540.10 | 40541.10 | / | |
| 540.11 | 40541.11 | / | |
| 540.12 | 40541.12 | / | |
| 540.13 | 40541.13 | / | |
| 540.14 | 40541.14 | / | |
| 540.15 | 40541.15 | / | |
| 541.0 | 40542.0 | BPS1 Close Output | |
| 541.1 | 40542.1 | BPS1 Open Output | |
| 541.2 | 40542.2 | BPS2 Close Output | |
| 541.3 | 40542.3 | BPS2 Open Output | |
| 541.4 | 40542.4 | BPS1 Close Status | |
| 541.5 | 40542.5 | BPS2 Close Status | |
| 541.6 | 40542.6 | Bypass Switch Unlock Status | |
| 541.7 | 40542.7 | Main Switch in Work Position | |
| 541.8 | 40542.8 | Main Switch in Test Position | |
| 541.9 | 40542.9 | Main Switch in Isolation Position | |
| 541.10 | 40542.10 | Main Switch Unlock Status | |
| 541.11 | 40542.11 | Bypass Switch in Work Position | |
| 541.12 | 40542.12 | Bypass Switch in Test Position | |
| 541.13 | 40542.13 | Bypass Switch in Isolation Position | |
| 541.14 | 40542.14 | Main Switch Unlock Input | |
| 541.15 | 40542.15 | Bypass Switch Unlock Input | |

Example:

If need to read “Aux. Output 1 Status” and “S1 Close Status”, firstly get their corresponding address is 508.0 and 509.4 by checking the table, it is known that you need to read 2 addresses’ data.

Assume the slave (controller) address is 01, the master (can be computer) request command is as following:

Table 3 – Master (Computer) Request Command

| Slave Address | Function Code | Starting Address (508) | | Data Qty. (2) | | CRC 16 Calibration | |
|---------------|---------------|------------------------|-----------|---------------|-----------|--------------------|-----------|
| | | MSB | LSB | MSB | LSB | LSB | MSB |
| 01 | 03 | 01 | FC | 00 | 02 | 05 | C7 |

Slave response command is as following:

Table 4 – Slave (Controller) Response Command

| Slave Address | Function Code | Data Qty. (Bytes) | Data | | | | CRC 16 Calibration | |
|---------------|---------------|-------------------|-------------------------|-------------------------|-------------------------|-------------------------|--------------------|-----------|
| | | | Data MSB of Address 508 | Data LSB of Address 508 | Data MSB of Address 509 | Data LSB of Address 509 | LSB | MSB |
| 01 | 03 | 04 | 00 | 01 | 00 | 10 | AA | 3F |

Table 5 – Data Analysis

| Address | Received Data (Hex) | Convert to Binary | Data Signification |
|---------|---------------------|--|--|
| 508 | 0001H | 0000 0000 0000 0001 (correspond to 508.15, 508.14.....508.1, 508.0) | Data of bit 0 is 1 indicates that aux. output 1 is active. |
| 509 | 0010H | 0000 0000 0001 0000 (correspond to 509.15, 509.14.....509.1, 509.0) | Data of bit 509.4 is 1 indicates S1 is closed. |

3.3 VALUE DATA FIELD CORRESPONDING TO FUNCTION CODE 03H

Table 6 – Value Data Field

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|------------------------------|-----------------|-------|------|-----------------|-----------------------|
| 1000 | 41001 | UAB1 (1# AB Line Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1001 | 41002 | UBC1 (1# BC Line Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1002 | 41003 | UCA1 (1# CA Line Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1003 | 41004 | UA1 (1# A Phase Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1004 | 41005 | UB1 (1# B Phase Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1005 | 41006 | UC1 (1# C Phase Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1006 | 41007 | UA1 Phase (1# A Phase) | 0~360.0 | 0.1 | ° | 16-bit Unsigned | NOTE3 |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|--|-----------------|-------|------|--------------------|--------|
| 1007 | 41008 | UB1 Phase (1# B Phase) | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1008 | 41009 | UC1 Phase (1# C Phase) | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1009 | 41010 | Frequency 1 (1# Power Frequency) | 0~100.00 | 0.01 | Hz | 16-bit Unsigned | |
| 1010 | 41011 | / | | | | | |
| 1011 | 41012 | / | | | | | |
| 1012 | 41013 | / | | | | | |
| 1013 | 41014 | / | | | | | |
| 1014 | 41015 | / | | | | | |
| 1015 | 41016 | / | | | | | |
| 1016 | 41017 | / | | | | | |
| 1017 | 41018 | / | | | | | |
| 1018 | 41019 | / | | | | | |
| 1019 | 41020 | / | | | | | |
| 1020 | 41021 | UAB2 (2# AB Line Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1021 | 41022 | UBC2 (2# BC Line Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1022 | 41023 | UCA2 (2# CA Line Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1023 | 41024 | UA2 (2# A Phase Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1024 | 41025 | UB2 (2# B Phase Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1025 | 41026 | UC2 (2# C Phase Voltage) | 0~65000 | 1 | V | 16-bit Unsigned | |
| 1026 | 41027 | UA2 Phase (2# A Phase) | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1027 | 41028 | UB2 Phase (2# B Phase) | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1028 | 41029 | UC2 Phase (2# C Phase) | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1029 | 41030 | Frequency 2 (2# Power) | 0~100.00 | 0.01 | Hz | 16-bit Unsigned | |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|--|------------------------|-------|------|-----------------|-----------------------|
| | | Frequency) | | | | | |
| 1030 | 41031 | S1S2 Volt Diff. (1#/2# Power Volt Diff.) | -32768~+32767 | 1 | V | 16-bit signed | NOTE4 |
| 1031 | 41032 | S1S2 Freq. Diff. (1#/2# Power Freq. Diff.) | -100.00~+100.00 | 0.01 | Hz | 16-bit signed | |
| 1032 | 41033 | S1S2 Phase Diff. (1#/2# Power Phase Diff.) | -180.0~+180.0 | 0.1 | ° | 16-bit signed | |
| 1033 | 41034 | / | | | | | |
| 1034 | 41035 | / | | | | | |
| 1035 | 41036 | / | | | | | |
| 1036 | 41037 | / | | | | | |
| 1037 | 41038 | / | | | | | |
| 1038 | 41039 | / | | | | | |
| 1039 | 41040 | / | | | | | |
| 1040 | 41041 | S1 A Phase Current | 0~65000 | 0.1 | A | 16-bit Unsigned | |
| 1041 | 41042 | S1 B Phase Current | 0~65000 | 0.1 | A | 16-bit Unsigned | |
| 1042 | 41043 | S1 C Phase Current | 0~65000 | 0.1 | A | 16-bit Unsigned | |
| 1043 | 41044 | S1 N Phase Current (Zero-sequence Current) | 0~65000 | 0.1 | A | 16-bit Unsigned | |
| 1044 | 41045 | S1 A Phase Current Phase | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1045 | 41046 | S1 B Phase Current Phase | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1046 | 41047 | S1 C Phase Current Phase | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1047 | 41048 | S1 N Phase Current Phase (Zero-sequence Current) | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1048 | 41049 | A Phase Active Power (LSB) | -2147483648~2147483647 | 0.1 | kW | 32-bit Signed | NOTE2 |
| 1049 | 41050 | A Phase Active Power (MSB) | | | | | |
| 1050 | 41051 | B Phase Active Power (LSB) | -2147483648~2147483647 | 0.1 | kW | 32-bit Signed | |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|------------------------------|----------------------------|-------|------|---------------|--------|
| 1051 | 41052 | B Phase Active Power (MSB) | | | | | |
| 1052 | 41053 | C Phase Active Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1053 | 41054 | C Phase Active Power (MSB) | | | | | |
| 1054 | 41055 | Total Active Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1055 | 41056 | Total Active Power (MSB) | | | | | |
| 1056 | 41057 | A Phase Reactive Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1057 | 41058 | A Phase Reactive Power (MSB) | | | | | |
| 1058 | 41059 | B Phase Reactive Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1059 | 41060 | B Phase Reactive Power (MSB) | | | | | |
| 1060 | 41061 | C Phase Reactive Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1061 | 41062 | C Phase Reactive Power (MSB) | | | | | |
| 1062 | 41063 | Total Reactive Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1063 | 41064 | Total Reactive Power (MSB) | | | | | |
| 1064 | 41065 | A Phase Apparent Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1065 | 41066 | A Phase Apparent Power (MSB) | | | | | |
| 1066 | 41067 | B Phase Apparent Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1067 | 41068 | B Phase Apparent Power (MSB) | | | | | |
| 1068 | 41069 | C Phase Apparent Power (LSB) | -2147483648~ 2147483647 | 0.1 | kW | 32-bit Signed | |
| 1069 | 41070 | C Phase Apparent Power | | | | | |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|---|------------------------|-------|------|-----------------|-------------------------------------|
| | | (MSB) | | | | | |
| 1070 | 41071 | Total Apparent Power (LSB) | -2147483648~2147483647 | 0.1 | kW | 32-bit Signed | |
| 1071 | 41072 | Total Apparent Power (MSB) | | | | | |
| 1072 | 41073 | A Phase Power Factor | -100~100 | 0.01 | | 16-bit Signed | |
| 1073 | 41074 | B Phase Power Factor | -100~100 | 0.01 | | 16-bit Signed | |
| 1074 | 41075 | C Phase Power Factor | -100~100 | 0.01 | | 16-bit Signed | |
| 1075 | 41076 | Average Power Factor | -100~100 | 0.01 | | 16-bit Signed | |
| 1076 | 41077 | / | | | | | |
| 1077 | 41078 | / | | | | | |
| 1078 | 41079 | / | | | | | |
| 1079 | 41080 | / | | | | | |
| 1080 | 41081 | / | | | | | |
| 1081 | 41082 | S1 Zero-sequence Current | 0~65000 | 0.1 | A | 16-bit Signed | |
| 1082 | 41083 | S1 Zero-sequence Current PCT On Rated Current | 0~1000 | 0.1 | % | 16-bit Unsigned | |
| 1083 | 41084 | / | | | | | |
| 1084 | 41085 | / | | | | | |
| 1085 | 41086 | Current C/O Load Breaker | 0~24 | No | | | |
| 1086 | 41087 | Load Breaker Trip Label | 0~24 | No | | | |
| 1087 | 41088 | Load Breaker C/O Fault Label | 0~24 | No | | | |
| 1088 | 41089 | S1 Volt Status | 0~65535 | No | | 16-bit Unsigned | See S1 Power Status |
| 1089 | 41090 | S1 Volt Delay | 0~65535 | 1 | s | 16-bit Unsigned | |
| 1090 | 41091 | S2 Volt Status | 0~65535 | No | | 16-bit Unsigned | See S2 Power Status |
| 1091 | 41092 | S2 Volt Delay | 0~65535 | 1 | s | 16-bit Unsigned | |
| 1092 | 41093 | Genset Status | 0~65535 | No | | 16-bit Unsigned | See Genset |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|--------------------------------------|-----------------|-------|-------|-------------------------------|-----------------------------------|
| 1093 | 41094 | Genset Delay | 0~65535 | 1 | s | 16-bit Unsigned | Status |
| 1094 | 41095 | ATS Status | 0~65535 | No | | 16-bit Unsigned | See ATS Status |
| 1095 | 41096 | ATS Delay | 0~65535 | 1 | s | 16-bit Unsigned | |
| 1096 | 41097 | / | | | | | |
| 1097 | 41098 | / | | | | | |
| 1098 | 41099 | Master Status | 0~1 | No | | 0: S1 Master; 1: S2 Master | |
| 1099 | 41100 | / | | | | | |
| 1100 | 41101 | Controller Time: Year | 0~100 | 1 | year | 16-bit Unsigned | |
| 1101 | 41102 | Controller Time: Month | 1~12 | 1 | month | 16-bit Unsigned | |
| 1102 | 41103 | Controller Time: Day | 1~31 | 1 | day | 16-bit Unsigned | |
| 1103 | 41104 | Controller Time: Week | 0~6 | / | | 16-bit Unsigned | 0: Sunday 1~6: Monday~Saturday |
| 1104 | 41105 | Controller Time: Hour | 0~23 | 1 | h | 16-bit Unsigned | |
| 1105 | 41106 | Controller Time: Minute | 0~59 | 1 | min | 16-bit Unsigned | |
| 1106 | 41107 | Controller Time: Second | 0~59 | 1 | s | 16-bit Unsigned | |
| 1107 | 41108 | / | | | | | |
| 1108 | 41109 | / | | | | | |
| 1109 | 41110 | / | | | | | |
| 1110 | 41111 | / | | | | | |
| 1111 | 41112 | Current Continuous Supply Time (h) | 0~65535 | 1 | h | 16-bit Unsigned | |
| 1112 | 41113 | Current Continuous Supply Time (min) | 0~59 | 1 | min | 16-bit Unsigned | |
| 1113 | 41114 | Continuous Supply Time (s) | 0~59 | 1 | s | 16-bit Unsigned | |
| 1114 | 41115 | Last Continuous Supply Time (h) | 0~65535 | 1 | h | 16-bit Unsigned | |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|--------------------------------------|-----------------|-------|-------|-----------------|-----------------------|
| 1115 | 41116 | Last Continuous Supply Time (min) | 0~59 | 1 | min | 16-bit Unsigned | |
| 1116 | 41117 | Last Continuous Supply Time (s) | 0~59 | 1 | s | 16-bit Unsigned | |
| 1117 | 41118 | S1 Accum. Supply Time (h) LSB | 0~4294967296 | 1 | h | 32-bit Unsigned | NOTE2 |
| 1118 | 41119 | S1 Accum. Supply Time (h) MSB | | | | | |
| 1119 | 41120 | S1 Accum. Supply Time (min) | 0~59 | 1 | min | 16-bit Unsigned | |
| 1120 | 41121 | S1 Accum. Supply Time (s) | 0~59 | 1 | s | 16-bit Unsigned | |
| 1121 | 41122 | S2 Accum. Supply Time (h) LSB | 0~4294967296 | 1 | h | 32-bit Unsigned | NOTE2 |
| 1122 | 41123 | S2 Accum. Supply Time (h) MSB | | | | | |
| 1123 | 41124 | S2 Accum. Supply Time (min) | 0~59 | 1 | min | 16-bit Unsigned | |
| 1124 | 41125 | S2 Accum. Supply Time (s) | 0~59 | 1 | s | 16-bit Unsigned | |
| 1125 | 41126 | S1 Accum. Active Power kWh (LSB) | 0-999999999 | 0.1 | kWh | 32-bit Signed | NOTE2 |
| 1126 | 41127 | S1 Accum. Active Power kWh (MSB) | | | | | |
| 1127 | 41128 | S1 Accum. Reactive Power kvarh (LSB) | 0-999999999 | 0.1 | kvarh | 32-bit Signed | |
| 1128 | 41129 | S1 Accum. Reactive Power kvarh (MSB) | | | | | |
| 1129 | 41130 | S1 Accum. Close Times (LSB) | 0~4294967296 | 1 | times | 32-bit Unsigned | |
| 1130 | 41131 | S1 Accum. Close Times (MSB) | | | | | |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|---------------------------------------|-----------------|-------|-------|-----------------|-----------------------|
| 1131 | 41132 | S2 Accum. Active Power kWh (LSB) | 0-99999999 | 0.1 | kWh | 32-bit Signed | |
| 1132 | 41133 | S2 Accum. Active Power kWh (MSB) | | | | | |
| 1133 | 41134 | S2 Accum. Reactive Power kvarh (LSB) | 0-99999999 | 0.1 | kvarh | 32-bit Signed | |
| 1134 | 41135 | S2 Accum. Reactive Power kvarh (MSB) | | | | | |
| 1135 | 41136 | S2 Accum. Close Times (LSB) | 0~4294967296 | 1 | times | 32-bit Unsigned | |
| 1136 | 41137 | S2 Accum. Close Times (MSB) | | | | | |
| 1137 | 41138 | Accum. Auto Transfer Times (LSB) | 0~4294967296 | 1 | times | 32-bit Unsigned | |
| 1138 | 41139 | Accum. Auto Transfer Times (MSB) | | | | | |
| 1139 | 41140 | Mains No Transfer Times (LSB) | 0~4294967296 | 1 | times | 32-bit Unsigned | |
| 1140 | 41141 | Mains No Transfer Times (MSB) | | | | | |
| 1141 | 41142 | Accum. Auto Transfer Run Time (h) LSB | 0~4294967296 | 1 | h | 32-bit Unsigned | |
| 1142 | 41143 | Accum. Auto Transfer Run Time (h) MSB | | | | | |
| 1143 | 41144 | Accum. Auto Transfer Run Time (min) | 0~59 | 1 | min | 16-bit Unsigned | |
| 1144 | 41145 | Accum. Auto Transfer Run Time (s) | 0~59 | 1 | s | 16-bit Unsigned | |
| 1145 | 41146 | BPS1 Accum. Close Times LSB | 0~4294967296 | 1 | times | 32-bit Unsigned | NOTE2 |
| 1146 | 41147 | BPS1 Accum. Close Times MSB | | | | | |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|---|-----------------|-------|-------|-----------------|--------|
| | | Close Times MSB | | | | | |
| 1147 | 41148 | BPS2 Accum. Close Times LSB | 0~4294967296 | 1 | times | 32-bit Unsigned | |
| 1148 | 41149 | BPS2 Accum. Close Times MSB | | | | | |
| 1149 | 41150 | / | | | | | |
| 1150 | 41151 | / | | | | | |
| 1151 | 41152 | S2 A Phase Current | 0~65000 | 0.1 | A | 16-bit Unsigned | |
| 1152 | 41153 | S2 B Phase Current | 0~65000 | 0.1 | A | 16-bit Unsigned | |
| 1153 | 41154 | S2 C Phase Current | 0~65000 | 0.1 | A | 16-bit Unsigned | |
| 1154 | 41155 | S2 N Line Current (Zero-sequence Current, Ground Current) | 0~65000 | 0.1 | A | 16-bit Unsigned | |
| 1155 | 41156 | S2 A Phase Current Phase | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1156 | 41157 | S2 B Phase Current Phase | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1157 | 41158 | S2 C Phase Current Phase | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1158 | 41159 | S2 N Line Current Phase | 0~360.0 | 0.1 | ° | 16-bit Unsigned | |
| 1159 | 41160 | S2 Zero-sequence Current | 0~65000 | 0.1 | A | 16-bit Signed | |
| 1160 | 41161 | S2 Zero-sequence Current PCT | 0~1000 | 0.1 | % | 16-bit Unsigned | |
| 1161 | 41162 | / | | | | | |
| 1162 | 41163 | / | | | | | |
| 1163 | 41164 | / | | | | | |
| 1164 | 41165 | / | | | | | |
| 1165 | 41166 | / | | | | | |
| 1166 | 41167 | / | | | | | |
| 1167 | 41168 | / | | | | | |
| 1168 | 41169 | / | | | | | |
| 1169 | 41170 | / | | | | | |

| Modbus Address | PLC Address | Name | Range (Decimal) | Ratio | Unit | Description | Remark |
|----------------|-------------|------|-----------------|-------|------|-------------|--------|
| 1170 | 41171 | / | | | | | |
| 1171 | 41172 | / | | | | | |
| 1172 | 41173 | / | | | | | |
| 1173 | 41174 | / | | | | | |
| 1174 | 41175 | / | | | | | |
| 1175 | 41176 | / | | | | | |
| 1176 | 41177 | / | | | | | |
| 1177 | 41178 | / | | | | | |
| 1178 | 41179 | / | | | | | |
| 1179 | 41180 | / | | | | | |

NOTE1: Actual value=Received Data*Ratio. Take frequency as the example, received data is 5000 (1388H), ratio is 0.01Hz, so the actual frequency value is 50.00Hz (5000*0.01Hz);

NOTE2: For 4-byte data, the actual value=Received Data MSB*65536 + Received Data LSB;

NOTE3: When the received data is 32766, it means no normal data, “###” can be displayed;

NOTE4: Definition of signed number. Take received data 8000H as the example, transfer it to binary 1000 0000 0000 0000b, the MSB is 1, which is a negative number. One’s complement is obtained by subtracting 1 from it, which is inverted to obtain the absolute value of the negative number. Then transfer it to -32768 in decimal.

Example:

Read “S1 Accum. Close Times (current is 123456 times)”, firstly get their corresponding address is 1129 and 1130 by checking the table, then it is known that you need to read 2 bytes’ data.

Assume the slave address is 01, the master request command is as following:

Table 7 – Master Request Command

| Slave Address | Function Code | Starting Address (1129) | | Data Qty. (2) | | CRC 16 Calibration | |
|---------------|---------------|-------------------------|-----------|---------------|-----------|--------------------|-----------|
| | | MSB | LSB | MSB | LSB | LSB | MSB |
| 01 | 03 | 04 | 69 | 00 | 02 | 15 | 27 |

Slave response command is as following:

Table 8 – Slave Response Command

| Slave Address | Function Code | Data Qty. (Bytes) | Data | | | | CRC 16 Calibration | |
|---------------|---------------|-------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------|-----------|
| | | | Data MSB of Address 1129 | Data LSB of Address 1129 | Data MSB of Address 1130 | Data LSB of Address 1130 | LSB | MSB |
| 01 | 03 | 04 | E2 | 40 | 00 | 01 | 0C | 5F |

Fill the received data into the corresponding address, as shown in the table below:

Table 9 – Data Analysis

| Address | Received Data (Hex) | Combination (Hex) | S1 Accum. Close Times (Decimal) |
|---------|---------------------|-------------------|---------------------------------|
| 1129 | E240H | 0001E240H | 123456 |
| 1130 | 0001H | | |

3.4 REMOTE COIL FIELD CORRESPONDING TO FUNCTION CODE 05H

Table 10 – Remote Coil Field

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|---------------------------------------|--|
| 400 | 401 | Remote MS1 Close | Only send FF00H active |
| 401 | 402 | Remote MS Open | Only send FF00H active |
| 402 | 403 | Remote MS2 Close | Only send FF00H active |
| 403 | 404 | Remote MS Open (same as address 401H) | Only send FF00H active |
| 404 | 405 | Auto/Manual | Manual Mode: Only send 0000H active Auto Mode: Only send FF00H active |
| 405 | 406 | S1 Master Status Set | Only send FF00H active |
| 406 | 407 | S2 Master Status Set | Only send FF00H active |
| 407 | 408 | Alarm Reset | Only send FF00H active |
| 408 | 409 | Remote Genset Start (S1) | Only send FF00H active |
| 409 | 410 | Remote Genset Stop (S1) | Only send FF00H active |
| 410 | 411 | Remote Genset Start (S2) | Only send FF00H active |
| 411 | 412 | Remote Genset Stop (S2) | Only send FF00H active |
| 412 | 413 | Remote Output 1 Output | Only send FF00H active |
| 413 | 414 | Remote Output 2 Output | Only send FF00H active |
| 414 | 415 | Remote Output 3 Output | Only send FF00H active |
| 415 | 416 | Remote Output 4 Output | Only send FF00H active |
| 416 | 417 | Remote Output 5 Output | Only send FF00H active |
| 417 | 418 | Remote Output 6 Output | Only send FF00H active |
| 418 | 419 | Remote Output 7 Output | Only send FF00H active |
| 419 | 420 | Remote Output 8 Output | Only send FF00H active |
| 420 | 421 | Remote Output 9 Output | Only send FF00H active |
| 421 | 422 | Remote Output 10 Output | Only send FF00H active |
| 422 | 423 | Remote Output 11 Output | Only send FF00H active |
| 423 | 424 | Remote Output 12 Output | Only send FF00H active |
| 424 | 425 | Remote Output 13 Output | Only send FF00H active |
| 425 | 426 | / | Only send FF00H active |
| 426 | 427 | Window Prompt Confirm | Only send FF00H active |
| 427 | 428 | Window Prompt Cancel | Only send FF00H active |
| 428 | 429 | / | Only send FF00H active |
| 429 | 430 | / | Only send FF00H active |
| 430 | 431 | Load 1 Close Control | Only send FF00H active |
| 431 | 432 | Load 1 Open Control | Only send FF00H active |
| 432 | 433 | Load 2 Close Control | Only send FF00H active |
| 433 | 434 | Load 2 Open Control | Only send FF00H active |
| 434 | 435 | Load 3 Close Control | Only send FF00H active |
| 435 | 436 | Load 3 Open Control | Only send FF00H active |
| 436 | 437 | Load 4 Close Control | Only send FF00H active |
| 437 | 438 | Load 4 Open Control | Only send FF00H active |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|-----------------------|------------------------|
| 438 | 439 | Load 5 Close Control | Only send FF00H active |
| 439 | 440 | Load 5 Open Control | Only send FF00H active |
| 440 | 441 | Load 6 Close Control | Only send FF00H active |
| 441 | 442 | Load 6 Open Control | Only send FF00H active |
| 442 | 443 | Load 7 Close Control | Only send FF00H active |
| 443 | 444 | Load 7 Open Control | Only send FF00H active |
| 444 | 445 | Load 8 Close Control | Only send FF00H active |
| 445 | 446 | Load 8 Open Control | Only send FF00H active |
| 446 | 447 | Load 9 Close Control | Only send FF00H active |
| 447 | 448 | Load 9 Open Control | Only send FF00H active |
| 448 | 449 | Load 10 Close Control | Only send FF00H active |
| 449 | 450 | Load 10 Open Control | Only send FF00H active |
| 450 | 451 | Load 11 Close Control | Only send FF00H active |
| 451 | 452 | Load 11 Open Control | Only send FF00H active |
| 452 | 453 | Load 12 Close Control | Only send FF00H active |
| 453 | 454 | Load 12 Open Control | Only send FF00H active |
| 454 | 455 | Load 13 Close Control | Only send FF00H active |
| 455 | 456 | Load 13 Open Control | Only send FF00H active |
| 456 | 457 | Load 14 Close Control | Only send FF00H active |
| 457 | 458 | Load 14 Open Control | Only send FF00H active |
| 458 | 459 | Load 15 Close Control | Only send FF00H active |
| 459 | 460 | Load 15 Open Control | Only send FF00H active |
| 460 | 461 | Load 16 Close Control | Only send FF00H active |
| 461 | 462 | Load 16 Open Control | Only send FF00H active |
| 462 | 463 | Load 17 Close Control | Only send FF00H active |
| 463 | 464 | Load 17 Open Control | Only send FF00H active |
| 464 | 465 | Load 18 Close Control | Only send FF00H active |
| 465 | 466 | Load 18 Open Control | Only send FF00H active |
| 466 | 467 | Load 19 Close Control | Only send FF00H active |
| 467 | 468 | Load 19 Open Control | Only send FF00H active |
| 468 | 469 | Load 20 Close Control | Only send FF00H active |
| 469 | 470 | Load 20 Open Control | Only send FF00H active |
| 470 | 471 | Load 21 Close Control | Only send FF00H active |
| 471 | 472 | Load 21 Open Control | Only send FF00H active |
| 472 | 473 | Load 22 Close Control | Only send FF00H active |
| 473 | 474 | Load 22 Open Control | Only send FF00H active |
| 474 | 475 | Load 23 Close Control | Only send FF00H active |
| 475 | 476 | Load 23 Open Control | Only send FF00H active |
| 476 | 477 | Load 24 Close Control | Only send FF00H active |
| 477 | 478 | Load 24 Open Control | Only send FF00H active |
| 478 | 479 | / | Only send FF00H active |
| 479 | 480 | / | Only send FF00H active |
| 480 | 481 | Remote BPS1 Close | Only send FF00H active |

| Modbus Address | PLC Address | Name | Description |
|----------------|-------------|--|------------------------|
| 481 | 482 | Remote BPS Open | Only send FF00H active |
| 482 | 483 | Remote BPS2 Close | Only send FF00H active |
| 483 | 484 | Remote BPS Open (same as address 481H) | Only send FF00H active |
| 484 | 485 | Main and Bypass Switch Unlock | Only send FF00H active |

NOTE: Remote command in the above table can be sent once only.

Example:

Remotely control controller to work in auto mode, firstly get its remote address is 404 by checking the table.

Assume that slave address is 01, the master request command is as following:

Table 11 – Master Request Command

| Slave Address | Function Code | Remote Address (404) | | Data | | CRC 16 Calibration | |
|---------------|---------------|----------------------|-----|------|-----|--------------------|-----|
| | | MSB | LSB | MSB | LSB | LSB | MSB |
| 01 | 05 | 01 | 94 | FF | 00 | CC | 2A |

Slave response command is as following:

Table 12 – Slave Response Command

| Slave Address | Function Code | Remote Address (404) | | Data | | CRC 16 Calibration | |
|---------------|---------------|----------------------|-----|------|-----|--------------------|-----|
| | | MSB | LSB | MSB | LSB | LSB | MSB |
| 01 | 05 | 01 | 94 | FF | 00 | CC | 2A |

Then whether the remote command is executed successfully can be confirmed by reading the auto mode status of address 500.8 via function code 03H.

3.5 S1 POWER STATUS DESCRIPTION

Table 13 – S1 Power Status Description

| Value (No.) | Status | Delay |
|-------------|---------------------------|-----------------|
| 0 | S1 Available | Delay (Unit: s) |
| 1 | S1 Unavailable | Delay (Unit: s) |
| 2 | S1 Voltage Normal | No Delay |
| 3 | S1 Blackout | No Delay |
| 4 | S1 Over Voltage | No Delay |
| 5 | S1 Under Voltage | No Delay |
| 6 | S1 Over Frequency | No Delay |
| 7 | S1 Under Frequency | No Delay |
| 8 | S1 Loss of Phase | No Delay |
| 9 | S1 Reverse Phase Sequence | No Delay |

Example:

If the content of address 1088 is 1, 1089 is 5, it indicates that currently 1# power is in voltage abnormal delay, countdown 5s.

If the content of address 1088 is 4, it indicates that currently 1# power has over voltage.

3.6 S2 POWER STATUS DESCRIPTION

Table 14 – S2 Power Status Description

| Value (No.) | Status | Delay |
|-------------|---------------------------|-----------------|
| 0 | S2 Available | Delay (Unit: s) |
| 1 | S2 Unavailable | Delay (Unit: s) |
| 2 | S2 Voltage Normal | No Delay |
| 3 | S2 Blackout | No Delay |
| 4 | S2 Over Voltage | No Delay |
| 5 | S2 Under Voltage | No Delay |
| 6 | S2 Over Frequency | No Delay |
| 7 | S2 Under Frequency | No Delay |
| 8 | S2 Loss of Phase | No Delay |
| 9 | S2 Reverse Phase Sequence | No Delay |

3.7 GENSET STATUS DESCRIPTION

Table 15 – Genset Status Description

| Value (No.) | Status | Delay |
|-------------|-------------------|-----------------|
| 0 | Start Delay | Delay (Unit: s) |
| 1 | Stop Delay | Delay (Unit: s) |
| 2 | Scheduled Not Run | Delay (Unit: s) |
| 3 | Scheduled Run | Delay (Unit: s) |
| 4 | S1 Cycle Start | Delay (Unit: s) |
| 5 | S2 Cycle Start | Delay (Unit: s) |
| 6 | S1 Genset Start | No Delay |
| 7 | S2 Genset Start | No Delay |
| 8 | Genset Start | No Delay |
| 9 | Genset Standby | No Delay |

Example:

If the content of address 1092 is 1, 1093 is 50, it indicates that genset is preparing to start, countdown 50s.

If the content of address 1092 is 6, it indicates that 1# power corresponding genset has been started.

3.8 ATS STATUS DESCRIPTION

Table 16 – ATS Status Description

| Value (No.) | Status | Delay |
|-------------|------------------------|-----------------|
| 0 | Ready to Transfer | No Delay |
| 1 | MS1/BPS1 Closing | Delay (Unit: s) |
| 2 | MS1/BPS1 Opening | Delay (Unit: s) |
| 3 | MS2/BPS2 Closing | Delay (Unit: s) |
| 4 | MS2/BPS2 Opening | Delay (Unit: s) |
| 5 | Transfer Rest | Delay (Unit: s) |
| 6 | Closing MS1/BPS1 Again | Delay (Unit: s) |
| 7 | Opening MS1/BPS1 Again | Delay (Unit: s) |
| 8 | Closing MS2/BPS2 Again | Delay (Unit: s) |
| 9 | Opening MS2/BPS2 Again | Delay (Unit: s) |
| 10 | Wait for Sync | Delay (Unit: s) |
| 11 | MS1/BPS1 Sync. Close | Delay (Unit: s) |
| 12 | MS2/BPS2 Sync. Close | Delay (Unit: s) |
| 13 | Wait MS1/BPS1 PF Input | Delay (Unit: s) |
| 14 | Wait MS2/BPS2 PF Input | Delay (Unit: s) |
| 15 | Elevator Control Delay | Delay (Unit: s) |
| 16 | MS1 On-load | No Delay |
| 17 | MS2 On-load | No Delay |
| 18 | Off-load | No Delay |
| 19 | BPS1 Closing | Delay (Unit: s) |
| 20 | BPS1 Opening | Delay (Unit: s) |
| 21 | BPS2 Closing | Delay (Unit: s) |
| 22 | BPS2 Opening | Delay (Unit: s) |
| 23 | BPS1 On-load | No Delay |
| 24 | BPS2 On-load | No Delay |
| 25 | S1 Parallel On-load | No Delay |
| 26 | S2 Parallel On-load | No Delay |
| 27 | / | |
| 28 | / | |
| 29 | / | |
| 30 | / | |
| 31 | QTIE Closing | Delay (Unit: s) |
| 32 | QTIE Opening | Delay (Unit: s) |
| 33 | S1 Load Stepwise Close | No Delay |
| 34 | S1 Load Stepwise Open | No Delay |
| 35 | S2 Load Stepwise Close | No Delay |
| 36 | S2 Load Stepwise Open | No Delay |

4. COMMUNICATION PARAMETER VIEW AND CONFIGURATION

4.1 VIEW CURRENT COMMUNICATION PARAMETERS

In controller main interface, press  key, the following interface is displayed.




Fig.3 Comm. Parameters Interface

This interface displays **RS485-1 9600bps, 8, N, None**, which indicates that the current communication rate of RS485-1 is 9600bps, data bit is 8-bit, stop bit is 2-bit, no parity (N: No parity/O: Odd parity/E: Even parity).

4.2 COMMUNICATION PARAMETERS CONFIGURATION

- 1) In the home page of main interface, press  key to enter menu interface;
- 2) Press Down key to select "Parameter Setting", then press  key to enter parameter password interface;
- 3) Input correct password (default 01234), press  key to enter the main interface of parameter;
- 4) Select "Module Setting" via  key, press  key to enter submenu;
- 5) Select "Module Address" via ,  key, Press  key to enter parameter edit function, corresponding parameters will be in the selected status;
- 6) Set the current selected content via ,  key, press  key to complete editing, then the selected status disappear;
- 7) Long press  key to return the main interface.

NOTE: The configuration will be active after parameter setting is completed.

5. FAQ

5.1 COMMUNICATION LINE SHIELDING LAYER GROUNDED

In order to prevent coupled interference signal on communication line, its single end needs to be grounded.

5.2 TERMINAL RESISTOR

At both ends of the linear network (on the two communication ports furthest apart), it is necessary to connect 120Ω terminal resistor in parallel on a pair of communication lines. According to the transmission line theory, the terminal resistor can absorb reflected waves on the network, effectively enhancing the signal strength. The value of two terminal resistors in parallel should be approximately equal to the characteristic impedance of the transmission line at the communication frequency.

A regular RS485 network usually uses terminal resistor. It can also be not used in the case of network connection line is very short, temporary or laboratory test.

5.3 RS485 TO USB COMMUNICATION ADAPTOR

PC can communicate with SG72A module produced by our company.

5.4 EXTENDED COMMUNICATION DISTANCE

Long distance (up to 10km) communication can be realized by a pair of SGCAN300 CANBUS relay modules.



Fig.4 SGCAN300 Application Diagram

5.5 COMMON SOLUTIONS OF COMMUNICATION FAILURE

- 1) Check whether the positive and negative of RS485 is correctly connected;
- 2) Check whether the communication parameter setting in parameter setting is correct;
- 3) Check whether the RS485 converter (if configured) is normal;
- 4) Check whether the terminal resistor is correctly connected;
- 5) Disconnect the connection line of controller's RS485, measure the voltage difference of RS485's A and B terminal. If the difference is between $\pm 200\text{mV}$, it means communication port has abnormal situation;
- 6) It is recommended to download third-party communication software such as modscan32, modbus poll to check whether communication is normal.