

# SmartGen

MAKING CONTROL SMARTER

## HED400 ENGINE MONITORING MODULE USER MANUAL



郑州众智科技股份有限公司  
SMARTGEN(ZHENGZHOU)TECHNOLOGY CO.,LTD.

## SmartGen Registered trademark

No. 28 Xuemei Street, Zhengzhou, Henan, China

Tel: +86-371-67988888/67981888/67992951

+86-371-67981000 (overseas)

Fax: +86-371-67992952

Web: [www.smartgen.com.cn/](http://www.smartgen.com.cn/)

[www.smartgen.cn/](http://www.smartgen.cn/)

Email: [sales@smartgen.cn](mailto:sales@smartgen.cn)

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

SmartGen reserves the right to change the contents of this document without prior notice.

**Table 1 Software Version**

Date	Version	Note
2025-03-26	1.0	Original release.

**Table 2 Notation Clarification**

Sign	Instruction
 NOTE	Highlights an essential element of a procedure to ensure correctness.
 CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
 WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

SmartGen

## CONTENT

1 OVERVIEW .....	5
2 PERFORMANCE AND CHARACTERISTICS .....	5
3 SPECIFICATION .....	6
4 OPERATION .....	7
4.1 CONTROLLER PANEL .....	7
4.2 KEYS FUNCTION DESCRIPTION .....	8
5 MAIN SCREEN DISPLAY PARAMETER SETTING .....	9
6 USER MENU AND PARAMETER SETTING .....	11
7 PARAMETER SETTING RANGE AND DEFINITION .....	13
7.1 MAIN SCREEN DISPLAY SETTING .....	18
7.2 PROGRAMMABLE OUTPUT PORT ITEMS .....	18
7.3 DEFINED COMINATION OUTPUT .....	20
7.4 DEFINITION CONTENTS OF DIGITAL INPUT PORTS 1~3 .....	20
7.5 EVENT LOG .....	22
8 SPEED CONTROL .....	22
8.1 KEY/INPUT PORT SPEED CONTROL .....	22
8.2 THROTTLE SPEED CONTROL .....	22
8.3 PRIORITY DESCRIPTION FOR GEAR INPUT PORT .....	23
9 LOCAL REMOTE MODE .....	23
10 CUSTOM SPN FAULT CODES .....	23
11 SENSOR CURVE SETTING .....	24
12 ALARMS .....	26
13 WIRE CONNECTION .....	27
14 TYPICAL APPLICATION .....	29
15 INSTALLATION .....	30
15.1 FIXING CLIPS .....	30
15.2 OVERALL DIMENSIONS AND PANEL CUTOUT .....	31
16 CONNECTIONS OF CONTROLLER WITH J1939 ENGINE .....	32
16.1 CUMMINS ISB/ISBE .....	32
16.2 VOLVO .....	32
16.3 YUCHAI .....	32
16.4 WEICHAI .....	33
17 TROUBLE SHOOTING .....	34

## 1 OVERVIEW

**HED400 Engine Monitoring Module** can be used for single engine monitoring to realize the functions of speed control, data measurement and alarm display, etc. It fits with color LCD display, optional Chinese and English, which enables simple operation and reliable running.

**HED400 Engine Monitoring Module** applies 32-bit microprocessor technology, realizing precise measuring of multiple parameters, value adjusting and threshold setting etc. The parameters can be adjusted from the front panel or by PC software. With compact structure, simple wiring and high reliability, it can be used in various engine automation systems.

## 2 PERFORMANCE AND CHARACTERISTICS

- Applies 32-bit high-performance SCM, high integration of hardware;
- 4.3-inch color LCD display, resolution 480x272 with adjustable backlight, optional Chinese and English, etc.;
- The RS485 communication interface can set baud rate and adjust parameters via PC;
- The CANBUS interface can connect ECU with J1939 and monitor ECU common data (water temperature, oil pressure, speed, fuel consumption, etc.), and also can control speed;
- ECU fault code analysis function is fitted;
- With 6-way analog sensor input ports that all interfaces support resistance sensors, among which the sensor 3-6 input ports can support current and voltage types;
- Multiple kinds of curves of temperature, oil pressure, fuel level sensors are optional and users can define the sensor curves by themselves;
- With maintenance function, alarm will be issued for maintenance time due;
- Support non-road China IVengine;
- Wide power supply range DC (8-35)V, which can suit different starting battery voltage environment;
- Silicone panel and pushbuttons, hard screen acrylic for screen protection;
- Sealed enclosure design, the whole unit protection can reach IP65;
- Modular design, high-quality anti-flaming shell, specified connector, embedded mounting, compact structure and easy installation.

3 SPECIFICATION

Table 3 Technical Parameters

Items	Contents
Operating Voltage	DC8V~DC35V, DC reverse connection protection Resolution: 0.1V Accuracy: 1%
Overall Consumption	<7W (Standby mode: <2W)
Speed Sensor	Voltage Range: 1.0V~ 24V (RMS) Frequency Range: 5Hz~10000Hz
Charger(D+) Voltage	Range: DC0V ~ DC60V Resolution: 0.1V Accuracy: 1%
Analog Sensor	Resistance Input Range: 0Ω ~ 6000Ω Resolution: 0.1Ω Accuracy: 1Ω (below 300Ω)
	Voltage Input Range: 0V ~ 5V Resolution: 0.001V Accuracy: 1%
	Current Input Range: 0mA ~ 20mA Resolution: 0.01mA Accuracy: 1%
Digital Output 1-3	5A DC28V DC power supply output (relay output)
Aux. Input 1-3	Active when connect to negative of power supply Low threshold voltage: 1.2V High limit input voltage: 60V
RS485 Interface	Isolated, half-duplex, 9600 bps baud rate, the max communication length 1,000m
CAN Interface	Isolated, the max communication length 250m, using Belden 9841 cable or equivalent
CM-EMC Certificate	EN 55032, EN 55024
Vibration Test	5 Hz~ 8 Hz ±17 mm 8 Hz ~100 Hz: a= 4g 100 ~ 500Hz: a=2g IEC 60068-2-6
Shock Test	50g, 11ms, half-sine, three consecutive shocks are applied from each of the three perpendicular directions, a total of 18 times IEC 60068-2-27
Bump Test	20g, 16ms, half-sine IEC 60255-21-2
Case Dimensions	127mm x 115mm x 55.9mm

Items	Contents
Panel Cutout	115mm x 103mm
Working Temperature	(-25~+70)°C
Working Humidity	(20~93)%RH
Storage Temperature	(-30~+80)°C
Protection Level	IP65
Weight	0.45kg

## 4 OPERATION

### 4.1 CONTROLLER PANEL



Fig.1 HED400 Front Panel Indication

**NOTE:** Partial icon' description.

Table 4 Icons Description

Icon	Function	Description
	After-treatment Icon	Engine fault
	After-treatment Icon	High exhaust temperature indicator light
	After-treatment Icon	NCD status indicator light
	After-treatment Icon	DWS/ driver warning indicator light
	After-treatment Icon	DPF regeneration request
	After-treatment Icon	DPF Regeneration inhibit

## 4.2 KEYS FUNCTION DESCRIPTION

On homepage, if no key is pressed for 20s, the icons will automatically hide. Press any key to show the key icons again.

**Table 5 Keys Description**

Icon	Keys	Description
	Alarm View	When not on alarm page, press this key can skip to the alarm page.
	Return	Press this key to return to the previous page on menu page.
	Homepage	Press this key to return to homepage. Long press this key on main screen to enter the menu page.
	Left/Decrease	Press this key to turn the page left when switching the page; Press this key to move the cursor up; Press this key to decrease the number by one.
	Right/Increase	Press this key to turn the page right when switching the page; Press this key to move the cursor down; Press this key to increase the number by one.
	Confirm	Press this key to confirm the current configuration during parameter setting.
	Speed Control	Press this key, the controller will enter the speed control screen.
	Speed Up	After pressing this key, the engine will increase the setting speed.
	Speed Down	After pressing this key, the engine will decrease the setting speed.
	Brightness	On main screen, press Left key + Right key simultaneously to enter the LCD backlight settings.

**▲NOTE:** Press any key to mute the sound on main screen.

## 5 MAIN SCREEN DISPLAY PARAMETER SETTING


The display theme of main screen can be set to instrument or four parameters display.



**Fig.2 Instrument Display**



**Fig.3 Four Parameters Display**



**Fig.4 Alarms Display**



**Fig.5 Input /Output Ports**

Maintenance	01/01
Maint. 1 Countdown	180:25:23
Maint. 2 Countdown	20:15:37
Maint. 3 Countdown	1070:37:18

Fig.6 Maintenance

Detail Infomation	01/01
Aux Sensor 1	+++°C
Aux Sensor 2	+++kPa
Aux Sensor 3	+++%
Aux Sensor 4	+++°C
Torque Percent	72%

Fig.7 Details Information




Fig.8 Brightness Adjustment

**▲NOTE:** On brightness adjustment screen, when the brightness level reaches 100%, press the brightness increase key again to enter the backlight on mode.

6 USER MENU AND PARAMETER SETTING

Press  on the main screen, it will enter user menu, items are as follows:


- Parameter Setting: input the correct password (factory default is 00000) to enter the user parameter setting screen.
- Manufacturer Parameter Setting: input the correct password (factory default is 00318) to enter the manufacturer setting screen.
- Maintenance Setting: input the correct password (factory default is 01234) to enter the maintenance setting screen.
- Language Selection: to select simplified Chinese, English.
- ECU DM2: to display DM2 fault code of engine.
- Backlight Adjustment: to adjust the screen backlight.
- Controller Information: to view the development information of controller, such as software version, hardware version and release date.
- Event Log: to enter the details page of event log.

Parameter setting includes the following contents:

- Module Setting
- Engine Setting
- Speed Control Setting
- Flexible Sensor Setting
- Aux. Input Ports
- Aux. Output Ports
- Maintenance Setting
- Intelligent Display Setting

For example:

Table 6 Menu Screen

Configuration Screen	Description	
<b>★Menu Setting</b>		
		Return to the previous menu.
		Move the cursor to the previous line.
		Confirm it to enter the menu corresponding to cursor.
		Move the cursor to the next line.
		Move the cursor to the homepage.
<b>★Module Setting</b>		
		Return to the previous menu.
		Move the cursor to the previous line; press it to decrease the number.
		Press it to adjust the parameter; press it again to save after adjustment.
		Move the cursor to the next line; press the confirm key to increase the number.
		One-touch back to homepage.

Configuration Screen	Description	
★Engine Type Setting		
 <p>Engine Type: 0: Non-ECU            ▶ 0: Non-ECU            1: General ECU            2: GTSCI-PLUS            3: VOLVO            4: CAT            5: KUBOTA</p>		Return to the previous menu.
		Move the cursor to the previous line.
		Press it to confirm the configuration.
		Move the cursor to the next line.
		One-touch back to homepage.
★Speed Control Setting		
 <p>Local Thro. Adj Set            0: Disable            Sensor Channel Flexible Sensor 3            Sensor Type 0: Voltage            Start Value 00.75V            Max Value 03.84V</p>		Return to the previous menu.
		Move the cursor to the previous line when no adjustment is made. Change selection during adjustment. Decrease the number during adjustment.
		Press it to adjust parameters; press it again to save the parameter after adjustment.
		Return to the previous menu when no adjustment is made; Change the selections during adjustment. Increase the number during adjustment.
		One-touch back to home page.

**NOTE:**

- Please modify the parameters in standby mode (crank disconnect speed, flex. sensor and speed control setting, etc.) otherwise abnormal conditions may appear.
- High threshold must be greater than the low threshold; otherwise high and low condition may occur at the same time.
- Please set the return value correctly in setting warning alarm, otherwise abnormal alarm will occur. When setting high warning, return value should be less than setting value while return value should be greater than setting value in setting low warning.

7 PARAMETER SETTING RANGE AND DEFINITION

Table 7 Parameter Setting Content and Range

No.	Item	Range	Default	Description	
Language Setting					
1	Language	(0-1)	0	0: Simplified Chinese; 1: English	
Module Setting					
1	User Password	(0-65534)	0	The password for entering user parameter setting.	
2	Manufacturer Password	(0-65534)	00318	The password for entering advanced parameter setting. <b>⚠ CAUTION:</b> Default password is "00318", operator can change the password to prevent others from changing the advanced configuration randomly. Please remember it after changing, if forget it, please contact the company service personnel.	
3	Maintenance Password	(0-65534)	01234	The password for entering maintenance parameter setting.	
4	Comm. Address	(1-254)	1	Controller address in remote monitoring.	
5	Local/Remote Select	(0-1)	0	0: Local Mode; 1: Remote Mode	
6	RS485 Comm. Baud Rate	(0-2)	0	0: 9600bps 1: 19200bps 2: 38400bps	
7	Stop Bit	(0-1)	0	0: 1-bit; 1: 2-bit	
8	Parity Bit	(0-2)	0	0: None; 1: Odd; 2: Even	
9	RS485 Resistor	(0-1)	0	0: Disable; 1: Enable	
10	CAN Baud Rate	(0-1)	0	0: 250kbps; 1: 500kbps	
11	CAN Resistor	(0-1)	0	0: Disable; 1: Enable	
12	Boot Screen Set	(0-1)	0	0: Disable; 1: Enable	
13	Boot Screen Duration	(0-3600)s	2	The duration for boot screen.	
14	Theme Select	(0-1)	0	0: Tachometer; 1: Four Parameters	
15	Top Left Display	(0-17)	1	See Table of Main Screen Display Setting for the details.	
16	Bottom Left Display	(0-17)	3		
17	Top Right Display	(0-17)	2		
18	Bottom Right Display	(0-17)	4		
19	Manufacturer Device Information	(0-1)	0	0: Disable; 1: Enable	
20	LCD Backlight	Brightness	(1-10)	10	The higher the brightness number, the brighter the backlight. When the button is not operated, the backlight delay begins. Once the time is up, the always on brightness is executed.
		Delay	(0-5)min	1	
		Always On	(0-10)	0	

No.	Item		Range	Default	Description
		Brightness			
Engine Setting					
1	Engine Type		(0-29)	1	Default: general unit. Select corresponding engine model for connecting different J1939 units.
2	Flywheel Teeth		(1.0-300.0)	118.0	Tooth number of the engine, for judging of starter separation conditions and inspecting of engine speed. See the following installation description.
3	Idle Speed		(0-6000)RPM	750	Standard for min.speed adjustment.
4	Rated Speed		(0-6000)RPM	2000	Standard for overspeed judgment and max. speed regulation.
5	Crank Speed	Disconnect	(0-1000)RPM	350	When speed exceeds the set value, controller determines that the engine has started successfully.
6	ECU Address		(0-255)	3	Engine speed control address.
7	DPF Regeneration Control Address		(0-255)	33	The address of engine regeneration control.
8	Over Speed Warn Set	Enable	(0-1)	0	Set value is the percentage of rated speed, return value and delay value can be set.
		Set	(0-200.0)%	110.0	
		Return	(0-200.0)%	108.0	
		Delay	(0-3600)s	5	
9	Battery Rated Voltage		(0-60.0)V	24.0	Standard for battery over/under voltage.
10	Overvolt Warn	Enable	(0-1)	0	Set value is the percentage of battery rated voltage, return value and delay value can be set.
		Set	(0-200)%	120	
		Return	(0-200)%	115	
		Delay	(0-3600)s	60	
11	Undervolt Warn	Enable	(0-1)	0	0: Disable; 1: Enable
		Set	(0-200)%	85	Set value is the percentage of battery rated voltage, return value and delay value can be set.
		Return	(0-200)%	90	
		Delay	(0-3600)s	60	
12	Aftertreatment Icon Display		(0-1)	1	0: Disable; 1: Enable
13	Charger Signal Source		(0-1)	0	0: ECU; 1: Analog
14	Charge Alt Fail	Enable	(0-1)	0	0: Disable; 1: Enable
		Set	(0-60.0)V	8.0	During engine normal running, when charger voltage is lower than this value, it will send a charging failure warning.
		Return	(0-60.0)V	10.0	
		Delay	(0-3600)s	60	
Speed Control Setting					
1	Enable Setting		(0-1)	0	0: Disable; 1: Enable
2	Port Select		(0-1)	0	0: Key/Input Port; 1: Throttle Control
3	Local	Enable	(0-1)	0	0: Disable; 1: Enable

No.	Item		Range	Default	Description
	Throttle Control	Setting			
		Sensor Channel	(0-5)	0	0: Flex. Sensor 1 1: Flex. Sensor 2 2: Flex. Sensor 3 3: Flex. Sensor 4 4: Flex. Sensor 5 5: Flex. Sensor 6
		Sensor Type	(0-2)	0	0: Resistance Type 1: Current Type 2: Voltage Type
		Start Value	(0-5000)	50	Different display units for different sensor types.
		Max. Value	(0-5000)	950	
4	Remote Throttle Control	Enable Setting	(0-1)	0	0: Disable; 1: Enable
		Sensor Channel	(0-5)	0	0: Flex. Sensor 1 1: Flex. Sensor 2 2: Flex. Sensor 3 3: Flex. Sensor 4 4: Flex. Sensor 5 5: Flex. Sensor 6
		Sensor Type	(0-2)	0	0: Resistance Type 1: Current Type 2: Voltage Type
		Start Value	(0-5000)	50	Different display units for different sensor types.
		Max. Value	(0-5000)	950	
5	Speed Control Period	(1-1000)	1	During the speed control, the engine speed increases or decreases for a single press of speed up/down key.	
6	Acceleration Rate	(0-2000)r/s	500	The change rate of engine speed up.	
7	Deceleration Rate	(0-2000)r/s	100	The change rate of engine speed down.	
8	Gear RPM	1st Gear	(0-6000)RPM	750	The engine runs at the preset gear-specific speed.
9		2nd Gear	(0-6000)RPM	1200	
10		3rd Gear	(0-6000)RPM	1800	
Sensor Setting					
Aux. Sensor 1~6					
1	Sensor Select	(0-3)	3	0: Not Used; 1: Temp. Sensor; 2: Pressure Sensor; 3: Level Sensor;	
2	Curve Type			Change according to sensor type.	
3	Open Action	(0-1)	1	0: Warning; 1: No Action	

No.	Item	Range	Default	Description	
4	Display Unit	(0-2)	0	0: °C; 1:°F (Temperature Sensor) 0: kPa; 1: bar; 2:psi (Pressure Sensor) 0: %; 1: L (Level Sensor) <b>NOTE:</b> Display unit varies from sensor to sensor.	
5	Alarm Range	Detection (0-2)	0	0: After normal running; 1: Always; 2: Inactive	
6	Over Warn Set	Enable	(0-1)	0	0: Disable; 1: Enable
		Set	(0-9000)	90	When external sensor value exceeds it, warning alarm is issued. Alarm, delay value and return value can be set.
		Return	(0-9000)	80	
		Delay	(0-3600)s	5	
7	Under Warn Set	Enable	(0-1)	0	0: Disable; 1: Enable
		Set	(0-9000)	20	When external sensor value is less than it, warning alarm is issued. Alarm, delay value and return value can be set.
		Return	(0-9000)	30	
		Delay	(0-3600)s	5	
8	Custom Curve Set			Corresponding curves needs to be set when selecting custom resistance /voltage/current type.	
<b>Engine Temperature Setting (ECU)</b>					
1	Data Source	(0-6)	0	0: ECU 1: Flex. Sensor 1 2: Flex. Sensor 2 3: Flex. Sensor 3 4: Flex. Sensor 4 5: Flex. Sensor 5 6: Flex. Sensor 6	
2	Display Unit	(0-1)	0	0: °C; 1: °F	
3	Alarm Range	Detection (0-2)	0	0: After normal running; 1: Always; 2: Inactive	
4	Over Warn Set	Enable	(0-1)	1	0: Disable; 1: Enable
		Set	(0-300)°C	95	When engine temperature exceeds it, warning alarm is issued. Alarm, delay value and return value can be set.
		Return	(0-300)°C	93	
		Delay	(0-3600)s	5	
5	Under Warn Set	Enable	(0-1)	0	0: Disable; 1: Enable
		Set	(0-300)°C	20	When engine temperature is less than it, warning alarm is issued. Alarm, delay value and return value can be set.
		Return	(0-300)°C	30	
		Delay	(0-3600)s	5	
<b>Engine Oil Pressure Setting (ECU)</b>					
1	Data Source	(0-6)	0	0: ECU 1: Flex. Sensor 1 2: Flex. Sensor 2 3: Flex. Sensor 3 4: Flex. Sensor 4 5: Flex. Sensor 5	

No.	Item	Range	Default	Description	
				6: Flex. Sensor 6	
2	Display Unit	(0-2)	0	0: kPa; 1: bar; 2: psi	
3	Alarm Detection Range	(0-2)	0	0: After normal running; 1: Always; 2: Inactive	
4	Over Warn Set	Enable	(0-1)	0	0: Disable; 1: Enable
		Set	(0-9000)kPa	90	When engine oil pressure exceeds it, warning alarm is issued. Alarm, delay value and return value can be set.
		Return	(0-9000)kPa	80	
		Delay	(0-3600)s	5	
5	Under Warn Set	Enable	(0-1)	1	0: Disable; 1: Enable
		Set	(0-9000)kPa	124	When engine oil pressure is less than it, warning alarm is issued. Alarm, delay value and return value can be set.
		Return	(0-9000)kPa	138	
		Delay	(0-3600)s	10	
<b>Fuel Level Correlation</b>					
1	Fuel Level Correlation	(0-6)	0	0: Not Used; 1: Flex. Sensor 1 2: Flex. Sensor 2 3: Flex. Sensor 3 4: Flex. Sensor 4 5: Flex. Sensor 5 6: Flex. Sensor 6	
<b>Aux. Input Port Setting</b>					
1	Aux. Input Port 1	(0-29)	0	0: Not Used. Details refer to Table of Definable Contents of Digital Input Port 1~3.	
2	Active Type	(0-1)	0	0: Close for active; 1: Open for active	
3	Aux. Input Port 2	(0-29)	0	0: Not Used. Details refer to Table of Definable Contents of Digital Input Port 1~3.	
4	Active Type	(0-1)	0	0: Close for active; 1: Open for active	
5	Aux. Input Port 3	(0-29)	0	0: Not Used. Details refer to e Table of Definable Contents of Digital Input Port 1~3.	
6	Active Type	(0-1)	0	0: Close for active; 1: Open for active	
<b>Aux. Output Port Setting</b>					
1	Aux. Output Port 1	(0-39)	0	0: Not Used, details refer to Table of Programmable Output Ports.	
2	Active Type	(0-1)	0	0: Normally open; 1: Normally Close	
3	Aux. Output Port 2	(0-39)	0	0: Not Used, details refer to Table of Programmable Output Ports.	
4	Active Type	(0-1)	0	0: Normally open; 1: Normally Close	
5	Aux. Output Port 3	(0-39)	0	0: Not Used, details refer to Table of Programmable Output Ports.	
6	Active Type	(0-1)	0	0: Normally open; 1: Normally Close	
<b>Maintenance Setting</b>					

No.	Item	Range	Default	Description
1	Maintenance 1 Set	(0-1)	0	After unit maintenance, it can reset time due alarm by resetting maintenance time, details refer to Table of Maintenance Setting.
2	Maintenance 2 Set	(0-1)	0	
3	Maintenance 3 Set	(0-1)	0	
4	Maintenance 4 Set	(0-1)	0	
5	Maintenance 5 Set	(0-1)	0	
6	Maintenance 6 Set	(0-1)	0	
7	Maintenance 7 Set	(0-1)	0	
8	Maintenance 8 Set	(0-1)	0	
9	Maintenance 9 Set	(0-1)	0	
10	Maintenance 10 Set	(0-1)	0	

## 7.1 MAIN SCREEN DISPLAY SETTING

**Table 8 Main Screen Display Setting**

No.	Items	Icon
00	Engine Speed	
01	Engine Water Temp.	
02	Engine Oil Pressure	
03	Fuel Level	
04	Bat. Volt.	
05	Charger Volt.	
06	Total Running Time	
07	Flex. Sensor 1	
08	Flex. Sensor 2	
09	Flex. Sensor 3	
10	Flex. Sensor 4	
11	Flex. Sensor 5	
12	Flex. Sensor 6	
13	Engine Load Rate	
14	Torque Percentage	
15	Urea Level	
16	DPF Carbon Accumulation	
17	DPF Soot Loading Rate	

## 7.2 PROGRAMMABLE OUTPUT PORT ITEMS


**Table 9 Contents of Programmable Output Ports**

No.	Items	Descriptions
00	Not Used	
01	Custom Combined Output 1	Function description see 7.3 <i>Defined Combination Output</i> .
02	Custom Combined Output 2	
03	Custom Combined Output 3	
04	Audible Alarm Output	Act when warning alarms and externally connected with alarm device. If the programmable input port "Alarm Mute" activates or any panel key is pressure, the output is disabled.

No.	Items	Descriptions
		When alarm output resumes upon detection of new warning alarm.
05	Reserved	
06	Running Status Output	Output when engine is in normal running, disconnect when speed is less than the crank disconnect speed.
07	1st Gear Speed Output	Output when input port of "1st Gear Active" is configured and receives an active signal.
08	2nd Gear Speed Output	Output when input port of "2nd Gear Active" is configured and receives an active signal.
09	3rd Gear Speed Output	Output when input port of "3rd Gear Active" is configured and receives an active signal.
10	Input Port 1 Active	Act when input port 1 is active.
11	Input Port 2 Active	Act when input port 2 is active.
12	Input Port 3 Active	Act when input port 3 is active.
13	Common Alarm	Act when common warning occurs.
14	Over Speed Warning	Act when engine over speed warning occurs.
15	Battery Over Volt. Warning	Act when battery over voltage warning occurs.
16	Battery Under Volt. Warning	Act when battery under voltage warning alarms.
17	High Water Temp.	Act when high water temperature warning occurs.
18	Low Oil Pressure	Act when low oil pressure warning occurs.
19	Charge Alt Fail	Act when charging failure warning alarms.
20	Flex. Sensor 1 High Warning	Act when Flex. Sensor 1 high warning occurs.
21	Flex. Sensor 1 Low Warning	Act when Flex. Sensor 1 low warning occurs.
22	Flex. Sensor 2 High Warning	Act when Flex. Sensor 2 high warning occurs.
23	Flex. Sensor 2 Low Warning	Act when Flex. Sensor 2 low warning occurs.
24	Flex. Sensor 3 High Warning	Act when Flex. Sensor 3 high warning occurs.
25	Flex. Sensor 3 Low Warning	Act when Flex. Sensor 3 low warning occurs.
26	Flex. Sensor 4 High Warning	Act when Flex. Sensor 4 high warning occurs.
27	Flex. Sensor 4 Low Warning	Act when Flex. Sensor 4 low warning occurs.
28	Flex. Sensor 5 High Warning	Act when Flex. Sensor 5 high warning occurs.
29	Flex. Sensor 5 Low Warning	Act when Flex. Sensor 5 low warning occurs.
30	Flex. Sensor 6 High Warning	Act when Flex. Sensor 6 high warning occurs.
31	Flex. Sensor 6 Low Warning	Act when Flex. Sensor 6 low warning occurs.
32-39	Reserved	

## 7.3 DEFINED COMINATION OUTPUT

Defined combination output is composed by 3 parts: OR condition output S1, OR condition output S2, AND condition output S3.



S1 or S2 is true, and S3 is true, then combination output works.

S1 and S2 both are false, or S3 is false, then combination output doesn't work.

**▲NOTE:** S1, S2 and S3 can be any contents except itself defined combination output of the output settings.

**▲NOTE:** S1, S2 and S3 cannot include or recursively include itself.

For example:

Contents of OR condition output S1: input port 1 is active;

Close when OR condition output S1 is active/inactive: close when active (disconnect when inactive);

Contents of OR condition output S2, input port 2 is active;

Close when OR condition output S2 is active/inactive: close when active (disconnect when inactive);

Contents of AND condition output S3: input port 3 is active;

Close when AND condition output S3 is active/inactive: close when active (disconnect when inactive);

When input port 1 is active or input port 2 is active, if input port 3 is active, defined combination output is working; if input port 3 is inactive, defined combination output is not working;

When input port 1 is inactive and port 2 is inactive, no matter port 3 is active or not, defined combination output is not working.

## 7.4 DEFINITION CONTENTS OF DIGITAL INPUT PORTS 1~3

**Table 10 Definition Contents of Digital Input Ports 1-3**

No.	Items	Description
0	Not Used	
1	User-defined	Users can customize the following functions: Warning: warning only, no shutdown. Inactive: input is deactivated. Always active: input always detects. Active when normal running: detect begins from normal running.
2	Speed Control Active	When the input is active, the controller is allowed to send speed control command to ECU.
3	Reserved	
4	Speed Raising Input	An external button (non self-locking) can be connected for manual speed control.
5	Speed Dropping Input	
6	Local/Remote Throttle Speed Control	During throttle speed control, when the input is active, speed control operates in remote throttle mode; when the input is inactive, speed control defaults to local throttle mode.
7	1st Gear Active	When the input is active, speed adjustment is performed at the

No.	Items	Description
		first gear speed in the speed settings.
8	2nd Gear Active	When the input is active, speed adjustment is performed at the second gear speed in the speed settings.
9	3rd Gear Active	When the input is active, speed adjustment is performed at the third gear speed in the speed settings.
10	Alarm Mute	When active, it can disable the "Audio Alarm" output configured in the output settings.
11	Local CAN Speed Control Disabled	When input is active, the controller is disabled to send speed control command to ECU
12	DPF Manual Regeneration	When the input is active, the controller sends a manual regeneration request command to ECU.
13	DPF Manual Regeneration Disabled	When the input port is active, the controller sends a regeneration disabled command to ECU.
14-29	Reserved	


**Table 11 Maintenance Setting**

Item	Content	Description
Enable Set	0: Disable; 1: Enable	It is used for enabling current maintenance function.
Maintenance Time	(0-30000)h	Hours from maintenance enabled until maintenance is required.
Time Due Action	0: Warning 1: No Action	Alarm action upon reaching preset maintenance duration.
Pre-alarm Time	(0-30000)h	Hours from maintenance enabled to pre-alarm threshold is reached.
Pre-alarm Time Due Action	0: Warning 1: No Action	Alarm action upon reaching pre-alarm maintenance duration.
First Maintenance Enable Select	0: Disable; 1: Enable	Set activation status of the first maintenance service function.
First Maintenance Time	(0-30000)h	Hours from first maintenance enabled until maintenance is required.
First Maintenance Time Due Action	0: Warning 1: No Action	Alarm action upon reaching preset first maintenance duration.
Reset Maintenance Time	0: Disable; 1: Enable	After maintenance, reset the maintenance time via it.

## 7.5 EVENT LOG

Enter “Event Log” via menu, up to 200 items can be recorded. Press ,  can scroll page to view the log, press  can return to previous menu, press  to return to home page.

**Table 12 Event Log Screen**

	<p>First line: display current event log No. and total logs;                  Second line: this log type is “Warning Alarm”;                  Third line: specific name of the event;                  Fourth line: time stamp, it records engine’s total running time.</p>
	<p>First line: display current event log no. and total logs;                  Second line: this log type is “ECU Warning Alarm”;                  Third line: specific name of the event;                  Fourth line: time stamp, it records engine’s total running time.                  Fifth line: SPN value and FMI value in the alarm occurrence.</p>

## 8 SPEED CONTROL

### 8.1 KEY/INPUT PORT SPEED CONTROL

When speed control is enabled, select speed control type 0: Key/Input Port.

Press  on main screen to enter the speed control screen. Press  or activate “Speed Raising Input”, the engine speed will rise by the configured value (default: 1RPM). Press  or activate “Speed Dropping Input”, the engine speed will drop by the configured value (default:1RPM). Press  to exit the speed control mode and return to home page.


### 8.2 THROTTLE SPEED CONTROL

When speed control is enabled, select speed control type 1: Throttle Control. The controller supports both local and remote throttle speed control. The active throttle type can be switched via the “Local/Remote Throttle” input port.

- Local throttle setting:
- Speed control enable: 1: Enable
- Sensor Channel: Flex. Sensor 3
- Sensor Type: 0: Resistance
- Start Value: 50Ω
- Max. Value: 950Ω
- Engine Idle Speed: 800RPM
- Rated Speed: 2000 RPM

During operation, connect the potentiometer to the input port of Flex. Sensor 3, and connect the other terminal to the sensor common. The min. resistance value corresponds to engine idle speed (800RPM); the max. resistance corresponds to the rated speed (2000 RPM). Adjust the potentiometer’s resistance will proportionally change the engine RPM. See the following figure for specific scaling

relationship. The same principle applies to voltage-type and current-type sensors.



**Fig.9 Resistance and Speed Relationship**

**NOTE:** Once any sensor channel is configured as a throttle control input and the corresponding throttle mode is activated, its programmable sensor function will be disabled.

**8.3 PRIORITY DESCRIPTION FOR GEAR INPUT PORT**

**Table 13 Description of Gear Input Port Priority**

1st Gear Active	2nd Gear Active	3rd Gear Active	Real Active Gear RPM
0	0	0	None
1	0 or 1	0 or 1	1
0	1	0 or 1	2
0	0	1	3

**NOTE:** The priority of gear input port is higher than the throttle speed control and key/input port speed control.

**9 LOCAL REMOTE MODE**

Connect the two controllers via the 485 interface. Set one to local mode and the other to remote mode. Once communication is successfully connected, the remote mode controller will read data from the local mode controller.

**10 CUSTOM SPN FAULT CODES**

Users can configure custom alarm names for SPN fault codes into the controller via PC. A total of 50 custom SPN fault codes are supported, with Chinese/English display.

The image shows a grid of 10 input forms, labeled SPN 1 through SPN 10. Each form contains three input fields: 'SPN' (with a default value of 0), 'Chinese' (with a placeholder '输入SPN名称'), and 'Other' (with a placeholder 'Enter the spn name').

Fig.10 SPN Code Page of PC Software

### 11 SENSOR CURVE SETTING

- When external sensor is required, sensor type needs to be set, default sensor to “Not Used”.
- When there is difference between standard sensor curves and used sensor curves, users can select “Custom Sensor”, and input sensor curve.
- When the sensor curve is inputted, x value must be inputted from small to large, otherwise, mistake occurs.
- If sensor type is selected as “Not Used”, sensor curve is not working.
- The headmost or backmost values in the vertical coordinates can be set as the same as below.




Fig.11 Curve Setting

Table 14 Sensor Selection

No.	Sensor	Curve Type	Remark
1	Temperature Sensor	0 Not Used 1 Custom Resist. Curve 2 Custom (4-20)mA Curve 3 Custom Volt Curve 4 VDO 5 CURTIS 6 VOLVO-EC 7 DATCON 8 SGX 9 SGD 10 SGH 11 PT100 12 PT1000 13 Cu50 14 -15 Reserved	Custom resistance type input range is (0~1)kΩ.
2	Pressure Sensor	0 Not Used 1 Custom Resist. Curve 2 Custom (4-20)mA Curve 3 Custom Volt Curve 4 VDO 10bar 5 CURTIS 6 VOLVO-EC 7 DATCON 10bar 8 SGX 9 SGD 10 SGH 11-15 Reserved	Custom resistance type input range is (0~1)kΩ.
3	Level Sensor	0 Not Used 1 Custom Resist. Curve 2 Custom (4-20)mA Curve 3 Custom Volt Curve 4 Reserved 5 Reserved 6 4-126Ω 7 0-190Ω 8 190-0Ω 9 240-33Ω 10 33-240Ω 11-15 Reserved	Custom resistance type input range is (0~1)kΩ.

## 12 ALARMS

When controller detects alarm signal, it displays the alarm content. When alarm is removed, alarm is cleared automatically.

**Table 15 Warning Alarms**

No.	Warning	Description
1	Over Speed	When controller detects engine speed
2	DPF Regeneration	When controller receives DPF regeneration warning signal of engine via J1939, it issues warning signal.
3	NCD Error	When controller receives NCD error warning signal via J1939, it issues warning signal.
4	Charge Alt Failure	Act when charging failure warning alarms.
5	Battery Overvoltage	When controller detects engine battery voltage is higher than pre-set threshold, it issues warning alarm signal.
6	Battery Undervoltage	When controller detects engine battery voltage is lower than pre-set threshold, it issues warning alarm signal.
7	ECU Warning	When controller receives warning signal of engine via J1939, it issues warning signal.
8	Sensor 1~6 Open	When controller detects sensor is open and action type is "Warning", it issues warning signal.
9	Sensor 1~6 High	When controller detects sensor value is above pre-set upper limit of warning values, it issues warning signal.
10	Sensor 1~6 Low	When controller detects sensor value is below pre-set lower limit of warning values, it issues warning signal.
11	Sensor 3~6 Error	When sensor parameter configuration is wrong, it issues warning signal.
12	Coolant Temperature (ECU) High	When controller detects coolant temperature is higher than pre-set high warning value, it issues warning signal.
13	Coolant Temperature (ECU) Low	When controller detects temperature is lower than pre-set low warning value, it issues warning signal.
14	Oil Pressure (ECU) High	When controller detects oil pressure value is above pre-set high warning value, it issues warning signal.
15	Oil Pressure (ECU) Low	When engine is running, controller detects oil pressure value is below pre-set low warning value, it issues warning signal.
16	Maintenance 1~10	When maintenance countdown is 0, and time due action is "Warning", it issues warning signal.
17	Input Port 1~3	When digital input port is configured as "Warning" and it is active, controller issues a corresponding warning signal.

13 WIRE CONNECTION

The back panel of HED400 is below:



Fig.12 Controller Back Panel

Table 16 Connection Terminal Description

No.	Function	Cable Size	Remark
1	Flex. Sensor 1	0.5mm <sup>2</sup>	Connect with temperature, pressure or level sensor. Setting items see <i>Table of Sensor Selection</i> . Only resistance sensor is available.
2	Flex. Sensor 2		
3	Speed Sensor Input MP1	0.5mm <sup>2</sup>	Speed Sensor Input
4	Speed Sensor Input MP2		Speed sensor input, controller inside has been connected to negative post of battery.
5	Charger D+ Input	1.0mm <sup>2</sup>	Connect with charger D+ (WL) terminal. If this terminal doesn't exist, hang it in the air.
6	Flex. Sensor 3	0.5mm <sup>2</sup>	Connect with temperature, pressure or level sensor. Setting items see <i>Table of Sensor Selection</i> . Voltage sensor, current sensor and resistance sensor are available.
7	ECU CAN H	0.5mm <sup>2</sup>	Impedance-120Ω shielding wire is recommended, and the single-end shall be earth connected. The "Matched Resistance Enable" is configured to determine if a 120Ω matched resistance should be connected to CANBUS automatically.
8	ECU CAN L	0.5mm <sup>2</sup>	
9	Flex. Sensor 4	0.5mm <sup>2</sup>	Connect with temperature, pressure or level sensor. Setting items see <i>Table of Sensor Selection</i> . Voltage sensor, current sensor and resistance sensor are

No.	Function	Cable Size	Remark
			available.
10	VOUT (+5V)	0.5mm <sup>2</sup>	Output DC+5V, Max. current is 30mA.
11	Flex. Sensor 5	0.5mm <sup>2</sup>	Connect with temperature, pressure or level sensor. Setting items see <i>Table of Sensor Selection</i> . Voltage sensor, current sensor and resistance sensor are available.
12	Flex. Sensor 6		Connect with temperature, pressure or level sensor. Setting items see <i>Table of Sensor Selection</i> . Voltage sensor, current sensor and resistance sensor are available.
13	GND	1.0mm <sup>2</sup>	Sensor Common.
14	RS485 B(-)	0.5mm <sup>2</sup>	Impedance-120Ω shielding wire is recommended, and the single-end shall be earth connected. No external 120Ω resistance is required, the "Matched Resistance Enable" is configured to determine if an internal resistance should be used automatically.
15	RS485 A(+)	0.5mm <sup>2</sup>	
16	AUX. Input 1	0.5mm <sup>2</sup>	Ground connected is active (B-).
17	AUX. Input 2	0.5mm <sup>2</sup>	Ground connected is active (B-).
18	AUX. Input 3	0.5mm <sup>2</sup>	Ground connected is active (B-).
19	AUX. Output 1	1.0mm <sup>2</sup>	B+ is supplied by 22 points, rated 5A.
20	AUX. Output 2	1.0mm <sup>2</sup>	B+ is supplied by 22 points, rated 5A.
21	AUX. Output 3	1.0mm <sup>2</sup>	B+ is supplied by 22 points, rated 5A.
22	DC Power B+	1.5mm <sup>2</sup>	Connect with positive post of starting battery.
23	GND	1.5mm <sup>2</sup>	Connect with negative post of starting battery.

**NOTE1:** The USB interface on back panel is a parameter programming interface, and you can use a PC to program the controller.

14 TYPICAL APPLICATION





Fig.13 HED400 Typical Application Diagram

SmartGen

## 15 INSTALLATION

### 15.1 FIXING CLIPS

Unit: mm



**Fig.14 HED400 Fixing Clips Installation**

- This controller is panel built-in design and is fixed by pressure frame when installation;
- Remove the pressure from the controller;
- Remove the four M4 bolts and place them in the corresponding slots of the front shell;
- Place the controller in the opening position of the control cabinet, place the pressure frame behind the controller by aligning the four bolts;
- Install and tighten the flat washers, spring washers and hexagonal nuts respectively.

15.2 OVERALL DIMENSIONS AND PANEL CUTOUT




Fig.15 Overall Dimensions and Panel Cutout

SmartGen

16 CONNECTIONS OF CONTROLLER WITH J1939 ENGINE

16.1 CUMMINS ISB/ISBE

Table 17 9-pin Connector

Terminals of controller	9 pins connector	Remark
CAN(H)	SAE J1939 signal-C	Using impedance 120Ω connecting line.
CAN(L)	SAE J1939 return-D	Using impedance 120Ω connecting line.

16.2 VOLVO

Suitable engine type is TD520, TAD520(optional), TD720, TAD720(optional), TAD721, TAD722, TAD732.

Table 18 Connector

Terminals of controller	Connector	Remark
-	1	Connected to negative of battery.
CAN(H)	12	Using impedance 120Ω connecting line.
CAN(L)	13	Using impedance 120Ω connecting line.

16.3 YUCHAI

Suitable for Yuchai electronic-controlled engine.

Table 19 Engine 42-pin Port

Terminals of controller	Engine 42 pins port	Remark
CAN_SCR	-	CAN communication shielding line.
CAN(H)	1.35	Using impedance 120Ω connecting line.
CAN(L)	1.34	Using impedance 120Ω connecting line.

Table 20 Engine 2-pin Port

Battery	Engine 2 pins port	Remark
Battery negative	1	Wire diameter 2.5mm <sup>2</sup> .
Battery positive	2	Wire diameter 2.5mm <sup>2</sup> .

## 16.4 WEICHAI

Suitable for Weichai electronic-controlled engine.

**Table 21 Engine Port**

Terminals of controller	Engine port	Remark
CAN_SCR	-	CAN communication shielding line.
CAN(H)	1.35	Using impedance 120Ω connecting line.
CAN(L)	1.34	Using impedance 120Ω connecting line.

**NOTE:** If there is any question of connection between controller and ECU communication, please feel free to contact SmartGen's service.

SmartGen

17 TROUBLE SHOOTING

Table 22 Troubleshooting

Symptoms	Possible Solutions
Controller no response with power	Check starting battery; Check controller wirings; Check DC fuse.
Oil pressure low alarm after crank disconnection	Check oil pressure sensor and its wirings.
Water temp. high alarm after crank disconnection	Check water temperature sensor and its wirings.
Alarm in running	Check related switch and wirings according to LCD display information.
RS485 communication abnormal	Check wirings; Check COM port settings are correct or not; Check RS485 A and B line are connected reversely or not; Check PC communication port is damaged or not; Recommend to enable 120Ω resistor between A and B of RS485.
Control displays ECU alarm	Troubleshoot by translating the SPN fault code according the alarm display; Refer to the fault manual; Consult the engine manufacturer.
ECU comm. Failure or incorrect data	Check its wirings; Check if CAN BUS H and L are connected reversely or not; Check if ECU is damaged or not; Check if the correct engine type is selected; Check if 120Ω resistor between CAN BUS H and L is enabled;
Low backlight brightness	Check battery voltage; Check backlight brightness setting.