

# SmartGen

MAKING CONTROL SMARTER

## HGM8100N SERIES

(HGM8110V\_8120V\_8110LT\_8120LT\_8110CAN\_8120CAN)

### GENSET CONTROLLER

### USER MANUAL



郑州众智科技股份有限公司  
SMARTGEN(ZHENGZHOU)TECHNOLOGY CO.,LTD.

No.28 Xuemei Street, Zhengzhou, Henan, China

Tel: +86-371-67988888/67981888/67992951

+86-371-67981000(overseas)

Fax: +86-371-67992952

Email: [sales@smartgen.cn](mailto:sales@smartgen.cn)

Web: [www.smartgen.com.cn](http://www.smartgen.com.cn)  
[www.smartgen.cn](http://www.smartgen.cn)

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

SmartGen reserves the right to change the contents of this document without prior notice.

**Table 1 Software Version**

Date	Version	Note
2016-07-24	1.0	Original release.
2021-04-07	1.1	Modify the error in key function and other translation problems.
2021-06-20	1.2	Add output port function: preheat output and key output; Add Input port function: speed raise/drop input and battle mode; Add speed regulation rate setting and charging voltage selection; Add new model HGM8110LT and HGM8120LT.
2021-08-10	1.3	Add AIN8 Expansion Module function; Add torque instructions for fixing clips.
2022-06-16	1.4	Update manual format and company logo.
2025-07-13	1.5	Modify the figures of controller back panel, overall dimensions and panel cutout; Update the logo of SmartGen in the header and add a horizontal line to the header; Update the company address in the foreword; Add parameters such as mains voltage transformer primary/secondary voltage, mains shutdown ATS enable, smart preheat, idle speed, ECU communication address, generator over/under voltage trip, and generator over/under frequency trip to the parameter settings contents and ranges; Update the table of definable contents of programmable input ports.

This manual is suitable for HGM8110V, HGM8120V, HGM8110LT, HGM8120LT, HGM8110CAN, HGM8120CAN controllers only.

**Table 2 Notation Clarification**

Sign	Instruction
 NOTE	Highlights an essential element of a procedure to ensure correctness.
 CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
 WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

SmartGen

# CONTENTS

1	OVERVIEW.....	6
2	MODELS COMPARISON.....	7
3	PERFORMANCE AND CHARACTERISTICS.....	8
4	SPECIFICATION.....	11
5	OPERATION.....	12
5.1	INDICATORS.....	12
5.2	KEY FUNCTION DESCRIPTION.....	12
5.3	LCD DISPLAY.....	14
5.3.1	MAIN DISPLAY.....	14
5.3.2	PARAMETERS SETTING MANUAL.....	16
5.3.3	PARAMETER SETTINGS.....	16
5.4	AUTO START/STOP OPERATION.....	17
5.5	MANUAL START/STOP OPERATION.....	18
5.6	GENSET CONTROLLER ATS CONTROL PROCEDURES.....	19
5.6.1	HGM8120N ATS CONTROL PROCEDURES.....	19
5.6.1.1	MANUAL TRANSFER PROCEDURES.....	19
5.6.1.2	AUTO TRANSFER PROCEDURES.....	19
5.6.2	HGM8110N ATS CONTROL PROCEDURES.....	20
5.6.2.1	MANUAL CONTROL PROCEDURES.....	20
5.6.2.2	AUTO CONTROL PROCEDURES.....	20
6	PROTECTION.....	21
6.1	WARNINGS.....	21
6.2	SHUTDOWN ALARM.....	23
6.3	TRIP AND STOP ALARM.....	24
6.4	TRIP ALARM.....	25
7	WIRINGS CONNECTION.....	26
8	SCOPES AND DEFINITIONS OF PROGRAMMABLE PARAMETERS.....	29
8.1	CONTENTS AND SCOPES OF PARAMETERS.....	29
8.2	ENABLE DEFINITION OF DIGITAL OUTPUT PORTS.....	39
8.2.1	DEFINED CONTENTS OF DIGITAL OUTPUT PORTS.....	39
8.2.2	CUSTOM PERIOD OUTPUT.....	43
8.2.3	CUSTOM COMBINED OUTPUT.....	43
8.3	DEFINED CONTENTS OF DIGITAL INPUT PORTS (ALL GND(B-) CONNECTED ACTIVE).....	44
8.4	SELECTION OF SENSORS.....	47
8.5	CONDITIONS OF CRANK DISCONNECT SELECTION.....	48
9	PARAMETERS SETTING.....	49
10	SENSORS SETTING.....	50
11	COMMISSIONING.....	51
12	TYPICAL APPLICATION.....	52
13	INSTALLATION.....	54
13.1	OVERALL DIMENSION.....	54

---

13.2	BATTERY VOLTAGE INPUT .....	54
13.3	SPEED SENSOR INPUT .....	54
13.4	OUTPUT AND EXPAND RELAYS .....	54
13.5	AC INPUT.....	55
13.6	WITHSTAND VOLTAGE TEST .....	55
14	GSM SHORT MESSAGE ALARM AND REMOTE CONTROL .....	56
14.1	GSM SHORT MESSAGE ALARM .....	56
14.2	GSM SHORT MESSAGE REMOTE CONTROL .....	56
15	CONNECTIONS OF CONTROLLER WITH ENGINE J1939 .....	58
15.1	CUMMINS ISB/ISBE.....	58
15.2	CUMMINS QSL9.....	58
15.3	CUMMINS QSM11 (IMPORT).....	59
15.4	CUMMINS QSX15-CM570 .....	59
15.5	CUMMINS GCS-MODBUS.....	60
15.6	CUMMINS QSM11 .....	60
15.7	CUMMINS QSZ13 .....	61
15.8	DETROIT DIESEL DDEC III/IV .....	61
15.9	DEUTZ EMR2.....	62
15.10	JOHN DEERE.....	62
15.11	MTU MDEC.....	62
15.12	MTU ADEC (SMART MODULE) .....	63
15.13	MTU ADEC (SAM MODULE).....	63
15.14	PERKINS.....	64
15.15	SCANIA.....	64
15.16	VOLVO EDC3.....	64
15.17	VOLVO EDC4.....	65
15.18	VOLVO-EMS2.....	65
15.19	YUCHAI .....	66
15.20	WEICHAI.....	66
16	ETHERNET INTERFACE .....	67
16.1	ETHERNET INTERFACE INTRODUCTION .....	67
16.2	NETWORK CLIENT CONNECTION MODE.....	67
16.3	CONTROLLER AND NETWORK CABLE CONNECTION .....	67
17	FAULT FINDING.....	68

## 1 OVERVIEW

HGM8100N series genset controllers are especially designed for extremely high/low temperature environment (-40~+70)°C. The controllers can operate reliably in extreme temperature conditions with the help of VFD display or LCD and the components that resist extreme temperature. Controller has strong ability of anti-electromagnetic interference, can be used under complex electromagnetic interference environment. It is easy to maintain and upgrade due to the plug-in terminal. All display information is Chinese (also can be set as English or other languages).

HGM8100N series genset controllers integrate digitization, intelligentization and network technology which are used for genset automation and monitor control system of single unit to achieve automatic start/stop, data measurement, alarm protection and “three remote” functions (remote control, remote measuring and remote communication).

HGM8100N series genset controllers adopt 32-bit micro-processor technology with precision parameters measuring, fixed value adjustment, time setting and threshold setting and etc. Major parameters can be configured from front panel, and all parameters can be configured by PC via RS485 interface or ETHERNET to adjust and monitor. It can be widely used in all types of automatic genset control system with compact structure, advanced circuits, simple connections and high reliability.

**2 MODELS COMPARISON**

HGM8100N series controllers include HGM8110V, HGM8120V, HGM8110LT, HGM8120LT, HGM8110CAN and HGM8120CAN.

**HGM8110N** been collectively named of HGM8110V, HGM8110LT and HGM8110CAN.

**HGM8120N** been collectively named of HGM8120V, HGM8120LT and HGM8120CAN.

**Table 3 Models Comparison**

Item	HGM8110V	HGM8120V	HGM8110CAN	HGM8120CAN	HGM8110LT	HGM8120LT
Display	VFD			LCD (heated)		
Mains Monitoring		•		•		•
Input Number	8	8	8	8	8	8
Output Number	8	8	8	8	8	8
Sensor Number	5	5	5	5	5	5
Earth Current	•	•	•	•	•	•
Schedule Function	•	•	•	•	•	•
RS485	•	•	•	•	•	•
ETHERNET			•	•		
GSM	•	•	•	•	•	•
J1939			•	•	•	•
USB	•	•	•	•	•	•
Real-time Clock	•	•	•	•	•	•
Event Log	•	•	•	•	•	•
Input/Output Expansion Module			•	•	•	•
AIN24 Analog Expansion Module			•	•	•	•
AIN8 Analog Expansion Module			•	•	•	•

**▲NOTE:**

- 1) Two fixed output ports: start output and fuel output.
- 2) Analog sensor consists of three fixed sensors (temperature sensor, pressure sensor and fuel level sensor) and two flexible sensors.

**3 PERFORMANCE AND CHARACTERISTICS**

**HGM8110N:** used for single automation systems, can control genset start/stop through remote start signals.

**HGM8120N:** AMF (Auto Mains Failure), updates based on HGM8110N, moreover, has mains electricity monitoring and mains/generator automatic transfer function, especially for automatic system composed by generator and mains.

**Main characteristics are as below:**

- 1) With ARM-based 32-bit SCM, highly integrated hardware, high reliability;
- 2) Vacuum fluorescent display (VFD) or LCD display (able to control heating according to the environment temperature), selectable Chinese/English interface which can be chosen at the site, making commissioning convenience for factory personnel;
- 3) LCD adopts hard screen acrylic material with good wear-resisting and scratch-resisting;
- 4) Silicone panel and pushbuttons can be used in extreme temperature environment;
- 5) RS485 communication interface enables “three remote” (remote control, remote measuring and remote communication) according to MODBUS protocol;
- 6) Ethernet monitoring can be realized via ETHERNET communication interface (need controller with Ethernet interface);
- 7) Equipped with SMS (Short Message Service) function. When genset has alarm, controller can send short messages via SMS automatically to max. 5 telephone numbers. Besides, generator status can be controlled and checked using SMS;
- 8) Equipped with CANBUS port and can communicate with J1939 genset. Not only can monitor frequently-used data (such as water temperature, oil pressure, speed, fuel consumption and so on) of ECU machine, but also control starting up, shutdown, raising speed and speed droop via CANBUS port (need controller with CANBUS interface);
- 9) Suitable for 3-phase 4-wire, 3-phase 3-wire, single phase 2-wire, and 2-phase 3-wire systems with voltage 120/240V and frequency 50/60Hz;
- 10) Collects and shows 3-phase voltage, current, power parameter and frequency of generator or mains;

**Mains**

Line voltage (Uab, Ubc, and Uca)  
 Phase voltage (Ua, Ub, and Uc)  
 Phase sequence  
 Frequency Hz

**Generator**

Line voltage (Uab, Ubc, and Uca)  
 Phase voltage (Ua, Ub, and Uc)  
 Phase sequence  
 Frequency Hz

**Load**

Current	Ia, Ib, Ic	A (unit)
Each phase and total active power	P	kW (unit)
Each phase and total reactive power	Q	Kvar (unit)
Each phase and total apparent power	S	kVA (unit)
Each phase and average power factor	$\lambda$	1 (unit)

- 
- Accumulate total generator power W kWh, kVarh, kVAh (unit)
  - Earth current I A (unit)
  - 11) For Mains, controller has over and under voltage, over and under frequency, loss of phase and reverse phase sequence detection functions; for generator, controller has over and under voltage, over and under frequency, loss of phase, reverse phase sequence, over and reverse power functions;
  - 12) 3 fixed analog sensors (temperature, oil pressure and liquid level);
  - 13) 2 configurable analog sensors can be set as sensor of temperature, oil pressure or fuel level;
  - 14) Precisely measure and display parameters about Engine;
    - Temp. (WT) °C/°F both be displayed
    - Oil pressure (OP) kPa/Psi/Bar all be displayed
    - Fuel level (FL) % (unit)
    - Speed (SPD) r/min (unit)
    - Voltage of Battery (VB) V (unit)
    - Voltage of Charger (VD) V (unit)
    - Hour count (HC) can accumulate to max. 65535 hours.
    - Start times can accumulate to max. 65535 times.
  - 15) Control and protection functions: automatic start/stop of the genset, ATS (Auto Transfer Switch) control with perfect fault indication and protection function;
  - 16) All output ports are relay-out;
  - 17) Parameter setting: parameters can be modified and stored in internal FLASH memory and cannot be lost even in case of power outage; most of them can be adjusted using front panel of the controller and all of them can be modified using PC via USB, RS485 or ETHERNET ports;
  - 18) More kinds of curves of temperature, oil pressure, fuel level can be used directly and users can define the sensor curves by themselves;
  - 19) Multiple crank disconnect conditions (speed sensor, oil pressure, generator frequency) are optional;
  - 20) Widely power supply range DC(8~35)V, suitable to different starting battery voltage environment;
  - 21) Event log, real-time clock, scheduled start & stop generator (can be set as start genset once a day/week/month whether with load or not);
  - 22) PLC (Programmable Logic Controller) function. Users can use graphical programming to achieve specific functions;
  - 23) Can be used on pumping units or as an indicating instrument (indicate and alarm are enabled only, relay is inhibited);
  - 24) With maintenance function. Actions (warning, shutdown or trip and stop) can be set when maintenance time out;
  - 25) All parameters used digital adjustment, instead of conventional analog modulation with normal potentiometer, with high reliability and stability;
  - 26) Waterproof security level IP55 due to rubber seal installed between the controller enclosure and

panel fascia;

27) Metal fixing clips enable perfect performance in high temperature environment;

28) Modular design, anti-flaming ABS plastic enclosure, pluggable connection terminals and embedded installation way; compact structure with easy mounting;

29) With accumulative running A, B and accumulative power A, B function, users can eliminate log event and re-accumulating, thus provide convenient for users' statistic.

SmartGen

4 SPECIFICATION

Table 4 Technical Parameters

Item	Contents
Operating Voltage	DC8.0V to DC35.0V, Continuous Power Supply.
Power Consumption	<4W (standby ≤2W)
Alternator Input Range	
3Phase 4Wire	AC15V ~ AC 360V (ph-N)
3Phase 3Wire	AC30V ~ AC620V (ph-ph)
Single Phase 2Wire	AC15V ~ AC360V (ph-N)
2Phase 3Wire	AC15V ~ AC360V (ph-N)
Alternator Frequency	50Hz/60Hz
Speed Sensor Voltage	1.0V to 24.0V (RMS)
Speed Sensor Frequency	10,000 Hz (max.)
Start Relay Output	16A DC28V at supply output
Fuel Relay Output	16A DC28V at supply output
Programmable Relay Output (1)	7A DC28V at supply output
Programmable Relay Output (2)	7A DC28V at supply output
Programmable Relay Output (3)	7A DC28V at supply output
Programmable Relay Output (4)	7A AC250V voltage free output
Programmable Relay Output (5)	8A AC250V voltage free output
Programmable Relay Output (6)	8A AC250V voltage free output
Case Dimension	242mm x 186mm x 53mm
Panel Cutout	214mm x 160mm
CT Secondary Current	5A rated
Working Temperature	(-40~+70)°C
Working Humidity	(20~93)%RH
LCD Display	When the temperature is -40°C, the controller can normally display within 25 seconds after power-on, and dynamically display that the response speed is normal after 2 minutes.
Storage Temperature	(-40~+70)°C
Protection Level	IP55 Gasket
Insulating Intensity	Apply AC2.2kV voltage between high voltage terminal and low voltage terminal; The leakage current is not more than 3mA within 1min.
Weight	0.85kg

5 OPERATION

5.1 INDICATORS

Table 5 Alarm Indicators

Alarm Type	Alarm Indicator
No Alarm	Indicator off
Warning	Slow flashing (1 time/s)
Trip Alarm	Slow flashing (1 time/s)
Shutdown Alarm	Fast flashing (5 times/s)
Trip and Stop Alarm	Fast flashing (5 times/s)

**Status Indicator:** illuminated from crank disconnect to ETS while off during other periods.

**Gens Normal Indicator:** It is light on when generator is normal; flashing when generator state is abnormal; off when there is no generator power.

**Mains Normal Indicator:** It is light on when mains is normal; flashing when mains state is abnormal; off when there is no mains power.

5.2 KEY FUNCTION DESCRIPTION

Table 6 Key Function Descriptions

Icon	Key	Description
	Stop	Stop running generator in Auto/Manual mode; Lamp test (press at least 3 seconds); Reset alarm in stop mode; During stopping process, press this button again to stop generator immediately.
	Start	Start genset in Manual mode.
	Manual Mode	Press this key and controller enters in <b>Manual</b> mode.
	Auto Mode	Press this key and controller enters in <b>Auto</b> mode.
	Mute/Reset Alarm	Alarming sound off; If there is trip alarm, pressing the button at least 3 seconds can reset this alarm.
	Gen Close/Open	Can control generator to switch on or off in manual mode. (HGM8110N without)
	Mains Close/Open	Can control mains to switch on or off in manual mode. (HGM8110N without)
	Close	Can close breaker in manual mode (HGM8120N without)

Icon	Key	Description
	Open	Can open breaker in manual mode (HGM8120N without)
	Set	Enter setting interface
	Up/Increase	1) Screen scroll; 2) Up cursor and increase value in setting menu.
	Down/Decrease	1) Screen scroll; 2) Down cursor and decrease value in setting menu.
	Left	1) Page scroll; 2) Left move cursor in setting menu.
	Right	1) Page scroll; 2) Right move cursor in setting menu.
	Confirm	In settings menu confirms the set value.
	Exit	1. Returns to the previous screen; 2. In settings menu returns to the upper level menu.

**NOTE:** In manual mode, pressing  and  simultaneously will force generator to crank. Successful start will not be judged according to crank disconnect conditions, operator will have to crank the starter motor manually; when operator decides that the engine has fired, he/she should release the button and start output will be deactivated, safety on delay will start.

**CAUTION:** Default password is "00318", user can change it in case of others change the advanced parameters setting. Please clearly remember the password after changing. If you forget it, please contact SmartGen services and send PD information in the controller page of "ABOUT" to us.

## 5.3 LCD DISPLAY

### 5.3.1 MAIN DISPLAY

Main screen show pages; use   to scroll the pages and   to scroll the screen.

★**Main Screen**, including as below,

Partial status display;

Gen: voltage, frequency;

Load: current, active power, reactive power, power factor;

Mains: voltage, frequency;

Engine: speed, temperature, oil pressure.

▲**NOTE:** HGM8110N has no mains correlative values; it will circularly scroll pages if no action after enter the main interface.

★**Status**, including as below,

Status of genset, mains, and ATS.

▲**NOTE:** HGM8110N has no mains status screen.

★**Engine**, including as below,

Speed, temperature of engine, engine oil pressure, fuel level, flexible sensor 1, flexible sensor 2, battery voltage, charger voltage, accumulated run time, accumulated start times, user A and user B accumulated start times.

▲**NOTE:** If connected with J1939 engine via CANBUS port, this page also includes: coolant pressure, coolant level, fuel temperature, fuel pressure, inlet temperature, exhaust temperature, turbo pressure, total fuel consumption and so on. (Different engine with different parameters)


★**Gen**, including as below,

Phase voltage, Line voltage, frequency, phase sequence.

★**Load**, including as below,

Each phase current, each phase and total active power (positive and negative), each phase and total reactive power (positive and negative), each phase and total apparent power, each phase and average power factor (positive and negative), accumulated energy, earth current and user A and user B accumulated energy.

▲**NOTE:** Power factor shows as following,



Remark:

P stands for active power

Q stands for reactive power

**Table 7 Power Factor Descriptions**

Power Factor	Conditions	Active Power	Reactive Power	Remark
COS>0L	P>0,Q>0	Input	Input	Load is inductive resistance.
COS>0C	P>0,Q<0	Input	Output	Load is capacitance resistance.
COS<0L	P<0,Q>0	Output	Input	Load equal to one under excitation generator.
COS<0C	P<0,Q<0	Output	Output	Load equal to one over excitation generator.

**Remark:**

1. Input active power, generator or mains supplies electricity to load.
2. Output active power, load supplies electricity to generator or mains.
3. Input reactive power, generator or mains sends reactive power to load.
4. Output reactive power, load sends reactive power to generator or mains.

★**Mains**, including as below,

Phase voltage, Line voltage, frequency, phase sequence.

▲**NOTE:** HGM8100N without mains page.

★**Alarm:**

Display all alarm information, including warning, alarm shutdown, trip shutdown and trip without shutdown.

▲**NOTE:** For ECU alarms and shutdown alarms, if the alarm information is displayed, check engine according to it, otherwise, please check the engine manual according to SPN alarm code.

★**Event log**

Records all start/stop events (shutdown alarm, trip and shutdown alarm, manual/auto start or stop) and the real time when alarm occurs.

★**Others**, including,

Time and date, countdown time for maintenance, input/output ports status, NET status etc.

★**About**, including,

Software and hardware version and PD number of controller.

## 5.3.2 PARAMETERS SETTING MANUAL

Press  to enter user menu;

**Parameter:** After entering the correct password (factory default password is 00318) you can enter parameter settings screen.

**Language:** Selectable Simplified Chinese, English and others (default: Espanol).

**Commissioning:** On load, off load and custom commissioning are optional. Custom commissioning can configure on load or not during commissioning, when to commissioning and select the mode after commissioning (manual mode, auto mode and stop mode).

**Clear users' accumulation:** Can clear total run time A and B, total electric energy A and B.

## 5.3.3 PARAMETER SETTINGS

- Mains setting
- Timer setting
- Engine setting
- Generator setting
- Load setting
- Switch setting
- Temperature sensor setting
- Oil pressure sensor setting
- Level sensor setting
- Flexible sensor1
- Flexible sensor2
- Digital input setting
- Output port setting
- Module setting
- Scheduling and maintenance setting
- GSM setting
- Expansion module setting

**NOTE:** Pressing  can exit setting directly during setting.

## 5.4 AUTO START/STOP OPERATION

Press , its indicator lights, and controller enters **Auto** mode.

### Starting Sequence,

- 1) **HGM8120N:** When mains is abnormal (over and under voltage, over and under frequency, loss of phase, reverse phase sequence), it enters into mains “abnormal delay” and LCD display countdown time. When mains abnormal delay is over, it enters into “start delay”; it also enters into this mode when “remote start (on load)” is active.
- 2) **HGM8110N:** Generator enters into “start delay” as soon as “remote start (on load)” is active.
- 3) Start Delay timer is shown on LCD.
- 4) When start delay is over, preheat relay outputs (if configured), “preheat start delay XX s” is shown on LCD.
- 5) When preheat delay is over, fuel relay outputs 1s and then start relay output; if engine crank fails during “cranking time”, the fuel relay and start relay deactivated and enter into “crank rest time” to wait for next crank.
- 6) If engine crank fails within setting times, the controller sends Fail to Start signals and Fail to Start message appears on LCD alarm page.
- 7) In case of successful crank attempt, “safety on timer” starts. During this period, low oil pressure, high water temperature, under speed, charge failure alarms are disabled. As soon as this delay is over, “start idle delay” is initiated (if configured).
- 8) During “start idle delay”, under speed, under frequency, under voltage alarms are inhibited. When this delay is over, “warming up delay” starts (if configured).
- 9) When “warming up delay” is over, if generator state is normal, its indicator will be illuminated. If voltage and frequency has reached on-load requirements, the closing relay will be energized, generator will accept load, generator power indicator will turn on, and generator will enter Normal Running state; if voltage and frequency are abnormal, the controller will initiate alarm (alarm type will be displayed on LCD alarm page).

**▲NOTE:** In case of “Remote Start (off Load)”, the procedure is the same, except for step NO. 9: the closing relay will NOT be energized, generator will NOT accept load.

### Stopping Sequence:

- 1) **HGM8120N:** When mains returns normal during genset running, it enters into mains voltage “normal delay”. When mains normal delay is over, it enters into “stop delay”; it also can enter into this mode when “remote start” is inactive.
- 2) **HGM8110N:** Generator enters into “stop delay” as soon as “remote start (on load)” is inactive.
- 3) When stop delay is over, close generator relay is un-energized; generator enters into “cooling down time”. After “transfer rest time”, close mains relay is energized. Generator indicator extinguish while mains indicator lights.
- 4) Idle relay is energized as soon as entering “stop idle delay”.
- 5) If enter “ETS hold delay”, ETS relay is energized. Fuel relay is deactivated and decides whether generator is stopped or not automatically.
- 6) Then enter gen-set “fail to stop time”, auto decides whether generator is stopped or not

automatically.

- 7) Enter “after stop time” (if configured) as soon as generator stops. Otherwise, controller will send “fail to stop” alarm. (If gen-set stopped successfully after warning of “fail to stop”, it will enter “after stop time” and remove alarm.)
- 8) Enter “generator at rest” as soon as “after stop time” is over.

## 5.5 MANUAL START/STOP OPERATION

- 1) **MANUAL START:** Press , controller enters into Manual mode and its indicator lights. Press  to start generator, it can automatically detect crank disconnect, and generator accelerates to high-speed running automatically. With high temperature, low oil pressure and abnormal voltage during generator running, controller can protect genset to stop quickly. Press  (HGM8120N) or press  and  (HGM8110N) to open or close the switch. (Please refer to No.4~9 of Auto start operation for detail procedures, which the difference is only the way of switch open and close).
- 2) **MANUAL STOP:** Press  can stop the running generators. (Please refer to No.3~8 of Auto stop operation for detail procedures).

**▲NOTE:** In “manual mode”, the procedures of ATS please refer to ATS procedure of generator in this manual.

## 5.6 GENSET CONTROLLER ATS CONTROL PROCEDURES

### 5.6.1 HGM8120N ATS CONTROL PROCEDURES

#### 5.6.1.1 MANUAL TRANSFER PROCEDURES

When controller is in **Manual** mode, the switch control procedures will start through manual transfer. Users can control the loading transfer of ATS via pressing button to switch on or off.

##### A. If “Open breaker detect” is selected “Disable”

Press generator close/open key  , if generator has taken load, it will send open signals; if load disconnects, it will send gen close signals; if mains has taken load, mains will open breaker, and then generator will close after open delay over.

Press mains close/open key  , if mains has taken load, it will send open signals; if load disconnects, it will send mains close signals; if generator has taken load, generator will open breaker, and then mains will close after open delay over.

##### B. If “Open breaker detect” is selected “Enable”

To transfer load from mains to generator need to press mains close/open key   firstly. After open delay, press generator close/open key  , and generator will close breaker. (there is no action when pressing generator close/open key directly.)

The way to transfer load from generator to mains is as same as above.

#### 5.6.1.2 AUTO TRANSFER PROCEDURES

When controller is in **AUTO** mode, switch control procedures will start through automatic transfer.

##### 1) If input port is configured as Close Mains Auxiliary

###### A. If “Open breaker detect” is selected “Enable”

When transferring load from mains to generator, controller begins detecting “fail to transfer”, then the open delay and transfer rest delay will begin. When detecting time out, if switch open failed, the generator will not switch on, otherwise, generator switch on. Detecting transfer failure while generator switch on. When detecting time out, if switch on fail, it needs to wait for generator to switch on. If transfer failure warning is selected “Enable”, there is warning signals whatever switch on or off failure.

The way to transfer load from generator to mains is as same as above.

###### B. If “Open breaker detect” is selected “Disable”

Mains load is transferred into generator load, after the delay of switch off and transfer interval, generator switch on. Detecting transfer failure while generator switches on. After detecting time out, if switch on fail, then wait for generator switch on. If transfer failure warning is selected “Enable”, there is warning signals.

##### 2) If input port is not configured as Close Mains Auxiliary

Mains load is transferred into generator load, after switch off and transfer interval delay, generator switch on.

The way to transfer generator load to mains load is as same as above.

## 5.6.2 HGM8110N ATS CONTROL PROCEDURES

### 5.6.2.1 MANUAL CONTROL PROCEDURES

When controller is in Manual mode, manual control will be executed.

Users can control switch on or off by pressing  and  key.

Press generator switch on key , generator will output load signals. Press generator switch off key , generator will output unload signals.

### 5.6.2.2 AUTO CONTROL PROCEDURES

When controller is in Auto mode, switch control procedures will start auto transfer.

#### 1) If input port is configured as Close Mains Auxiliary

##### A. If "Open breaker detect" is selected "Enable"

Generator load is transferred into generator un-load, after the delay of switch off, detecting transfer failure while switch off output. When detecting time out, if switch off failed, it will wait for switch off. Otherwise, switch off is completed.

Generator unload is transferred into generator load, after the delay of switch on, detecting transfer failure while switch on outputting. When detecting time out, if switch on failed, it will wait for switch on. Otherwise, switch on is completed.

If transfer failure warning is selected "Enable", there is warning signals whatever switch on or off failure.

##### B. If "Open breaker detect" is selected "Disable"

Generator load is transferred into generator unload, after the delay of switch off, switch off is completed.

Generator unload is transferred into generator load, after the delay of switch on, detecting transfer failure while switch on outputting. When detecting time out, if switch on failed, to wait for switch on. Otherwise, switch on is completed.

If transfer failure warning is selected "Enable", there is warning signal when "switch on fail".

#### 2) If input port is not configured as Close Mains Auxiliary

Generator un-load is transferred into generator load, close generator output.

Generator load is transferred into generator un-load, open generator output.

#### NOTE:

- 1) When using ATS of no interposition, switch off detecting should "Disable";
- 2) When using ATS of having interposition, switch off "Disable" or "Enable" both are OK. If choose "Enable", switch off output should be configured;
- 3) When using AC contactor, switch off "Enable" is recommended.

**6 PROTECTION**

**6.1 WARNINGS**

When controller detects the warning signals, alarm only and not stop the genset.

**Table 8 Warning Alarms**

No.	Type	Description
1	Over Speed	When controller detects the speed is higher than the set value, it will send warn signals.
2	Under Speed	When controller detects the speed is lower than the set value, it will send warn signals.
3	Loss of Speed Signal	When controller detects the speed is 0 and the action selects "Warn", it will send warn signals.
4	Over Frequency	When controller detects the frequency is higher than the set value, it will send warn signals.
5	Under Frequency	When controller detects the frequency is lower than the set value, it will send warn signals.
6	Over Voltage	When controller detects the voltage is higher than the set value, it will send warn signals.
7	Under Voltage	When controller detects the voltage is lower than the set value, it will send warn signals.
8	Over Current	When controller detects the current is higher than the set value, it will send warn signals.
9	Fail to Stop	When generator not stops after the "stop delay" is over.
10	Charging Failure	When controller detects the charger voltage is lower than the set value, it will send warn signals.
11	Battery Over Voltage	When controller detects the battery voltage is higher than the set value, it will send warn signals.
12	Battery Under Voltage	When controller detects the battery voltage is lower than the set value, it will send warn signals.
13	Maintenance Due	When count down time is 0 and the action selects "Warn", it will send warn signals.
14	Reverse Power	When controller detects the reverse power value (power is negative) is higher than the set value, it will send warn signals.
15	Over Power	When controller detects the power value (power is positive) is higher than the set value, it will send warn signals.
16	ECU Warn	When controller gets the alarm signals from engine via J1939, it will send warn signals.
17	Gen Loss of Phase	When controller detects the generator loss phase, it will send warn signals.
18	Gen Reverse Phase Sequence	When controller detects the reverse phase sequence, it will send warn signals.
19	Switch Failure	When controller detects the switch on and off fail, and the action selects enable, it will send warn signals.
20	Temp. Sensor Open	When controller detects the sensor is open circuit, and the action

No.	Type	Description
		selects "warn", it will send warn signals.
21	High Temp.	When controller detects the temperature is higher than the set value, it will send warn signals.
22	Low Temp.	When controller detects the temperature is lower than the set value, it will send warn signals.
23	Oil Pressure Sensor Open	When controller detects the sensor is open circuit, and the action selects "warn", it will send warn signals.
24	Low Oil Pressure	When controller detects the oil pressure is lower than the set value, it will send warn signals.
25	Level Sensor Open	When controller detects the sensor is open circuit, and the action selects "warn", it will send warn signals.
26	Low Level	When controller detects the lever is lower than the set value, it will send warn signals.
27	Flexible Sensor 1 Open	When controller detects the sensor is open circuit, and the action selects "warn", it will send warn signals.
28	Flexible Sensor 1 High	When controller detects the sensor value is higher than the max. set value, it will send warn signals.
29	Flexible Sensor 1 Low	When controller detects the sensor value is lower than the min. set value, it will send warn signals.
30	Flexible Sensor 2 Open	When controller detects the sensor is open circuit, and the action selects "warn", it will send warn signals.
31	Flexible Sensor 2 High	When controller detects the sensor value is higher than the max. set value, it will send warn signals.
32	Flexible Sensor 2 Low	When controller detects the sensor value is lower than the min. set value, it will send warn signals.
33	Digital Input	When digital input port is set as warning and active, controller sends corresponding warning signals.
34	GSM Comm. Failure	When GSM is enabled but the controller couldn't detect GSM module, controller sends corresponding warning signals.
35	Earth Fault	When controller detects earth current is greater than value of setting, and the action selects "warn", it will send warn signals.

6.2 SHUTDOWN ALARM

When controller detects shutdown alarm, it will send gen close signals and stop the generator.

**Table 9 Shutdown Alarms**

No.	Type	Description
1	Emergency Stop	When controller detects emergency stop signals, it will send stop signals.
2	Over Speed	When controller detects the speed value is higher than the set value, it will send stop signals.
3	Under Speed	When controller detects the speed value is lower than the set value, it will send stop signals.
4	Loss of Speed Signal	When controller detects speed value equals to 0, and the action selects "shutdown", it will send stop signals
5	Over Frequency	When controller detects the frequency value is higher than the set value, it will send stop signals.
6	Under Frequency	When controller detects the frequency value is lower than the set value, it will send stop signals.
7	Over Voltage	When controller detects the voltage value is higher than the set value, it will send stop signals.
8	Under Voltage	When controller detects the voltage value is lower than the set value, it will send stop signals.
9	Fail to Start	If genset start failure within setting of start times, controller will send stop signals.
10	Over Current	When controller detects the current value is higher than the set value, it will send stop signals.
11	Maintenance Due	When count down time is 0 and the action selects "Shutdown", it will send stop signals.
12	ECU Shutdown	When controller receives engine shutdown signals via J1939, controller send stop signals.
13	ECU Comm. Failure	After engine start, controller does not receive data signals via J1939, controller sends stop signals.
14	Reverse Power	When controller detects reverse power value (power is negative) is higher than the set value, and the reverse power action selects "shutdown", it will send stop signals.
15	Over Power	When controller detects power value (power is positive) is higher than the set value, and the reverse power action selects "shutdown", it will send stop signals.
16	Temp. Sensor Open	When controller detects sensor is open circuit, and the action selects "shutdown", it will send stop signals.
17	High Temp.	When controller detects temperature is higher than the set value, it will send stop signals.
18	Pressure Sensor Open	When controller detects sensor is open circuit, and the action selects "shutdown", it will send stop signals.
19	Low Oil Pressure	When controller detects oil pressure is lower than the set value, it will

No.	Type	Description
		send stop signals.
20	Level Sensor Open	When controller detects sensor is open circuit, and the action selects "shutdown", it will send stop signals.
21	Flexible Sensor 1 Open	When controller detects sensor is open circuit, and the action selects "shutdown", it will send stop signals.
22	Flexible Sensor 1 High	When controller detects the sensor value is higher than the max. set value, it will send stop signals.
23	Flexible Sensor 1 Low	When controller detects the sensor value is lower than the min. set value, it will send stop signals.
24	Flexible Sensor 2 Open	When controller detects sensor is open circuit, and the action selects "shutdown", it will send stop signals.
25	Flexible Sensor 2 High	When controller detects the sensor value is higher than the max. set value, it will send stop signals.
26	Flexible Sensor 2 Low	When controller detects the sensor value is lower than the min. set value, it will send stop signals.
27	Digital Input	When digital input port is set as shutdown, and the action is active, it will send stop signals.
28	Earth Fault	When controller detects the earth current of genset exceeds preset earth fault threshold and the earth fault action selects "shutdown" it will send stop signals.

### 6.3 TRIP AND STOP ALARM

When controller detects trip and stop alarm signals, it will shut down generator quickly and stop after high speed cooling.

**Table 10 Trip and Stop Alarms**

No.	Type	Description
1	Over Current	When controller detects the value is higher than the set value, and the action selects "trip and stop", it will send trip and stop signals.
2	Maintenance Due	When count down time is 0 and the action selects "trip and stop", it will send trip and stop signals.
3	Reverse Power	When controller detects reverse power value (power is negative) is higher than the set value, and the action selects "trip and stop", it will send trip and stop signals.
4	Over Power	When controller detects the power value (power is positive) is higher than the set value, and the action selects "trip and stop", it will send trip and stop signals.
5	Digital Input	When digital input port is set as "trip and stop", and the action is active, it will send trip and stop signals.
6	Earth Fault	When controller detects the earth current of genset exceeds preset earth fault threshold and the earth fault action selects "trip and stop", it will send trip and stop signals.

6.4 TRIP ALARM

When controller detects trip alarm, it will break close generator signals quickly, but genset not stop.

Table 11 Trip Alarms

No.	Type	Description
1	Over Current	When controller detects the value is higher than the set value, and the action selects "trip", it will send trip signals.
2	Reverse Power	When controller detects reverse power value (power is negative) is higher than the set value, and the action selects "trip", it will send trip signals.
3	Over Power	When controller detects the power value (power is positive) is higher than the set value, and the action selects "trip", it will send a trip signals.
4	Digital Input	When digital input port is set as "trip", and the action is active, it will send trip signals.
5	Earth Fault	When controller detects the earth current of genset exceeds preset earth fault threshold and the earth fault action select "trip" it will send trip signals.

7 WIRINGS CONNECTION

HGM8100N series controller's back panel as following:




Fig.1 HGM8100N Back Panel

**Table 12 Terminal Wiring Connection**

No.	Function	Cable Size	Remarks	
1	B-	2.5mm <sup>2</sup>	Connected with negative of starter battery.	
2	B+	2.5mm <sup>2</sup>	Connected with positive of starter battery. If wire length is over 30m, better to double wires in parallel. Max. 20A fuse is recommended.	
3	Emergency stop	2.5mm <sup>2</sup>	Connected with B+ via emergency stop button.	
4	Fuel relay output	1.5mm <sup>2</sup>	B+ is supplied by 3 terminal, rated 16A.	
5	Start relay output	1.5mm <sup>2</sup>	B+ is supplied by 3 terminal, rated 16A.	Connected to starter coil.
6	Aux. Output 1	1.5mm <sup>2</sup>	B+ is supplied by 2 terminal, rated 7A.	Details see Table 14.
7	Aux. Output 2	1.5mm <sup>2</sup>	B+ is supplied by 2 terminal, rated 7A.	
8	Aux. Output 3	1.5mm <sup>2</sup>	B+ is supplied by 2 terminal, rated 7A.	
9	Charger(D+)	1.0mm <sup>2</sup>	Connected with charger starter's D+ (WL) terminals. Being hang up If there is no this terminal.	
10	Aux. Input 1	1.0mm <sup>2</sup>	Ground connected is active (B-).	Details see Table 15.
11	Aux. Input 2	1.0mm <sup>2</sup>	Ground connected is active (B-).	
12	Aux. Input 3	1.0mm <sup>2</sup>	Ground connected is active (B-).	
13	Aux. Input 4	1.0mm <sup>2</sup>	Ground connected is active (B-).	
14	Aux. Input 5	1.0mm <sup>2</sup>	Ground connected is active (B-).	
15	Aux. Input 6	1.0mm <sup>2</sup>	Ground connected is active (B-).	
16	Magnetic Pickup	0.5mm <sup>2</sup>	Connected with Speed sensor, shielding line is recommended. (B-) has already inside connected with speed sensor 2.	
17	MP 2			
18	MP 1			
19	Aux. Input 7	1.0mm <sup>2</sup>	Ground connected is active (B-).	Details see Table 15.
20	Aux. Output 4	1.5mm <sup>2</sup>	Normally close output, rated 7A.	Details see Table 14.
21			Public points of relay.	
22			Normally close output, rated 7A.	
23	ECU CAN	/	Impedance-120Ω shielding wire is recommended, its single-end earthed. (HGM8110V, HGM8120V, HGM8110LT and HGM8120LT without this terminal)	
24	ECU CAN H	0.5mm <sup>2</sup>		
25	ECU CAN L	0.5mm <sup>2</sup>		
26-32	RESERVE	/	Empty terminal.	
33	RS485	/	Impedance-120Ω shielding wire is recommended, its	

No.	Function	Cable Size	Remarks
34	RS485A(+)	0.5mm <sup>2</sup>	single-end earthed.
35	RS485B(-)	0.5mm <sup>2</sup>	
36	Aux. Output 5	2.5mm <sup>2</sup>	Normally close output, rated 8A.
37		2.5mm <sup>2</sup>	Normally close output, rated 8A.
38		2.5mm <sup>2</sup>	Public points of relay.
39	Aux. Output 6	2.5mm <sup>2</sup>	Normally close output, rated 8A.
40		2.5mm <sup>2</sup>	Public points of relay.
41	Mains Voltage L1	1.0mm <sup>2</sup>	Connected to A-phase of mains (2A fuse is recommended) (HGM8110N without).
42	Mains Voltage L2	1.0mm <sup>2</sup>	Connected to B-phase of mains (2A fuse is recommended) (HGM8110N without).
43	Mains Voltage L3	1.0mm <sup>2</sup>	Connected to C-phase of mains (2A fuse is recommended) (HGM8110N without).
44	Mains Voltage N	1.0mm <sup>2</sup>	Connected to N-wire of mains (HGM8110N without).
45	Genset Voltage L1	1.0mm <sup>2</sup>	Connected to A-phase of genset (2A fuse is recommended).
46	Genset Voltage L2	1.0mm <sup>2</sup>	Connected to B-phase of genset (2A fuse is recommended).
47	Genset Voltage L3	1.0mm <sup>2</sup>	Connected to C-phase of genset (2A fuse is recommended).
48	Genset Voltage N	1.0mm <sup>2</sup>	Connected to N-wire of gen-set.
49	Genset CT1	1.5mm <sup>2</sup>	Outside connected to secondary coil of current transformer (rated 5A).
50	Genset CT2	1.5mm <sup>2</sup>	Outside connected to secondary coil of current transformer (rated 5A).
51	Genset CT3	1.5mm <sup>2</sup>	Outside connected to secondary coil of current transformer (rated 5A).
52	Genset Current COM	1.5mm <sup>2</sup>	See following installation instruction.
53	Earth Current	1.5mm <sup>2</sup>	Outside connected to secondary coil of current transformer (rated 5A).
54		1.5mm <sup>2</sup>	
55	Aux. Input 8	1.0mm <sup>2</sup>	Ground connected is active (B-).
56	Aux. Sensor 1	1.0mm <sup>2</sup>	Connected to temperature, oil pressure or fuel level sensors.
57	Aux. Sensor 2	1.0mm <sup>2</sup>	
58	Oil Pressure Sensor	1.0mm <sup>2</sup>	
59	Temperature Sensor	1.0mm <sup>2</sup>	
60	Fuel Level Sensor	1.0mm <sup>2</sup>	Connected to fuel level sensor.
61	Sensor COM	/	Public terminal of sensor, (B-) has already connected.
62	RS232	0.5mm <sup>2</sup>	Connected to GSM module.

Details see Table 14

Details see Table 15.

Details see Table 16.

No.	Function	Cable Size	Remarks
63	RS232 RX	0.5mm <sup>2</sup>	
64	RS232 TX	0.5mm <sup>2</sup>	

**NOTE:** USB ports in controller rear panel are programmable parameter ports, user can directly configure controller via PC.

**NOTE:** Ethernet ports in controller rear panel are website port, user can directly configure and monitor controller via PC.

**NOTE:** Please refer to the Module Comparison in this manual for more details.

## 8 SCOPES AND DEFINITIONS OF PROGRAMMABLE PARAMETERS

### 8.1 CONTENTS AND SCOPES OF PARAMETERS

**Table 13 Parameters Contents and Scopes**

No.	Items	Parameters	Defaults	Description
<b>Mains Setting</b>				
1	AC System	(0~3)	0	0: 3P4W; 1: 3P3W; 2: 2P3W; 3: 1P2W.
2	Rated Voltage	(30~30000)V	230	Standard for checking mains over/under voltage. It is primary voltage when using voltage transformer.
3	Rated Frequency	(10.0~75.0) Hz	50.0	Standard for checking mains over/under frequency.
4	Normal Delay	(0~3600)s	10	The delay from mains abnormal to normal.
5	Abnormal Delay	(0~3600)s	5	The delay from mains normal to abnormal.
6	Volt. Trans. (PT)	(0~1)	0	0: Disable; 1: Enable
7	Volt. Trans.(PT) Primary Volt.	(30-30000)V	100	This value is the primary voltage of mains voltage transformer.
8	Volt. Trans.(PT) Secondary Volt.	(30-1000)V	100	This value is the secondary voltage of mains voltage transformer.
9	Over Voltage	(0~200)%	120	Setting value is mains rated voltage's percentage, and return value (default: over voltage: 116; under voltage: 84) and delay value (default: 5s) can be set.
10	Under Voltage	(0~200)%	80	
11	Over Frequency	(0~200)%	114	Setting value is mains rated voltage's percentage, and return value (default: over voltage: 110; under voltage: 94) and delay value (default: 5s) can be set.
12	Under Frequency	(0~200)%	90	
13	Loss of Phase	(0~1)	1	0: Disable; 1: Enable
14	Reverse Phase Seq.	(0~1)	1	
15	Mains Option	(0~1)	0	0: AMF; 1: Display only.
16	Mains Shutdown ATS Enable	(0-1)	0	0: Disable; 1: Enable When this parameter is enabled, in shutdown mode, if the mains supply is normal or simulated mains supply

No.	Items	Parameters	Defaults	Description
				conditions are met, and the mains load prohibition is inactive, the mains closing output will be activated, allowing the mains to supply the load. (Only for HGM8120V/CAN.)
17	Mains Closing Enable in Stop Mode	(0-1)	0	0: Disable; 1: Enable (Only for HGM8120LT.)
18	Mains Normal Closing Enable	(0-1)	1	0: Disable; 1: Enable (Only for HGM8120LT.)
19	Mains Abnormal Prevent Startup Enable	(0-1)	0	0: Disable; 1: Enable (Only for HGM8120LT.)
<b>Timer Setting</b>				
1	Start Delay	(0~3600)s	1	Time from mains abnormal or remote start signal is active to start genset.
2	Stop Delay	(0~3600)s	1	Time from mains normal or remote start signal is deactivated to stop genset.
3	Pre-heat Delay	(0~3600)s	0	Time of pre-powering heat plug before starter is powered up.
4	Cranking Time	(3~60)s	8	Time of starter power up.
5	Crank Rest Time	(3~60)s	10	The waiting time before second power up when engine start fail.
6	Safety On Delay	(0~3600)s	10	Alarms for low oil pressure, high temperature, under speed, under frequency/voltage, charge fail are inactive.
7	Start Idle Time	(0~3600)s	0	Idle running time of genset when starting.
8	Warming Up Time	(0~3600)s	10	Warming time between genset switch on and normal running.
9	Cooling Time	(0~3600)s	10	Radiating time before genset stop, after it unloads.
10	Stop Idle Time	(0~3600)s	0	Idle running time when genset stop.
11	ETS Solenoid Hold	(0~3600)s	20	The time of powering up the electromagnet during stop procedure.
12	Fail to Stop Delay	(0~3600)s	0	Time between ending of genset idle delay and stopped when "ETS output time" is set as 0; Time between ending of ETS hold delay and stopped when "ETS output time" is not 0.
13	After Stop Time	(0~3600)s	0	Time between genset stopped and standby.
14	Smart Preheating Enable	(0-1)	0	0: Disable; 1: Enable (HGM8110LT and HGM8120LT don't have this function.)

No.	Items	Parameters	Defaults	Description
15	Smart Preheating Sensor Selection	(0-4)	0	The sensor selection refers to the associated sensor set: 0: Temperature Sensor; 1: Pressure Sensor; 2: Level Sensor; 3: Flex. Sensor 1; 4: Flex. Sensor 2. (HGM8110LT and HGM8120LT don't have this function.)
16	Smart Preheating Set Value	(0-1000)	40	The set value represents the sensor threshold for ending this phase. If enabled, when the value of the selected sensor exceeds the set value, the controller will end the preheat process in advance. (HGM8110LT and HGM8120LT do not have this function.)
<b>Engine Setting</b>				
1	Engine Type	(0~39)	0	Default: Conventional engine. When connected to J1939 engine, choose the corresponding type.
2	Flywheel Teeth	(10~300)	118	Tooth number of the engine, for judging of crank disconnect conditions and inspecting of engine speed. See the installation instructions.
3	Rated Speed	(0~6000)r/min	1500	Offer standard to judge over/under/loading speed.
4	Idle Speed	(0~6000)r/min	750	When the GTSC1_PLUS generator set is selected, the idle speed can be controlled during the idle phase.
5	Loading Speed	(0~100)%	90	Setting value is percentage of rated speed. Controller detects when it is ready to load. It won't switch on when speed is under loading speed.
6	Loss of Speed Signal	(0~3600)s	5	Time from detecting speed is 0 to confirm the action.
7	Loss of Speed Action	(0~1)	0	0: Warn; 1: Shutdown
8	Over Speed Shutdown	(0~200)%	114	Setting value is percentage of rated speed and delay value (over speed default as 2s, under speed default as 3s) also can be set.
9	Under Speed Shutdown	(0~200)%	80	
10	Over Speed Warn	(0~200)%	110	Setting value is percentage of rated speed and delay value (default: 5s) and return value (default: over speed: 108; under
11	Under Speed Warn	(0~200)%	86	

No.	Items	Parameters	Defaults	Description
				speed: 90) also can be set.
12	Battery Rated Voltage	(0~60.0)V	24.0	Standard for detecting over/under voltage of battery.
13	Battery Over Volts	(0~200)%	120	Setting value is percentage of rated voltage of battery. Delay value (default: 60s) & return value (default: over voltage: 115; under voltage: 90) also can be set.
14	Battery Under Volts	(0~200)%	85	
15	Charge Alt Fail	(0~60.0)V	8.0	In normal running, when charger D+(WL) voltage under this value, charge failure alarms.
16	Start Attempts	(1~10) times	3	Max. Crank times of crank attempts. When reach this number, controller will send start failure signal.
17	Crank Disconnect	(0~6)	2	See Table 17. There are 3 conditions of disconnecting starter with engine. Each condition can be used alone and simultaneously to separating the start motor and genset as soon as possible.
18	Disconnect Generator Freq	(0~200)%	24	When generator frequency higher than the set value, starter will be disconnected. See the installation instruction.
19	Disconnect Engine Speed	(0~200)%	24	When generator speed higher than the set value, starter will be disconnected. See the installation instruction.
20	Disconnect Oil Pressure	(0~1000)kPa	200	When generator oil pressure higher than the set value, starter will be disconnected. See the installation instruction.
21	Speed Regulation Rate	(1~50)r/min	20	This function works with input speed regulation function. The speed is adjusted at this rate for each input port speed raise/drop active. (Conventional unit has no this function.)
22	ECU Comm. Address	(0-255)	3	When the GTSC1_PLUS generator set is selected, the ECU communication address can be modified. (HGM8110LT and HGM8120LT don't have this function.)
23	Charging Voltage Selection	(0~1)	0	0: Charger D+; 1: Engine ECU (HGM8110LT and HGM8120LT don't have this function.)
<b>Generator Setting</b>				
1	AC System	(0~3)	0	0: 3P4W; 1: 3P3W; 2: 2P3W; 3: 1P2W.
2	Poles	(2~64)	4	Numbers of generator pole, used for

No.	Items	Parameters	Defaults	Description
				calculating starter rotate speed when without speed sensor.
3	Rated Voltage	(30~30000)V	230	To offer standards for detecting of generator' over/under voltage and loading voltage. It is primary voltage when using voltage transformer.
4	Loading Voltage	(0~200)%	85	Setting value is percentage of generator rated voltage. Detect when controller ready to loading. If generator voltage under load voltage, won't enter into normally running.
5	Rated Frequency	(10.0~75.0) Hz	50.0	To offer standards for detecting of over/under/load frequency.
6	Loading Frequency	(0~200)%	85	Setting value is percentage of generator rated frequency. When generator frequency under load frequency, it won't enter into normal running.
7	Volt. Trans. (PT)	(0~1)	0	0: Disable; 1: Enable
8	Over Volt. Shutdown	(0~200)%	120	Setting value is percentage of generator rated volt. Delay value (default: 3s) also can be set.
9	Over Volt. Trip	(0-200)%	112	Setting value is percentage of generator rated volt. Delay value (default: 3s) also can be set. (HGM8110LT and HGM8120LT don't have this function.)
10	Under Volt. Shutdown	(0~200)%	80	Setting value is percentage of generator rated volt. Delay value (default: 3s) also can be set.
11	Under Volt. Trip	(0-200)%	82	Setting value is percentage of generator rated volt. Delay value (default: 3s) also can be set. (HGM8110LT and HGM8120LT don't have this function.)
12	Over Freq. Shutdown	(0~200)%	114	Setting value is percentage of generator rated freq. Delay value (default: over frequency: 2s; under frequency: 3s) also can be set
13	Under Freq. Shutdown	(0~200)%	80	
14	Over Freq. Trip	(0-200)%	112	Setting value is percentage of generator rated freq. Delay value (default: 3s) also can be set. (HGM8110LT and HGM8120LT don't have this function.)
15	Under Freq. Trip	(0-200)%	82	
16	Over Volt. Warn	(0~200)%	110	Setting value is percentage of generator rated volt. Delay value (default: 5s) and
17	Under Volt.	(0~200)%	84	

No.	Items	Parameters	Defaults	Description
	Warn			return value(default: over voltage: 108; under voltage: 86) also can be set.
18	Over Freq. Warn	(0~200)%	110	Setting value is percentage of generator rated freq. Delay value (default: 5s) and return value (default: over frequency: 108; under frequency: 86) also can be set.
19	Under Freq. Warn	(0~200)%	84	
20	Loss of Phase	(0~1)	1	0: Disable 1: Enable.
21	Reverse Phase Sequence	(0~1)	1	When it is enabled, controller begins to monitor alarms.
<b>Load Setting</b>				
1	CT Ratio	(5~6000)/5	500	The ratio of external current transformer.
2	Rated Current	(5~6000)A	500	Generator's rated current, standard of load current.
3	Rated Power	(0~6000)kW	276	Generator's rated power, standard of load power.
4	Over Current	(0~200)%	120	Setting value is percentage of generator rated volt. Delay value also can be set as DMT or IDMT.
5	Over Power	(0~1) (0-200)% (0-200)% (0-3600)s (0-3)	0 110 105 5 1	0: Disable 1: Enable The set value is the percentage of the rated active power of the generator. The return value is the percentage of the rated active power of the generator. Delay value. Action (0: Warning; 1: Alarm Shutdown; 2: Shutdown; 3: Trip but not shutdown).
6	Reverse Power	(0~1) (0-200)% (0-200)% (0-3600)s (0-3)	0 10 5 5 0	0: Disable 1: Enable The set value is the percentage of the rated active power of the generator. The return value is the percentage of the rated active power of the generator. Delay value. Action (0: Warning; 1: Alarm Shutdown; 2: Shutdown; 3: Trip but not shutdown).
7	Earth Fault	(0~1)	0	0: Disable 1: Enable This configuration can only be modified on PC software.)
<b>ATS Setting</b>				
1	Transfer Time	(0~7200)s	5	Interval time from mains switch off to generator switch on; or from generator switch off to mains switch on.
2	Close Time	(0~20.0)s	5.0	Pulse width of mains/generator switch on. When it is 0, means output constantly.
3	Open Time	(0~20.0)s	3.0	Pulse width of mains/generator switch off.
4	Check Time	(0~20.0)s	5.0	Time of detecting ATS auxiliary contacts

No.	Items	Parameters	Defaults	Description
				after transferred.
5	Check Fail Warn	(0~1)	0	0: Disable 1: Enable
6	Open Check	(0~1)	0	0: Disable 1: Enable
7	Instant. Mains Dropout	(0~1)	1	0: Disable 1: Enable
<b>Module Setting</b>				
1	Power On Mode	(0~2)	0	0: Stop mode 1: Manual mode 2: Auto mode
2	Module Address	(1~254)	1	Controller's address during remote sensing.
3	Stop Bits	(0~1)	0	0: 2 stop bits; 1: 1 stop bit This configuration can only be modified on PC software.)
4	Language	(0~2)	0	0: Simplified Chinese 1: English 2: Others.
5	Password	(0~65535)	00318	For entering advanced parameters setting.
6	Temperature Unit	(0~1)	0	0: °C 1: °F This configuration can only be modified on PC software.)
7	Press Unit	(0~2)	0	0: kPa; 1: Psi; 2: Bar This configuration can only be modified on PC software.)
8	Time and Date			Current time and date can be set by users.
9	Ethernet	(0~1)	1	0: Disable 1: Enable All the settings about Ethernet (IP address, subnet mask) will active after the next time power on.
<b>GSM Setting</b>				
1	GSM Enable	(0~1)	0	0: Disable; 1: Enable
2	Phone Number	Max.20 digits		0: Disable; 1: Enable Its national and area's cods must be added. e.g. China: 8613666666666.
<b>Scheduling and Maintenance Setting</b>				
1	Scheduled Run	(0~1)	0	0: Disable; 1: Enable
2	Scheduled Not Run	(0~1)	0	0: Disable; 1: Enable
3	Maintenance	(0~1)	0	0: Disable; 1: Enable
<b>Analog Sensor Setting</b>				
Temperature Sensor				
1	Curve Type	(0~15)	7	SGX. See Table 16.
2	Open Circuit Action	(0~2)	0	0: Warn; 1: Shutdown; 2: No action
3	High Temp. Shutdown	(0~300)°C	98	Shutdown when sensor temperature higher than this value. Detecting only after

No.	Items	Parameters	Defaults	Description
				safety delay is over. The delay value (default: 3s) also can be set.
4	High Temp. Warn	(0~300)°C	95	Warn when sensor temperature higher than this value. Detecting only after safety delay is over. The delay value (default: 5s) and return value (default: 93) also can be set.
5	Low Temp. Warn	(0~1)	0	0: Disable; 1: Enable
<b>Oil Pressure Sensor</b>				
1	Curve Type	(0~15)	7	SGX. See Table 16.
2	Open Circuit Action	(0~2)	0	0: Warn; 1: Shutdown; 2: No action
3	Low Oil Pressure Shutdown	(0~1000)kPa	103	Shutdown when oil pressure lower than this value. Detecting only after safety delay is over. The delay value (default: 3s) also can be set.
4	Low Oil Pressure Warn	(0~1000)kPa	124	Warn when oil pressure higher than this value. Detecting only after safety delay is over. The delay value (default: 5s) and return value (default: 138) also can be set.
<b>Level Sensor</b>				
1	Curve Type	(0~15)	4	SGH. See Table 16.
2	Open Circuit Action	(0~2)	0	0: Warn; 1: Shutdown; 2: No action
3	Low Level Warn	(0~300)%	10	Warn when level lower than this value. It is detecting all the time. The delay value (default: 5s) and return value (default: 15) also can be set.
<b>Flexible Sensor 1</b>				
1	Flexible Sensor 1 Setting	(0~1)	0	0: Disable 1: Enable; (can be set as temperature/pressure/level sensor).
<b>Flexible Sensor 2</b>				
1	Flexible Sensor 2 Setting	(0~1)	0	0: Disable; 1: Enable; (can be set as temperature/pressure/level sensor).
<b>Digital Inputs Setting</b>				
<b>Digital Input Port 1</b>				
1	Contents Setting	(0~56)	28	Remote start (on load). See Table 15. (The setting range for HGM8110LT and HGM8120LT is up to 55.)
2	Active Type	(0~1)	0	0: Closed to active; 1: Open to active
<b>Digital Input Port 2</b>				
1	Contents Setting	(0~56)	26	High temperature shutdown. See Table 15. (The setting range for HGM8110LT and HGM8120LT is up to 55.)

No.	Items	Parameters	Defaults	Description
2	Active Type	(0~1)	0	0: Closed to active; 1: Open to active
Digital Input Port 3				
1	Contents Setting	(0~56)	27	Low oil pressure shutdown. See Table 15. (The setting range for HGM8110LT and HGM8120LT is up to 55.)
2	Active Type	(0~1)	0	0: Closed to active; 1: Open to active
Digital Input Port 4				
1	Contents Setting	(0~56)	0	User defined. See Table 15. (The setting range for HGM8110LT and HGM8120LT is up to 55.)
2	Active Type	(0~1)	0	0: Closed to active; 1: Open to active
3	Arming	(0~3)	2	0: From safety on 1: From starting 2: Always 3: Never
4	Active Actions	(0~4)	0	0: Warn; 1: Shutdown; 2: Trip and stop; 3: Trip; 4: Indication
5	Active Delay	(0~20.0)s	2.0	Time from detecting active to confirm
6	Description			LCD display detailed contents when the input is active.
Digital Input Port 5				
1	Contents Setting	(0~56)	0	User defined. See Table 15. (The setting range for HGM8110LT and HGM8120LT is up to 55.)
2	Active Type	(0~1)	0	0: Closed to active; 1: Open to active
3	Arming	(0~3)	2	0: From safety on 1: From starting 2: Always 3: Never
4	Active Actions	(0~4)	1	0: Warn; 1: Shutdown; 2: Trip and stop; 3: Trip; 4: Indication
5	Active Delay	(0~20.0)s	2.0	Time from detecting active to confirm
6	Description			LCD display detailed contents when the input is active. This configuration can only be modified on PC software.)
Digital Input Port 6				
1	Contents Setting	(0~56)	0	User defined .See Table 15. (The setting range for HGM8110LT and HGM8120LT is up to 55.)
2	Active Type	(0~1)	0	0: Closed to active; 1: Open to active
3	Arming	(0~3)	2	0: From safety on 1: From starting 2: Always 3: Never
4	Active Actions	(0~4)	2	0: Warn; 1: Shutdown; 2: Trip and stop; 3: Trip; 4: Indication
5	Active Delay	(0~20.0)s	2.0	Time from detecting active to confirm
6	Description			LCD display detailed contents when the input is active.

No.	Items	Parameters	Defaults	Description
				This configuration can only be modified on PC software.)
<b>Digital Input Port 7</b>				
1	Contents Setting	(0~56)	5	Lamp test. See Table 15. (The setting range for HGM8110LT and HGM8120LT is up to 55.)
2	Active Type	(0~1)	0	0: Closed to active; 1: Open to active
<b>Digital Input Port 8</b>				
1	Contents Setting	(0~56)	0	User defined. See Table 15. (The setting range for HGM8110LT and HGM8120LT is up to 55.)
2	Active Type	(0~1)	0	0: Closed to active; 1: Open to active
3	Arming	(0~3)	2	0: From safety on 1: From starting 2: Always 3: Never
4	Active Actions	(0~4)	0	0: Warn; 1: Shutdown; 2: Trip and stop; 3: Trip; 4: Indication
5	Active Delay	(0~20.0)s	2.0	Time from detecting active to confirm. This configuration can only be modified on PC software.)
6	Description			LCD display detailed contents when the input is active. This configuration can only be modified on PC software.)
<b>Relay Outputs Setting</b>				
<b>Relay Output Port 1</b>				
1	Contents Setting	(0~299)	1	User defined period output 1 (default as in preheat output). See Table 14.
2	Active Type	(0~1)	0	0: Normally open; 1: Normally close.
<b>Relay Output Port 2</b>				
1	Contents Setting	(0~299)	35	Idle control. See Table 14.
2	Active Type	(0~1)	0	0: Normally open; 1: Normally close.
<b>Relay Output Port 3</b>				
1	Contents Setting	(0~299)	29	Generator closed output. See Table 14.
2	Active Type	(0~1)	0	0: Normally open; 1: Normally close.
<b>Relay Output Port 4</b>				
1	Contents Setting	(0~299)	31	Mains closed output. See Table 14. (HGM8110N is reserved.)
2	Active Type	(0~1)	0	0: Normally open; 1: Normally close.
<b>Relay Output Port 5</b>				
1	Contents Setting	(0~299)	38	ETS. See Table 14.
2	Active Type	(0~1)	0	0: Normally open; 1: Normally close.
<b>Relay Output Port 6</b>				
1	Contents Setting	(0~299)	48	Common alarm. See Table 14.
2	Active Type	(0~1)	0	0: Normally open; 1: Normally close.

8.2 ENABLE DEFINITION OF DIGITAL OUTPUT PORTS

8.2.1 DEFINED CONTENTS OF DIGITAL OUTPUT PORTS

Table 14 Defined Contents of Digital Output Ports

No.	Type	Description
0	Not Used	
1	Custom Period 1	Details of function description please see the following.
2	Custom Period 2	
3	Custom Period 3	
4	Custom Period 4	
5	Custom Period 5	
6	Custom Period 6	
7	Custom Combined 1	
8	Custom Combined 2	
9	Custom Combined 3	
10	Custom Combined 4	
11	Custom Combined 5	
12	Custom Combined 6	
13	Preheat Output	When the controller starting engine is in preheating, and preheat is enabled (PC sensor 4 configuration interface), it outputs when lower the threshold, not output when over the threshold. When smart preheating is enabled (in the timer configuration interface), the output engages when the temperature is below the preheating threshold and disengages when it exceeds the preheating threshold. (HGM8110LT and HGM8120LT don't have the smart preheating function.)
14	Reserved	
15	Reserved	
16	Reserved	
17	Air Flap Control	Action when over speed shutdown and emergency stop. It also can close the air in flow.
18	Audible Alarm	Action when warning, shutdown, trips. Can be connected annunciator externally. When "Alarm Mute" configurable input port is active, it can remove the alarm.
19	Louver Control	Action in genset starting and disconnect when genset stopping completely.
20	Fuel Pump Control	It is controlled by fuel pump of level sensor's limited threshold.
21	Heater Control	It is controlled by heating of temperature sensor's setting bound.
22	Cooler Control	It is controlled by cooler of temperature sensor's setting bound.
23	Fuel Pre-Supply Output	Action when start and running safety period.

No.	Type	Description
24	Generator Excite	Output in start period. If there is no generator frequency during high-speed running, output for 2 seconds again.
25	Pre-Lubricate	Actions in period of pre-heating to safety run.
26	Remote Control Output	This port is controlled by communication (PC).
27	GSM Power	Supply power for GSM module (GSM module is reset when GSM communication failed).
28	Key Output	When the unit type is SINOTRUK Or SINOTRUK3000, it constantly outputs after preheating.
29	Close Gen Output	Control generator to take load.
30	Open Output	Control generator to off load.
31	Close Mains Output	Control mains to take load. (HGM8110N is reserved.)
32	Reserved	
33	Start Relay	
34	Fuel Relay	Action when genset is cranking and disconnect when stopped completely.
35	Idle Control	Used for engine which has idles. Close before starting and open in warming up delay; Close during stopping idle mode and open when stop is completed.
36	Speed Raise Output	Action in warming up delay.
37	Speed Drop Output	Action between the period from "stop idle" to "wait for stop".
38	Energize to Stop	Used for engines with ETS electromagnet. Close when stop idle is over and open when pre-set "ETS delay" is over.
39	Speed Drop Pulse	Active 0.1s when controller enters into stop idle, used for control part of ECU dropping to idle speed.
40	ECU Stop	Used for ECU engine and control its stop.
41	ECU Power	Used for ECU engine and control its power.
42	Speed Raise Pulse	Active 0.1s when controller enters into warming up delay; used for control part of ECU raising to normal speed.
43	Crank Success	Close when detects a successful start signal.
44	Generator OK	Action when generator is normal.
45	Generator Available	Action in period of generator ok to high-speed cooling.
46	Mains OK	Action when mains normal. (HGM8110N is reserved.)
47	Reserved	
48	Common Alarm	Action when genset common warning, common shutdown, common trips alarm.
49	Common Trip and Stop	Action when common trip and stop alarm.
50	Common Shutdown	Action when common shutdown alarm.
51	Common Trip	Action when common trips alarm.
52	Common Warning	Action when common warning alarm.
53	Reserved	

No.	Type	Description
54	Battery Over Voltage	Action when battery's over voltage warning alarm.
55	Battery Under Voltage	Action when battery's low voltage warning alarm.
56	Charging Failure	Action when charge failure warning alarms.
57	Reserved	
58	Reserved	
59	Reserved	
60	ECU Warning	Indicate ECU sends a warning signal.
61	ECU Shutdown	Indicate ECU sends a shutdown signal.
62	ECU Comm. Failure	Indicate controller not communicate with ECU.
63	Reserved	
64	Reserved	
65	Reserved	
66	Reserved	
67	Reserved	
68	Reserved	
69	Digital Input 1 Active	Action when input port 1 is active.
70	Digital Input 2 Active	Action when input port 2 is active.
71	Digital Input 3 Active	Action when input port 3 is active.
72	Digital Input 4 Active	Action when input port 4 is active.
73	Digital Input 5 Active	Action when input port 5 is active.
74	Digital Input 6 Active	Action when input port 6 is active.
75	Digital Input 7 Active	Action when input port 7 is active.
76	Digital Input 8 Active	Action when input port 8 is active.
77~80	Reserved	
81~96	Expand Digital Input 1~16 Active	Action when expand digital input port is active.
97~98	Reserved	
99	Emergency Stop	Action when emergency stop alarm.
100	Fail to Start	Action when failed start alarm.
101	Fail to Stop	Action when failed stop alarm.
102	Under Speed Warning	Action when under speed warning.
103	Under Speed Shutdown	Action when under speed shuts down.
104	Over Speed Warning	Action when over speed warn.
105	Over Speed Shutdown	Action when over speed shutdown alarm.
106	Reserved	
107	Reserved	
108	Reserved	
109	Gen Over Freq. Warning	Action when generator over frequency warning.
110	Gen Over Freq. Shutdown	Action when generator over frequency shutdown alarm.
111	Gen Over Volt. Warn	Action when generator over voltage warning.
112	Gen Over Volt. Shut	Action when generator over voltage shutdown.
113	Gen Under Freq. Warning	Action when generator low frequency warning.
114	Gen Under Freq. Shut	Action when generator low frequency shutdown.
115	Gen Under Volt. Warning	Action when generator low voltage warning.
116	Gen Under Volt. Shut	Action when generator low voltage shutdown.

No.	Type	Description
117	Gen Loss of Phase	Action when generator loss phase.
118	Gen Reverse Phase Seq.	Action when generator reverse phase sequence.
119	Reserved	
120	Over Power Alarm	Action when controller detects generator has over power.
121	Reserved	
122	Reverse Power Alarm	Action when controller detects generator has reverse power.
123	Over Current Alarm	Action when over current alarm.
124	Reserved	This function is only applicable to the HGM8110V/8120V/8110CAN/8120CAN models.
	Mains Abnormal	This function is only applicable to the HGM8120T.
125	Mains Inactive	(HGM8110N is reserved.)
126	Mains Over Freq.	(HGM8110N is reserved.)
127	Mains Over Volt.	(HGM8110N is reserved.)
128	Mains Under Freq.	(HGM8110N is reserved.)
129	Mains Under Volt.	(HGM8110N is reserved.)
130	Mains Phase Seq. Wrong	(HGM8110N is reserved.)
131	Mains Loss of Phase	(HGM8110N is reserved.)
132~138	Reserved	
139	High Temp Warning	Action when high-temperature warning.
140	Low Temp Warning	Action when low temperature warning.
141	High Temp Shutdown	Action when high-temperature shutdown alarm.
142	Reserved	
143	Low Oil Pressure Warning	Action when low oil pressure warning.
144	Low Oil Pressure Shutdown	Action when low oil pressure shutdown.
145	Oil Pressure Sensor Open	Action when oil pressure sensor is open circuit.
146	Reserved	
147	Low Fuel Level	Action when controller has low fuel level alarm.
148	Reserved	
149	Reserved	
150	Flexible Sensor 1 High Warn	
151	Flexible Sensor 1 Low Warn	
152	Flexible Sensor 1 High Shut	
153	Flexible Sensor 1 Low Shut	
154	Flexible Sensor 2 High Warn	
155	Flexible Sensor 2 Low Warn	
156	Flexible Sensor 2 High Shut	
157	Flexible Sensor 2 Low Shut	
158~161	Reserved	
162	Expand 1 Sensor 15 High Shut.	
163	Expand 1 Sensor 15 High Alarm	
164	Expand 1 Sensor 15 Low Shut.	
165	Expand 1 Sensor 15 Low Alarm	
166~201	Expand 1 Sensor 16~24	

No.	Type	Description
202~229	Reserved	
230	Stop Mode	Action in Stop mode.
231	Manual Mode	Action in Manual mode.
232	Reserved	
233	Auto Mode	Action in Auto mode.
234	Generator On Load	
235	Mains On Load	(HGM8110N is reserved.)
236~239	Reserved	
240~279	PLC Flag 1~40	Action when PLC flag is 1.
280~299	Reserved	

## 8.2.2 CUSTOM PERIOD OUTPUT

Defined period output is composed by 2 parts, **period output S1** and **condition output S2**.



While **S1** and **S2** are **TRUE** synchronously, **OUTPUT**;

While **S1** or **S2** is **FALSE**, **NOT OUTPUT**.

**Period output S1**, can set generator's one or more period output freely, can set the delay time and output time after entering into period.

**Condition output S2**; can set as any conditions in output ports.

**▲NOTE:** When delay time and output time both are 0 in period output S1, it is TRUE in this period.

### Example,

Output period: start

Delay output time: 2s

Output time: 3s

Condition output contents: input port 1 is active


Close when condition output active/inactive: close when active (disconnect when inactive);

Input port 1 active, after enter "start time" and delay 2s, this defined period output is outputting, after 3s, stop outputting;

Input port 1 inactive, defined output period is not outputting.

## 8.2.3 CUSTOM COMBINED OUTPUT

Defined combination output is composed by 3 parts, or condition output S1, or condition output S2, and condition output S3.



**S1** or **S2** is **TRUE**, and **S3** is **TRUE**, defined combination output is outputting;

**S1** and **S2** are **FALSE**, or **S3** is **FALSE**, defined combination output is not outputting.

**▲NOTE:** S1, S2, S3 can be set as any contents except for "defined combination output" in the output setting.

**▲NOTE:** 3 parts of defined combination output (S1, S2, S3) couldn't include or recursively include themselves.

**Example,**

Contents of or condition output S1: input port 1 is active;

Close when or condition output S1 is active /inactive: close when active (disconnect when inactive);

Contents of or condition output S2, input port 2 is active;

Close when or condition output S2 is active /inactive: close when active (disconnect when inactive);

Contents of and condition output S3: input port 3 is active;

Close when and condition output S3 is active /inactive: close when active (disconnect when inactive);

When input port 1 active or input port 2 active, if input port 3 is active, defined combination output is outputting; If input port 3 inactive, defined combination output is not outputting;

When input port 1 inactive and input port 2 inactive, whatever input port 3 is active or not, defined combination output is not outputting.

**8.3 DEFINED CONTENTS OF DIGITAL INPUT PORTS (ALL GND(B-) CONNECTED ACTIVE)**

**Table 15 Defined Contents of Digital Input Ports**

No.	Type	Description
0	Users Defined	Including following functions, Indication: indicate only, not warning or shutdown. Warning: warn only, not shutdown. Shutdown: alarm and shutdown immediately Trip and stop: alarm, generator unloads and shuts down after high-speed cooling Trip: alarm, generator unloads but not shutdown. Never: input inactive. Always: input is active all the time. From crank: detecting as soon as start. From safety on: detecting after safety on run delay.
1	Reserved	Only for HGM8100LT.
	Not Used	Only for HGM8100V/CAN.
2	Alarm Mute	Can prohibit "Audible Alarm" output when input is active.
3	Reset Alarm	Can reset shutdown alarm and trip alarm when input is active.
4	60Hz Active	Use for CANBUS engine and it is 60Hz when input is active.
5	Lamp Test	All LED indicators are illuminating when input is active.
6	Panel Lock	All buttons in panel is inactive except direction buttons and there is  in the right of first row in LCD when input is active.
7	Reserved	
8	Idle Speed Active	Under voltage/frequency/speed protection is inactive.
9	Auto Stop Inhibit	In <b>Auto</b> mode, during generator normal running, when input is active, inhibit generator shutdown automatically.
10	Auto Start Inhibit	In <b>Auto</b> mode, inhibit generator start automatically when input is active.
11	Scheduled Run Inhibit	In <b>Auto</b> mode, inhibit scheduled run genset when input is

No.	Type	Description
		active.
12	Preheating Completion Input	When the generator set is in the preheating stage, if a preheating completion input is received and certain conditions are met, it can proceed to the fuel output stage. (The HGM8110LT and HGM8120LT models do not have this function.)
13	Gen Closed Auxiliary	Connect generator loading switch's Aux. Point.
14	Gen Load Inhibit	Prohibit genset switch on when input is active.
15	Mains Closed Auxiliary	Connect mains loading switch's Aux. Point. (HGM8110LT and HGM8120LT don't have this function.)
16	Mains Load Inhibit	Prohibit mains switch on when input is active. (HGM8110LT and HGM8120LT don't have this function.)
17	Auto Mode Lock	When input is active, controller enters into Auto mode; mode selection buttons are inactive.
18	Auto Mode Inhibit	When input is active, controller won't work under Auto mode. Auto mode key and simulate auto key input does not work.
19	Reserved	
20	Reserved	
21	Alarm Stop Inhibit	All shutdown alarms are prohibited except emergency stop.
22	Instrument Mode	All outputs are prohibited in this mode.
23	Reserved	
24	Reset Maintenance Time	Controller will set maintenance time and date as default when input is active.
25	Reserved	
26	High Temperature Shutdown	Connected sensor digital input.
27	Low Oil Pressure Shutdown	Connected sensor digital input.
28	Remote Start On Load	In <b>Auto</b> mode, when input is active, genset can start automatically and take load after genset normal running; when input is inactive, genset will stop automatically.
29	Remote Start Off Load	In <b>Auto</b> mode, when input is active, genset can start automatically and NOT take load after genset normal running; when input is inactive, genset will stop automatically.
30	Manual Start	In <b>Manual</b> mode, when input is active, genset will start automatically; when input is inactive, genset will stop automatically.
31	Reserved	
32	Reserved	
33	Simulate Stop Key	An external button can be connected and pressed as simulate panel.
34	Simulate Manual Key	
35	Reserved	

No.	Type	Description
36	Simulate Auto Key	An external button can be connected and pressed as simulate panel.
37	Simulate Start Key	
38	Simulate Generator Load Key	This is simulate G-close key when HGM8110N controller is applied.
39	Simulate Mains Load Key	HGM8110N is reserved.
40	Reserved	
41	Reserved	
42	Reserved	
43	Mains AMF Control	The Mains supply AMF control function is activated when the input is inactive. (This function is not available for HGM8110V, HGM8110CAN, HGM8110LT, and HGM8120LT models.)
44	Reserved	
45	Aux. Mains OK	In <b>Auto</b> mode, mains normal when input is active. (HGM8110N doesn't have this function.)
46	Aux. Mains Failure	In <b>Auto</b> mode, mains abnormal when input is active. (HGM8110N doesn't have this function.)
47	Alternative Config. 1	Alternative configuration is active when input is active. Users can set different parameters to make it easy to select current configuration via input port.
48	Alternative Config. 2	
49	Alternative Config. 3	
50	Reserved	
51	Speed Raise Input	When it is active, speed value of speed regulation rate is increased. (Only active for 34 item GTSC1 of ECU unit type.)
52	Speed Drop Input	When it is active, speed value of speed regulation rate is decreased. (Only active for 34 item GTSC1 of ECU unit type.) (HGM8110N doesn't have this function.)
53~54	Reserved	
55	Aftertreatment Inhibit Regeneration	When the input is active, a regeneration inhibit command is sent to the ECU that supports aftertreatment regeneration. (This function is not available for the HGM8100LT model.)
56	Aftreatment Manual Regeneration	When the input is active, a regeneration command is sent to the ECU that supports aftertreatment regeneration. (This function is not available for the HGM8100LT model.)

8.4 SELECTION OF SENSORS

Table 16 Sensors Selection

No.		Description	Remark
1	Temperature Sensor	0 Not used 1 Custom Res Curve 2 Custom 4-20mA curve 3 VDO 4 CURTIS 5 VOLVO-EC 6 DATCON 7 SGX 8 SGD 9 SGH 10 PT100 11 SUSUKI 12 PRO 13~15 Reserved	Defined resistance's range is 0~6KΩ, default is SGX sensor.
2	Pressure Sensor	0 Not used 1 Custom Res Curve 2 Custom 4-20mA curve 3 VDO 10Bar 4 CURTIS 5 VOLVO-EC 6 DATCON 10Bar 7 SGX 8 SGD 9 SGH 10 VDO 5Bar 11 DATCON 5Bar 12 DATCON 7Bar 13 SUSUKI 14 PRO 15 Reserved	Defined resistance's range is 0~6KΩ, default is SGX sensor.
3	Fuel Level Sensor	0 Not used 1 Custom Res Curve 2 Custom 4-20mA curve 3 SGD 4 SGH 5~15 Reserved	Defined resistance's range is 0~6KΩ, default is SGH sensor.

**NOTE:** User should make special declare when order controller if your genset is equipped with sensor of 4~20mA.

8.5 CONDITIONS OF CRANK DISCONNECT SELECTION

Table 17 Crank Disconnect Conditions Selection

No.	Setting Description
0	Gen frequency
1	Speed sensor
2	Speed sensor + Gen frequency
3	Oil pressure
4	Oil pressure + Gen frequency
5	Oil pressure + Speed sensor
6	Oil pressure + Speed sensor + Gen frequency

**NOTE:**

1. There are 3 conditions to make starter disconnected with engine, that is, speed sensor, generator frequency and engine oil pressure. They all can be used separately. We recommend that engine oil pressure should be using with speed sensor and generator frequency together, in order to make the starter motor is separated with engine immediately and can check crank disconnect exactly.
2. Speed sensor is the magnetic equipment which be installed in starter for detecting flywheel teeth.
3. When set as speed sensor, must ensure that the number of flywheel teeth is as same as setting, otherwise, "over speed shutdown" or "under speed shutdown" may be caused.
4. If genset without speed sensor, please don't select corresponding items, otherwise, "start fail" or "loss speed signal" maybe caused.
5. If genset without oil pressure sensor, please don't select corresponding items.
6. If not select generator frequency in crank disconnect setting, controller will not collect and display the relative power quantity (can be used in water pump set); if not select speed sensor in crank disconnect setting, the rotating speed displayed in controller is calculated by generator frequency and number of poles.

## 9 PARAMETERS SETTING

In **HGM8110N** controller, there are no items of mains in setting and also no mains items in configurable ports of input/output.

**⚠CAUTION:** Please change the controller parameters when generator is in standby mode only (e. g. Crank disconnect conditions selection, configurable input, configurable output, various delay), otherwise, shutdown and other abnormal conditions may happen.

**⚠NOTE:** Maximum set value must over minimum set value in case that the condition of too high as well as too low will happen.

**⚠NOTE:** When setting the warning alarm, please set the correct return value; otherwise, maybe there is abnormal alarm. When setting the maximum value, the return value must less than set value; when setting the minimum value, the return value must over set value.


**⚠NOTE:** Please set the generator frequency value as low as possible when cranking, in order to make the starter be separated quickly as soon as crank disconnect.

**⚠NOTE:** Configurable input could not be set as same items; otherwise, there are abnormal functions. However, the configurable output can be set as same items.

SmartGen

**10 SENSORS SETTING**

1. When reselect sensors, the sensor curve will be transferred into the standard value. For example, if temperature sensor is SGX (120°C resistor type), its sensor curve is SGX (120°C resistor type); if select the SGD (120°C resistor type), the temperature sensor curve is SGD curve.
2. When there is difference between standard sensor curves and using sensor, user can adjust it in "curve type".
3. When input the sensor curve, X value (resistor) must be input from small to large, otherwise, mistake occurs.
4. If select sensor type as "None", sensor curve is not working.
5. If corresponding sensor has alarm switch only, user must set this sensor as "None", otherwise, maybe there is shutdown or warning.
6. The headmost or backmost values in the vertical coordinates can be set as same as below,



**Fig.2 Sensor Curve Setting**

**Table 18 Normal Pressure Unit Conversion Form**

	N/m <sup>2</sup> (pa)	kgf/cm <sup>2</sup>	bar	psi
1Pa	1	1.02x10 <sup>-5</sup>	1x10 <sup>-5</sup>	1.45x10 <sup>-4</sup>
1kgf/cm <sup>2</sup>	9.8x10 <sup>4</sup>	1	0.98	14.2
1bar	1x10 <sup>5</sup>	1.02	1	14.5
1psi	6.89x10 <sup>3</sup>	7.03x10 <sup>-2</sup>	6.89x10 <sup>-2</sup>	1

## 11 COMMISSIONING

Please make the under procedures checking before commissioning,

- 1) Ensure all the connections are correct and wires diameter is suitable.
- 2) Ensure that the controller DC power has fuse, controller's positive and negative correctly connected to starting battery.
- 3) Emergency stop must be connected with positive of starting battery via scram button's normal close point and fuse.
- 4) Take proper action to prevent engine to crank disconnect (e. g. Remove the connection wire of fuel valve). If checking is OK, make the starting battery power on; choose manual mode and controller will execute routine.
- 5) Set controller under manual mode, press "start" button, genset will start. After the setting times as setting, controller will send signal of Start Fail; then press "stop" to reset controller.
- 6) Recover the action of stop engine start (e. g. Connect wire of fuel valve), press start button again, genset will start. If everything goes well, genset will normal run after idle running (if idle run be set). During this time, please watch for engine's running situations and AC generator's voltage and frequency. If abnormal, stop genset running and check all wires connection according to this manual.
- 7) Select the **AUTO** mode from controller's panel, connect mains signal. After the mains normal delay, controller will transfer ATS (if fitted) into mains load. After cooling time, controller will stop genset and make it into "at rest" mode until there is abnormal of mains.
- 8) When mains is abnormal again, genset will be started automatically and into normal running, then controller send signal to making generator switch on, and control the ATS as generator load. If not like this, please check ATS' wires connection of control part according to this manual.
- 9) If there is any other question, please contact SmartGen's service personnel.

12 TYPICAL APPLICATION




Fig.3 HGM8110CAN Typical Application Diagram




Fig.4 HGM8120N typical application diagram

**NOTE:** Fuse F1: min. 2A; max. 20A. Fuse F2: max. 32A. Users should select suitable fuse depend on practical application.




Fig.5 HGM8100N Expansion Module Typical Application Diagram


SmartGen

**13 INSTALLATION**

**13.1 OVERALL DIMENSION**

Controller is panel built-in design; it is fixed by clips when installed. The controller’s overall dimensions and cutout dimensions for panel, please refers to as following,

Unit: mm



**Fig.6 Overall Dimensions and Panel Cutout**

**NOTE:** The torque of 0.27N·m (2.75kgf·cm) is recommended.

**13.2 BATTERY VOLTAGE INPUT**

HGM8100N series controller can suit for widely range of battery voltage DC(8~35)V. Negative of battery must be connected with the engine shell. Diameter of wire that connects from power supply to battery must be over 2.5mm<sup>2</sup>. If floating charger configured, please firstly connect output wires of charger to battery’s positive and negative directly, then, connect wires from battery’s positive and negative to controller’s positive and negative input ports in order to prevent charger disturbing the controller’s normal working.

**13.3 SPEED SENSOR INPUT**

Speed sensor is the magnetic equipment which be installed in starter and for detecting flywheel teeth. Its connection wires to controller should apply for 2 cores shielding line. The shielding layer should connect to No.16 terminal in controller while another side is hanging in air. The else two signal wires are connected to No.17 and No.18 terminals in controller. The output voltage of speed sensor should be within AC(1~24)V (effective value) during the full speed. AC12V is recommended (in rated speed). When install the speed sensor, let the sensor is spun to contacting flywheel first, then, port out 1/3 lap, and lock the nuts of sensor at last.

**13.4 OUTPUT AND EXPAND RELAYS**

**CAUTION:** All outputs of controller are relay contact output type. If need to expand the relays, please add freewheel diode to both ends of expand relay’s coils (when coils of relay have DC current) or, increase resistance-capacitance return circuit (when coils of relay have AC current), in order to prevent disturbance to controller or others equipment.

## 13.5 AC INPUT

Current input of controller must be connected to outside current transformer. And the current transformer's secondary side current must be 5A. At the same time, the phases of current transformer and input voltage must correct. Otherwise, the current of collecting and active power maybe not correct.

**▲NOTE:** ICOM port must be connected to negative pole of battery.



**WARNING!** When there is load current, transformer's secondary side prohibits open circuit.

## 13.6 WITHSTAND VOLTAGE TEST

**▲CAUTION:** When controller has been installed in control panel, if need the high voltage test, please disconnect controller's all terminal connections, in order to prevent high voltage into controller and damage it.

SmartGen

**14 GSM SHORT MESSAGE ALARM AND REMOTE CONTROL**

**14.1 GSM SHORT MESSAGE ALARM**

When controller detects alarm, it will send short message to phone automatically.

**NOTE:** All alarms about shutdown, trip and stop and trip will be sent to the pre-set phone. Warnings are sent to the phone according to the pre-set.

**14.2 GSM SHORT MESSAGE REMOTE CONTROL**

Users send order message to GSM module, then controller will make actions according to this SMS order and pass back corresponding operations information. Controllers only execute the orders by pre-set.

**Table 19 SMS Orders List**

No.	SMS Orders	Pass back Information	Description
1	SMS GENSET	GENSET ALARM	Genset stop alarm.
		SYSTEM IN STOP MODE GENSET AT REST	At rest status in stop mode.
		SYSTEM IN MANUAL MODE GENSET AT REST	At rest status in manual mode.
		SYSTEM IN AUTO MODE GENSET AT REST	At rest status in Auto mode.
		SYSTEM IN STOP MODE GENSET IS RUNNING	Running status in stop mode.
		SYSTEM IN MANUAL MODE GENSET IS RUNNING	Running status in manual mode.
		SYSTEM IN AUTO MODE GENSET AT RUNNING	Running status in stop mode.
2	SMS START	GENSET ALARM	Generator shutdown alarm or trip alarm.
		STOP MODE NOT START	Cannot start in stop mode.
		SMS START OK	Start in manual mode.
		AUTO MODE NOT START	Cannot start in auto mode
3	SMS STOP MODE	SMS STOP OK	Set as stop mode.
4	SMS MANUAL MODE	SMS MANUAL MODE OK	Set as manual mode.
5	SMS AUTO MODE	SMS AUTO MODE OK	Set as auto mode.
6	SMS DETAIL	Pass back information can be set via controller software.	Gets details information of genset.
7	SMS INHIBIT START	INHIBIT START OK	Set as inhibit start.
8	SMS PERMIT START	PERMIT START OK	Remove inhibit boot.

**NOTE:** Its national and area's codes must be added. e.g. China: 8613666666666.

**▲NOTE:** When sending orders, users need to follow SMS orders in above form and all the letters must be capital.

**▲NOTE:** Pass back information from SMS DETAIL include: working mode, mains voltage, generator voltage, load current, mains frequency, generator frequency, active power, apparent power, power factor, battery voltage, D+ voltage, water temperature, oil pressure, oil level, engine speed, total running time, genset status, and alarm status.

SmartGen

15 CONNECTIONS OF CONTROLLER WITH ENGINE J1939

15.1 CUMMINS ISB/ISBE

Table 20 Connector B

Terminals of controller	Connector B	Remark
Fuel relay output	39	
Starting relay output	-	Connect with starter coil directly.
Auxiliary output 1	Expand 30A relay, battery voltage of 01, 07, 12, 13 is supplied by relay.	ECU power; Set auxiliary output 1 as "ECU power".

Table 21 9-Pin Connector

Terminals of controller	9 pins connector	Remark
CAN GND	SAE J1939 shield	CAN communication shielding line (connect with ECU terminal only).
CAN(H)	SAE J1939 signal	Impedance 120Ω connecting line is recommended.
CAN(L)	SAE J1939 return	Impedance 120Ω connecting line is recommended.

Engine type: Cummins ISB.

15.2 CUMMINS QSL9

Suitable for CM850 engine control module.

Table 22 50-Pin Connector

Terminals of controller	50 pins connector	Remark
Fuel relay output	39	
Starting relay output	-	Connect to starter coil directly.

Table 23 9-Pin Connector

Terminals of controller	9 pins connector	Remark
CAN GND	SAE J1939 shield-E	CAN communication shielding line (connect with ECU terminal only).
CAN(H)	SAE J1939 signal-C	Using impedance 120Ω connecting line.
CAN(L)	SAE J1939 return-D	Using impedance 120Ω connecting line.

Engine type: Cummins-CM850.

**15.3 CUMMINS QSM11 (IMPORT)**

It is suitable for CM570 engine control module. Engine type is QSM11 G1, QSM11 G2.

**Table 24 C1 Connector**

Terminals of controller	C1 connector	Remark
Fuel relay output	5&8	Outside expand relay, when fuel output, making port 5 and port 8 of C1 be connected.
Starting relay output	-	Connect to starter coil directly.

**Table 25 3-Pin Data Link Connector**

Terminals of controller	3 pins data link connector	Remark
CAN GND	C	CAN communication shielding line (connect with ECU terminal only).
CAN(H)	A	Using impedance 120Ω connecting line.
CAN(L)	B	Using impedance 120Ω connecting line.

**Engine type: Cummins ISB.**

**15.4 CUMMINS QSX15-CM570**

It is suitable for CM570 engine control module. Engine type is QSX15.

**Table 26 50-Pin Connector**

Terminals of controller	50 pins connector	Remark
Fuel relay output	38	Oil spout switch.
Starting relay output	-	Connect to starter coil directly.

**Table 27 9-Pin Connector**

Terminals of controller	9 pins connector	Remark
CAN GND	SAE J1939 shield-E	CAN communication shielding line (connect with ECU terminal only).
CAN(H)	SAE J1939 signal-C	Using impedance 120Ω connecting line.
CAN(L)	SAE J1939 return-D	Using impedance 120Ω connecting line.

**Engine type: Cummins QSX15-CM570.**

**15.5 CUMMINS GCS-MODBUS**

It is suitable for GCS engine control module. RS485-MODBUS used to read information of engine. Engine types are QSX15, QST30, SK23/45/60/78 and so on.

**Table 28 D-SUB Connector 06**

Terminals of controller	D-SUB connector 06	Remark
Fuel relay output	5&8	Outside expand relay, when fuel output, making port 05 and 08 of the connector 06 be connected.
Starting relay output	-	Connect to starter coil directly.

**Table 29 D-SUB Connector 06**

Terminals of controller	D-SUB connector 06	Remark
RS485 GND	20	CAN communication shielding line (connect with ECU terminal only).
RS485+	21	Using impedance 120Ω connecting line.
RS485-	18	Using impedance 120Ω connecting line.

**Engine type: Cummins QSK-MODBUS, Cummins QST-MODBUS, Cummins QSX-MODBUS.**

**15.6 CUMMINS QSM11**

**Table 30 Engine OEM Connector**

Terminals of controller	OEM connector of engine	Remark
Fuel relay output	38	
Starting relay output	-	Connect with starter coil directly.
CAN GND	-	CAN communication shielding line (connect with controller's this terminal only).
CAN(H)	46	Using impedance 120Ω connecting line.
CAN(L)	37	Using impedance 120Ω connecting line.

**Engine type: common ECU.**

15.7 CUMMINS QSZ13

Table 31 Engine OEM Connector

Terminals of controller	OEM connector of engine	Remark
Fuel relay output	45	
Starting relay output	-	Connect to starter coil directly.
Auxiliary output 1	16&41	Setting to idle speed control, normally close output. Making 16 connect to 41 during high-speed running of controller via external expansion relay.
Auxiliary output 2	19&41	Setting to pulse raise speed control, normally open output. Making 19 connect with 41 for 0.1s during high-speed warming of controller via external expansion relay.
CAN GND	-	CAN communication shielding line (connect with controller's this terminal only).
CAN(H)	1	Using impedance 120Ω connecting line.
CAN(L)	21	Using impedance 120Ω connecting line.

Engine type: Common ECU.

15.8 DETROIT DIESEL DDEC III/IV

Table 32 Engine CAN Port

Terminals of controller	CAN port of engine	Remark
Fuel relay output	Expand 30A relay, battery voltage of ECU is supplied by relay.	
Starting relay output	-	Connect to starter coil directly.
CAN GND	-	CAN communication shielding line (connect with controller's terminal only).
CAN(H)	CAN(H)	Using impedance 120Ω connecting line.
CAN(L)	CAN(L)	Using impedance 120Ω connecting line.

Engine type: Common ECU.

15.9 DEUTZ EMR2

Table 33 F Connector

Terminals of controller	F connector	Remark
Fuel relay output	Expand 30A relay, battery voltage of 14 is supplied by relay. Fuse is 16A.	
Starting relay output	-	Connect to starter coil directly.
-	1	Connect to battery negative pole.
CAN GND	-	CAN communication shielding line (connect with controller's terminal only).
CAN(H)	12	Impedance 120Ω connecting line is recommended.
CAN(L)	13	Impedance 120Ω connecting line is recommended.

Engine type: VolvoEDC4.

15.10 JOHN DEERE

Table 34 21-Pin Connector

Terminals of controller	21 pins connector	Remark
Fuel relay output	G, J	
Starting relay output	D	
CAN GND	-	CAN communication shielding line (connect with controller's terminal only).
CAN(H)	V	Using impedance 120Ω connecting line.
CAN(L)	U	Using impedance 120Ω connecting line.

Engine type: John Deere.

15.11 MTU MDEC

Suitable for MTU engines, 2000 series, 4000 series.

Table 35 X1 Connector

Terminals of controller	X1 connector	Remark
Fuel relay output	BE1	
Starting relay output	BE9	
CAN GND	E	CAN communication shielding line (connect with one terminal only).
CAN(H)	G	Using impedance 120Ω connecting line.
CAN(L)	F	Using impedance 120Ω connecting line.

Engine type: MTU-MDEC-303.

**15.12 MTU ADEC (SMART MODULE)**

It is suitable for MTU engine with ADEC (ECU8) and SMART module.

**Table 36 ADEC (X1 Port)**

Terminals of controller	ADEC (X1 port)	Remark
Fuel relay output	X1 10	X1 Terminal 9 Connected to negative of battery.
Starting relay output	X1 34	X1 Terminal 33 Connected to negative of battery.

**Table 37 ADEC (X4 Port)**

Terminals of controller	SMART (X4 port)	Remark
CAN GND	X4 3	CAN communication shielding line (connect to controller's this terminal only).
CAN(H)	X4 1	Using impedance 120Ω connecting line.
CAN(L)	X4 2	Using impedance 120Ω connecting line.

**Engine type: MTU-ADEC.**

**15.13 MTU ADEC (SAM MODULE)**

It is suitable for MTU engine with ADEC (ECU7) and SAM module.

**Table 38 ADEC (X1 Port)**

Terminals of controller	ADEC (X1 port)	Remark
Fuel relay output	X1 43	X1 Terminal 28 Connected to negative of battery.
Starting relay output	X1 37	X1 Terminal 22 Connected to negative of battery.

**Table 39 SAM (X23 Port)**

Terminals of controller	SAM (X23 port)	Remark
CAN GND	X23 3	CAN communication shielding line (connect with controller's this terminal only).
CAN(H)	X23 2	Using impedance 120Ω connecting line.
CAN(L)	X23 1	Using impedance 120Ω connecting line.

**Engine type: Common ECU.**

**15.14 PERKINS**

It is suitable for ADEM3/ ADEM4 engine control module. Engine type is 2306, 2506, 1106, and 2806.

**Table 40 Connector**

Terminals of controller	Connector	Remark
Fuel relay output	1, 10, 15, 33, 34	
Starting relay output	-	Connect to starter coil directly.
CAN GND	-	CAN communication shielding line (connect with controller's terminal only).
CAN(H)	31	Using impedance 120Ω connecting line.
CAN(L)	32	Using impedance 120Ω connecting line.

**Engine type: Perkins.**

**15.15 SCANIA**

It is suitable for S6 engine control module. Engine model is DC9, DC12, and DC16.

**Table 41 B1 Connector**

Terminals of controller	B1 connector	Remark
Fuel relay output	3	
Starting relay output	-	Connect to starter coil directly.
CAN GND	-	CAN communication shielding line (connect with controller's terminal only).
CAN(H)	9	Using impedance 120Ω connecting line.
CAN(L)	10	Using impedance 120Ω connecting line.

**Engine type: Scania.**

**15.16 VOLVO EDC3**

Suitable engine control model is TAD1240, TAD1241, and TAD1242.

**Table 42 "Stand alone" Connector**

Terminals of controller	"Stand alone" Connector	Remark
Fuel relay output	H	
Starting relay output	E	
Auxiliary output 1	P	ECU power; Set auxiliary output 1 as "ECU power".

**Table 43 "Data bus" Connector**

Terminals of controller	"Data bus" connector	Remark
CAN GND	-	CAN communication shielding line (connect with controller's terminal only).
CAN(H)	1	Using impedance 120Ω connecting line.
CAN(L)	2	Using impedance 120Ω connecting line.

**Engine type: Volvo.**

**▲NOTE:** When this engine type is selected, preheating time should be set to at least 3 seconds.

**15.17 VOLVO EDC4**

Suitable engine types: TD520, TAD520 (optional), TD720, TAD720 (optional), TAD721, TAD722, and TAD732.

**Table 44 Connector**

Terminals of controller	Connector	Remark
Fuel relay output	Expanded 30A relay, and relay offers battery voltage for terminal14. Fuse is 16A.	
Starting relay output	-	Connect to starter coil directly.
	1	Connected to negative of battery.
CAN GND	-	CAN communication shielding line (connect with controller's terminal only).
CAN(H)	12	Using impedance 120Ω connecting line.
CAN(L)	13	Using impedance 120Ω connecting line.

**Engine type: VolvoEDC4.**

**15.18 VOLVO-EMS2**

Volvo Engine types are TAD734, TAD940, TAD941, TAD1640, TAD1641, and TAD1642.

**Table 45 Engine CAN Port**

Terminals of controller	Engine's CAN port	Remark
Auxiliary output 1	6	ECU stop; Set auxiliary output 1 as "ECU stop".
Auxiliary output 2	5	ECU power; Set auxiliary output 2 as "ECU power".
	3	Negative power.
	4	Positive power.
CAN GND	-	CAN communication shielding line (connect with controller's terminal only).
CAN(H)	1(Hi)	Using impedance 120Ω connecting line.
CAN(L)	2(Lo)	Using impedance 120Ω connecting line.

**Engine type: Volvo-EMS2.**

**▲NOTE:** When this engine type is selected, preheating time should be set to at least 3 seconds.

**15.19 YUCHAI**

It is suitable for Yuchai BOSCH common rail electronic-controlled engine.

**Table 46 Engine 42-Pin Port**

Terminals of controller	Engine 42 pins port	Remark
Fuel relay output	1.40	Connect to engine ignition lock.
Starting relay output	-	Connect to starter coil directly.
CAN GND	-	CAN communication shielding line (connect with controller's this terminal only).
CAN(H)	1.35	Using impedance 120Ω connecting line.
CAN(L)	1.34	Using impedance 120Ω connecting line.

**Table 47 Engine 2-Pin Port**

Battery	Engine 2 pins port	Remark
Battery negative	1	Wire diameter 2.5mm <sup>2</sup> .
Battery positive	2	Wire diameter 2.5mm <sup>2</sup> .

**Engine type: BOSCH.**

**15.20 WEICHAH**

It is suitable for Weichai BOSCH common rail electronic-controlled engine.

**Table 48 Engine Port**

Terminals of controller	Engine port	Remark
Fuel relay output	1.40	Connect to engine ignition lock.
Starting relay output	1.61	
CAN GND	-	CAN communication shielding line (connect with controller's this terminal only).
CAN(H)	1.35	Using impedance 120Ω connecting line.
CAN(L)	1.34	Using impedance 120Ω connecting line.

**Engine type: GTSC1.**

**▲NOTE:** If there is any question of connection between controller and ECU communication, please feel free to contact SmartGen's service personnel.

## 16 ETHERNET INTERFACE

### 16.1 ETHERNET INTERFACE INTRODUCTION

ETHERNET port, used for controller monitoring, can realize network client connection mode.

**▲NOTE:** After changing controller network parameters (e.g. IP address, subnet mask etc.) new settings will take effect only after the controller is restarted.

### 16.2 NETWORK CLIENT CONNECTION MODE

When the controller is used as network client, it can be monitored via network port using TCP ModBus protocol.

The procedure is the following:

- 1) Set IP address and subnet mask of the controller. The IP address should be in the same network segment and different from the IP address used by the monitoring equipment (e.g. PC). e.g.: if monitoring equipment IP address is 192.168.0.16, controller IP can be 192.168.0.18, subnet mask is 255.255.255.0.
- 2) Connect the controller. It can be connected to the monitoring equipment directly using network cable or via switchboard.
- 3) The communication between the controller and monitoring equipment is carried out using TCP ModBus protocol.

**▲NOTE:** Controller parameters can be set in this connection mode. SmartGen provides testing software for this connection mode. Communication protocol can be obtained from the SmartGen service.

### 16.3 CONTROLLER AND NETWORK CABLE CONNECTION

**Table 49 Controller Internet Access**

No.	Name	Description
1	TX+	Tranceive Data+
2	TX-	Tranceive Data-
3	RX+	Receive Data+
4	NC	Not connected
5	NC	Not connected
6	RX-	Receive Data-
7	NC	Not connected
8	NC	Not connected

- 1) Controller and PC connection via a line of cable

For this connection crossover cable must be used.

Crossover cable: EIA/TIA 568A standard on one end and EIA/TIA 568B on the other end.

**▲NOTE:** If PC network port has Auto MDI/MDIX function, parallel cable can also be used.

- 2) Controller and PC connection via switchboard (or router).

Parallel lines must be used.

Parallel cable: EIA/TIA 568A standard on both ends or EIA/TIA 568B standard on both ends.

**▲NOTE:** If switchboard (or router) network port has Auto MDI/MDIX function, crossover cable can also be used.

**Table 50 Fault Finding**

Symptoms	Possible Solutions
Controller no response with power.	Check starting batteries; Check controller connection wirings; Check DC fuse.
Genset shutdown	Check the water/cylinder temperature is too high or not; Check the genset AC voltage; Check DC fuse.
Controller emergency stop	Check emergency stop button is correct or not; Check whether the starting battery positive be connected with the emergency stop input; Check whether the circuit is open.
Low oil pressure alarm after crank disconnect	Check the oil pressure sensor and its connections.
High water temp. alarm after crank disconnect	Check the water temperature sensor and its connections.
Shutdown alarm in running	Check related switch and its connections according to the information on LCD; Check digital inputs.
Crank not disconnect	Check fuel oil circuit and its connections; Check starting batteries; Check speed sensor and its connections; Refer to engine manual.
Starter no response	Check starter connections; Check starting batteries.
Genset running while ATS not transfer	Check ATS; Check the connections between ATS and controllers.
RS485 communication is abnormal	Check connections; Check setting of COM port is correct or not; Check RS485's connections of A and B is reverse connect or not; Check RS485 transfer module whether damaged or not; Check communication port of PC whether damage.
ECU communication failed	Check connections of CAN high and low polarity; Check if correctly connected of 120Ω resistor; Check if type of engine correct; Check if connections from controller to engine and setting of outputs correct.
ECU warning or stop	Get information from LCD of alarm page; If there is detailed alarm, check engine according to description. If not, please refer to engine manual according to SPN alarm code.