


---

# SmartGen

MAKING CONTROL SMARTER

## ACC7100

# DIESEL AIR COMPRESSOR CONTROLLER COMMUNICATION PROTOCOL



郑州众智科技股份有限公司  
SMARTGEN(ZHENGZHOU)TECHNOLOGY CO.,LTD.

---

**SmartGen** Registered trademark

No. 28 Xuemei Street, Zhengzhou, Henan, China

Tel: +86-371-67988888/67981888/67992951

+86-371-67981000 (overseas)

Fax: +86-371-67992952

Web: [www.smartgen.com.cn/](http://www.smartgen.com.cn/)

[www.smartgen.cn/](http://www.smartgen.cn/)

Email: [sales@smartgen.cn](mailto:sales@smartgen.cn)

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

SmartGen reserves the right to change the contents of this document without prior notice.

**Table 1 - Software Version**

| Date       | Version | Note   |
|------------|---------|--|
| 2019-10-18 | 1.0     | Original release.  |
| 2022-11-21 | 1.1     | 1. Update company logo;<br>2. Add some communication data. |
|            |         |  |
|            |         |  |

# CONTENT

|       |  |    |
|-------|--|----|
| 1.    | INTRODUCTION .....                         | 4  |
| 2.    | MODBUS BASIC RULES .....                   | 4  |
| 3.    | DATA FRAME FORMAT .....                    | 4  |
| 4.    | COMMUNICATION PROTOCOL.....                | 4  |
| 4.1   | ILLUSTRATION .....                         | 4  |
| 4.2   | INFORMATION FRAME FORMAT .....             | 5  |
| 4.3   | ADDRESS CODE.....                          | 5  |
| 4.4   | FUNCTION CODE.....                         | 5  |
| 4.4.1 | ILLUSTRATION.....                          | 5  |
| 4.4.2 | 03H READ REGISTERS .....                   | 5  |
| 4.4.3 | 05H FORCE SINGLE COIL.....                 | 5  |
| 4.4.4 | 06H WRITE SINGLE REGISTER .....            | 5  |
| 4.5   | DATA FIELD .....                           | 6  |
| 4.5.1 | ILLUSTRATION.....                          | 6  |
| 4.5.2 | FUNCTION 03H DATA FIELD FORMAT .....       | 6  |
| 4.5.3 | FUNCTION 05H DATA FIELD FORMAT .....       | 6  |
| 4.5.4 | FUNCTION 06H DATA FIELD FORMAT .....       | 6  |
| 4.6   | ERROR CHECK CODE (CRC).....                | 7  |
| 4.7   | EXAMPLES OF INFORMATION FRAME FORMAT ..... | 8  |
| 4.7.1 | FUNCTION CODE 03H .....                    | 8  |
| 4.7.2 | FUNCTION CODE 05H .....                    | 9  |
| 4.7.3 | FUNCTION CODE 06H .....                    | 10 |
| 4.8   | ERROR HANDLING .....                       | 11 |
| 5.    | ATTACHMENT: ADDRESS AND DATA.....          | 12 |
| 5.1   | FUNCTION CODE 03H MAPPING DATA FIELD ..... | 12 |
| 5.2   | FUNCTION CODE 05H MAPPING COIL FIELD.....  | 24 |
| 5.3   | ENGINE RUNNING STATUS .....                | 26 |

## 1. INTRODUCTION

This protocol describes read and write command format of PC serial port and the definition of internal information data for the third-party to develop and use.

MODBUS communication protocol allows the module to transfer information and data effectively with PLC, RTU, SCADA system of international brands (such as, Schneider, Siemens, and Modicon etc.), and DCS or third-party monitoring system which is compatible with MODBUS. The monitoring system can be set up if a central PC (or IPC)-based communication master software is added (such as Kingview, Intouch, FIX, synall etc.).

## 2. MODBUS BASIC RULES

- All communication loops should follow the master-slave mode. In this way, data can be transferred between a master (e.g. PC) and 32 slaves.
- No communication can start from slaves.
- In communication loop, all communication should be transmitted in “information frame”.
- If master or slave receives information frame with unknown command, no response will be given.

## 3. DATA FRAME FORMAT

Communication is asynchronously transferred by the unit of byte (data frame). Each data frame is a serial data stream of 10 bits (stop bit: 1) or 11 bits (stop bit: 2) between master and slave.

**Table 2 - Data Frame Format**

| Item       | Description              |
|------------|--------------------------|
| Start bit  | 1-bit                    |
| Data bit   | 8-bit                    |
| Parity bit | No parity                |
| Stop bit   | 1-bit, 2-bit can be set. |
| Baud rate  | 9600bps                  |

## 4. COMMUNICATION PROTOCOL

### 4.1 ILLUSTRATION

When communication command is sent to the instrument, device who accords with the address code receives the communication command, and removes the address code to read information. If nothing goes wrong, it shall conduct the task, and then send implementation result to the sender. The returned information includes address code, function code of implemented action, data after implemented action, and CRC. If an error occurs, then nothing shall be sent.

## 4.2 INFORMATION FRAME FORMAT

**Table 3 - Information Frame Format**

| Initiating structure          | Address code | Function code | Data field         | CRC               | End structure                 |
|-------------------------------|--------------|---------------|--------------------|-------------------|-------------------------------|
| Delay (equivalent to 4 bytes) | 1 byte 8-bit | 1 byte 8-bit  | N bytes<br>N*8-bit | 2 bytes<br>16-bit | Delay (equivalent to 4 bytes) |

### 4.3 ADDRESS CODE

Address code is the first data frame (8-bit) in each transmitted information frame (0-255). Single device address range is 1-255, which means that slave device whose address code is defined by users will receive the information sent by the master. Each slave has a unique address code, and each response begins with its address code. The address code issued by the master means the slave address to be sent to, while address code issued by slave means the responded slave address.

### 4.4 FUNCTION CODE

#### 4.4.1 ILLUSTRATION

Function code is the second data of each communication transmission. ModBus communication protocol defines function code as 1-255 (01H-0FFH). ACC7100 controller uses a part of it. By master request master can tell slave to conduct certain action. By slave response slave can show that it has responded to the master and conducted the action as the function code issued by the slave is the same as the one issued by the master. If the function code MSB is 1 (function code > 127), it means slave does not respond, or response has an error.

The following table shows the specific signification and operation of function code.

**Table 4 - ModBus Partial Function Codes**

| Function code | Definition            | Operation                                 |
|---------------|-----------------------|---|
| 03H           | Read Registers        | Reads single or multiple register data.   |
| 05H           | Force Single Coil     | Forces a single coil.                     |
| 06H           | Write Single Register | Write a 16-bit binary number to register. |

#### 4.4.2 03H READ REGISTERS

With communication command of function code 03H, master can read the numerical registers (all kinds of collected analogue data and pre-set parameter values are stored in the register) inside the instrument. Input register value of 03H mapping data field is 16-bit (2 bytes). So register values read from the instrument are all 2 bytes. For each time maximum readable register values are 125.

Command format of slave response is address code, function code, data field, and CRC code. Data in data field are dual bytes in a group of 2 bytes and high byte is in the front.

#### 4.4.3 05H FORCE SINGLE COIL

With this command master can store single coil data to bit registers (e.g. ATS transfer control). Slave also can respond information to the master with this command.

#### 4.4.4 06H WRITE SINGLE REGISTER

With this command master can store single data to bit registers in the instrument. Register in ModBus communication protocol refers to 16-bit (2 bytes) and high byte is in the front. In this way all

points in the device are 2 bytes. Command format is slave address, function code, data field and CRC code.

## 4.5 DATA FIELD

### 4.5.1 ILLUSTRATION

Data field varies with different function codes.

### 4.5.2 FUNCTION 03H DATA FIELD FORMAT

**Table 5 - Master Request**

| Data Sequence | Data Signification    | Byte Count |
|---------------|-----------------------|------------|
| 1             | Starting address      | 2          |
| 2             | Read register numbers | 2          |

**Table 6 - Slave Response**

| Data Sequence | Data Signification  | Byte Count |
|---------------|---------------------|------------|
| 1             | Loopback byte count | 1          |
| 2             | N register data     | N          |

### 4.5.3 FUNCTION 05H DATA FIELD FORMAT

**Table 7 - Master Request**

| Data Sequence | Data Signification      | Byte Count |
|---------------|-------------------------|------------|
| 1             | Coil address            | 2          |
| 2             | Force single coil value | 2          |

**Table 8 - Slave Response**

| Data Sequence | Data Signification | Byte Count |
|---------------|--------------------|------------|
| 1             | Coil address       | 2          |
| 2             | Single coil value  | 2          |

### 4.5.4 FUNCTION 06H DATA FIELD FORMAT

**Table 9 - Master Request**

| Data Sequence | Data Signification       | Byte Count |
|---------------|--------------------------|------------|
| 1             | Register address         | 2          |
| 2             | Register value (2 bytes) | 2          |

**Table 10 - Slave Response**

| Data Sequence | Data Signification       | Byte Count |
|---------------|--------------------------|------------|
| 1             | Register address         | 2          |
| 2             | Register value (2 bytes) | 2          |

## 4.6 ERROR CHECK CODE (CRC)

Master or slave can detect whether the received information is wrong or not with CRC. Sometimes due to electric noise or other interference, information will have small change in the transmission process. CRC ensures master or slave does not respond to the wrong information in the transmission process. In this way system safety and efficiency are guaranteed. CRC applies CRC-16 calibration method.

For 2 bytes CRC, low byte is in the front and high byte is in the back.

**▲NOTE:** All information frame formats are same: address code, function code, data area and CRC code.

CRC includes 2 bytes, which is 16-bit binary number. CRC is counted by the sender and placed at the end of the transmitted information. Responded device will count the received information is the same as the information again. If they are different, then it means there is an error.

CRC counting method: first place 16-bit register as 1. Then gradually tackle with 8-bit data information. Only 8-bit of data is used in the process of CRC counting. Start bit and stop bit are not included.

In the process of CRC counting, 8-bit data is Exclusive OR with the register data. The obtained result moves 1 bit to the low byte direction and fill MSB with 0. Check LSB again and if LSB is 1, then make register contents Exclusive OR with the preset values. If LSB is 0, then do not do Exclusive OR counting.

This process is repeated for many times. After the eighth bit move, the next 8-bit shall Exclusive OR with the current register contents. This also repeated for 8 times as the last one. Until all data information is handled, the last register contents are CRC value.

CRC-16 Calculation Procedure:

- 1) Place a 16-bit register as FFFF hex;
- 2) Make the first 8-bit data Exclusive OR with the low 8-bit of the CRC register, and put the result in the CRC register;
- 3) Shift the CRC register one bit to the right, and fill MSB with 0. Examine the moved-out bit;
- 4) If LSB was 0: repeat Step 3 (another shift);  
If LSB was 1: Exclusive OR the CRC register with A001 hex;
- 5) Repeat Step 3 and 4 until 8 shifts have been performed. When this is done, a complete 8-bit data are processed;
- 6) Repeat Step 2 to 5 for the next 8-bit data of the message;
- 7) The final CRC register value is the CRC code. Least Significant Byte is transmitted first and Most Significant Byte is at the last.

**▲NOTE:** The calculation of CRC code starts from <slave address> for all bytes, excluding <CRC code>.

## 4.7 EXAMPLES OF INFORMATION FRAME FORMAT

### 4.7.1 FUNCTION CODE 03H

Slave address is 00 and start address is 0026H of 3 data (each data is 2 bytes).

**Table 11 - Data Address Example**

| Address | Data (Hex) |
|---------|------------|
| 0026H   | 0014       |
| 0027H   | 0014       |
| 0028H   | 0005       |

**Table 12 - Function Code 03H Master Request Example**

| Request          | Bytes | Example (Hex)                            |
|------------------|-------|--|
| Slave address    | 1     | 01 Send to slave 01                      |
| Function code    | 1     | 03 Read holding registers                |
| Starting address | 2     | 00 Starting address is 0026H<br>26       |
| Count number     | 2     | 00 Read 3 data (total 6 bytes)<br>03     |
| CRC code         | 2     | E4 CRC code which calculated by PC<br>00 |

**Table 13 - Function Code 03H Slave Response Example**

| Response      | Bytes | Example (Hex)                               |
|---------------|-------|---|
| Slave address | 1     | 01 Respond slave address 01                 |
| Function code | 1     | 03 Read register                            |
| Read count    | 1     | 06 3 data (total 6 bytes)                   |
| Data 1        | 2     | 00 The content of address 0026H<br>14       |
| Data 2        | 2     | 00 The content of address 0027H<br>14       |
| Data 3        | 2     | 00 The content of address 0028H<br>05       |
| CRC code      | 2     | 91 CRC code which calculated by slave<br>71 |

#### 4.7.2 FUNCTION CODE 05H

Slave address is 01 and starting address is 0002H of 1 coil. Place 0002H unit as 1.

**Table 14 - Coil Data Address Example**

| Address | Data (Hex) |
|---------|------------|
| 0000    | 0          |
| 0001    | 1          |
| 0002    | 0          |

**NOTE:** FF00 hex coil value is forced to 1 and 0000H is forced to 0. Other values are illegal and will not affect the coil.

**Table 15 - Function Code 05H Master Request Example**

| Request          | Bytes | Example (Hex)                            |
|------------------|-------|--|
| Slave address    | 1     | 01 Send slave address 01                 |
| Function code    | 1     | 05 Force coil                            |
| Starting address | 2     | 00 Starting address is 0000H<br>00       |
| Data             | 2     | FF Set coil as 1<br>00                   |
| CRC code         | 2     | CD CRC code which calculated by PC<br>FB |

**Table 16 - Function Code 05H Slave Response Example**

| Slave Response   | Bytes | Example (Hex)                               |
|------------------|-------|---|
| Slave address    | 1     | 01 Respond slave address 01                 |
| Function code    | 1     | 05 Force coil                               |
| Starting address | 2     | 00 Starting address is 0000H<br>00          |
| Data             | 2     | FF Set coil as 1<br>00                      |
| CRC code         | 2     | CD CRC code which calculated by slave<br>FB |

**4.7.3 FUNCTION CODE 06H**

Slave address is 01 and place starting address of 00E3H of 1 point as 0002H.

**Table 17 - Function Code 06H Master Request Example**

| Request          | Bytes | Example (Hex)                               |
|------------------|-------|---|
| Slave address    | 1     | 01 Send slave address 01                    |
| Function code    | 1     | 06 Write single register                    |
| Starting address | 2     | 00 Starting address is 00E3H<br>E3          |
| Data             | 2     | 00 Place 1 point data (total 2 bytes)<br>02 |
| CRC code         | 2     | F9 CRC code which calculated by PC<br>FD    |

**Table 18 - Function Code 06H Slave Response Example**

| Slave Response   | Bytes | Example (Hex)                               |
|------------------|-------|---|
| Slave address    | 1     | 01 Respond slave address 01                 |
| Function code    | 1     | 06 Write single register                    |
| Starting address | 2     | 00 Starting address is 00E3H<br>E3          |
| Data             | 2     | 00 Place 1 point data (total 2 bytes)<br>02 |
| CRC code         | 2     | F9 CRC code which calculated by slave<br>FD |

#### 4.8 ERROR HANDLING

When device detects other errors except the CRC code, the slave must send information to the master. The function code MSB is 1, which means the response function code by slave should add 128 based on the function code sent by the master. The following codes show that unexpected errors have occurred.

If CRC error occurs for the information received by the slave, then the device will ignore.

**Table 19 - Error Code Format of Slave Response (CRC excluded)**

| Type          | Byte              |
|---------------|-------------------|
| Address code  | 1 byte            |
| Function code | 1 byte (MSB is 1) |
| Error code    | 1 byte            |
| CRC code      | 2 bytes           |

Error code:

01 illegal function code


The function code received in the query is not an allowable action for the slave.

02 illegal data address

The data address received in the query is not an allowable address for the slave.

03 illegal data value

A value contained in the query data field is not an allowable value for the slave.



**5. ATTACHMENT: ADDRESS AND DATA**

**5.1 FUNCTION CODE 03H MAPPING DATA FIELD**

**Table 20 - Function Code 03H Mapping Data Field**

| Address | Item                       | Description        | Byte |
|---------|----------------------------|--------------------|------|
| 0000    | Common Alarm               | 1 for active (LSB) | 1bit |
|         | Common Shutdown Alarm      | 1 for active       | 1bit |
|         | Common Warning Alarm       | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Auto Mode                  | 1 for active       | 1bit |
|         | Manual Mode                | 1 for active       | 1bit |
|         | Stop Mode                  | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for manual       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Lock Mode                  | 1 for active (MSB) | 1bit |
| 0001    | Emergency Stop Alarm       | 1 for active       | 1bit |
|         | Engine Overspeed Shutdown  | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Loss of Speed Signal Alarm | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Failed to Start Alarm      | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | ECU Alarm Shutdown         | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Urea Level Low Shutdown    | 1 for active       | 1bit |
|         | High Temp. Shutdown        | 1 for active       | 1bit |
|         | Low Oil Press Shutdown     | 1 for active       | 1bit |
| 0002    | ECU Comm. Fail Shutdown    | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |
|         | Reserved                   | 1 for active       | 1bit |

| Address | Item                              | Description  | Byte |
|---------|-----------------------------------|--------------|------|
|         | Reserved                          | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Temp. Sensor Open Shutdown        | 1 for active | 1bit |
|         | High Temp. Shutdown               | 1 for active | 1bit |
|         | Low Temp. Shutdown                | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Oil Pressure Sensor Open Shutdown | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Low Oil Pressure Shutdown         | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
| 0003    | Fuel Level Open Shutdown          | 1 for active | 1bit |
|         | Fuel Level High Shutdown          | 1 for active | 1bit |
|         | Fuel Level Low Shutdown           | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Discharge Pressure Open Shutdown  | 1 for active | 1bit |
|         | Discharge Pressure High Shutdown  | 1 for active | 1bit |
|         | Discharge Pressure Low Shutdown   | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Discharge Temp. Open Shutdown     | 1 for active | 1bit |
|         | Discharge Temp. High Shutdown     | 1 for active | 1bit |
|         | Discharge Temp. Low Shutdown      | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Flexible Sensor 1 Open Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 1 High Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 1 Low Shutdown    | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
| 0004    | Flexible Sensor 2 Open Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 2 High Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 2 Low Shutdown    | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Flexible Sensor 3 Open Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 3 High Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 3 Low Shutdown    | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Flexible Sensor 4 Open Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 4 High Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 4 Low Shutdown    | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
|         | Flexible Sensor 5 Open Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 5 High Shutdown   | 1 for active | 1bit |
|         | Flexible Sensor 5 Low Shutdown    | 1 for active | 1bit |
|         | Reserved                          | 1 for active | 1bit |
| 0005    | Input 1 Shutdown                  | 1 for active | 1bit |
|         | Input 2 Shutdown                  | 1 for active | 1bit |

| Address | Item                                    | Description  | Byte   |
|---------|---|--------------|--------|
|         | Input 3 Shutdown                        | 1 for active | 1bit   |
|         | Input 4 Shutdown                        | 1 for active | 1bit   |
|         | Input 5 Shutdown                        | 1 for active | 1bit   |
|         | Input 6 Shutdown                        | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Authorization Time Due Shutdown         | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
| 0006    | Fuel Filter Maintenance Time Due        | 1 for active | 1bit   |
|         | Oil Separator Maintenance Time Due      | 1 for active | 1bit   |
|         | Air Filter Maintenance Time Due         | 1 for active | 1bit   |
|         | Lubrication Maintenance Time Due        | 1 for active | 1bit   |
|         | Engine Oil Filter Maintenance Time Due  | 1 for active | 1bit   |
|         | Engine Fuel Filter Maintenance Time Due | 1 for active | 1bit   |
|         | Engine Lubrication Maintenance Time Due | 1 for active | 1bit   |
|         | Maintenance 8 Time Due                  | 1 for active | 1bit   |
|         | Maintenance 9 Time Due                  | 1 for active | 1bit   |
|         | Maintenance 10 Time Due                 | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
|         | Reserved                                | 1 for active | 1bit   |
| 0007    | Reserved                                | 2Bytes       | 2Bytes |
| 0008    | Reserved                                | 2Bytes       | 2Bytes |
| 0009    | Reserved                                | 2Bytes       | 2Bytes |
| 0010    | Reserved                                | 2Bytes       | 2Bytes |
| 0011    | Reserved                                | 2Bytes       | 2Bytes |
| 0012    | Reserved                                | 2Bytes       | 2Bytes |
| 0013    | Reserved                                | 2Bytes       | 2Bytes |
| 0014    | Reserved                                | 2Bytes       | 2Bytes |
| 0015    | Reserved                                | 2Bytes       | 2Bytes |
| 0016    | Reserved                                | 2Bytes       | 2Bytes |
| 0017    | Reserved                                | 2Bytes       | 2Bytes |
| 0018    | Reserved                                | 2Bytes       | 2Bytes |
| 0019    | Reserved                                | 2Bytes       | 2Bytes |
| 0020    | Engine Over Speed Warning               | 1 for active | 1bit   |

| Address                         | Item                                    | Description  | Byte |
|---------------------------------|---|--------------|------|
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Loss of Speed Signal Warning            | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Failed to Stop Warning                  | 1 for active | 1bit |
|                                 | Charge Alt Fail Warning                 | 1 for active | 1bit |
|                                 | Battery Overvoltage Warning             | 1 for active | 1bit |
|                                 | Battery Undervoltage Warning            | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Urea Level Low Warning                  | 1 for active | 1bit |
|                                 | ECU Warning                             | 1 for active | 1bit |
| 0021                            | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Engine Temp. Sensor Open Warning        | 1 for active | 1bit |
|                                 | Engine High Temp. Warning               | 1 for active | 1bit |
|                                 | Engine Low Temp. Warning                | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Engine Oil Pressure Sensor Open Warning | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
| Low Engine Oil Pressure Warning | 1 for active                            | 1bit         |      |
| Reserved                        | 1 for active                            | 1bit         |      |
| 0022                            | Fuel Level Open Warning                 | 1 for active | 1bit |
|                                 | Fuel Level High Warning                 | 1 for active | 1bit |
|                                 | Fuel Level Low Warning                  | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Discharge Pressure Open Warning         | 1 for active | 1bit |
|                                 | Discharge Pressure High Warning         | 1 for active | 1bit |
|                                 | Discharge Pressure Low Warning          | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Discharge Temp. Open Warning            | 1 for active | 1bit |
|                                 | Discharge Temp. High Warning            | 1 for active | 1bit |
|                                 | Discharge Temp. Low Warning             | 1 for active | 1bit |
|                                 | Reserved                                | 1 for active | 1bit |
|                                 | Flexible Sensor 1 Open Warning          | 1 for active | 1bit |

| Address  | Item   | Description  | Byte |
|----------|--|--------------|------|
|          | Flexible Sensor 1 High Warning               | 1 for active | 1bit |
|          | Flexible Sensor 1 Low Warning                | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
| 0023     | Flexible Sensor 2 Open Warning               | 1 for active | 1bit |
|          | Flexible Sensor 2 High Warning               | 1 for active | 1bit |
|          | Flexible Sensor 2 Low Warning                | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Flexible Sensor 3 Open Warning               | 1 for active | 1bit |
|          | Flexible Sensor 3 High Warning               | 1 for active | 1bit |
|          | Flexible Sensor 3 Low Warning                | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Flexible Sensor 4 Open Warning               | 1 for active | 1bit |
|          | Flexible Sensor 4 High Warning               | 1 for active | 1bit |
|          | Flexible Sensor 4 Low Warning                | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Flexible Sensor 5 Open Warning               | 1 for active | 1bit |
|          | Flexible Sensor 5 High Warning               | 1 for active | 1bit |
|          | Flexible Sensor 5 Low Warning                | 1 for active | 1bit |
| Reserved | 1 for active                                 | 1bit         |      |
| 0024     | Input 1 Warning                              | 1 for active | 1bit |
|          | Input 2 Warning                              | 1 for active | 1bit |
|          | Input 3 Warning                              | 1 for active | 1bit |
|          | Input 4 Warning                              | 1 for active | 1bit |
|          | Input 5 Warning                              | 1 for active | 1bit |
|          | Input 6 Warning                              | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Authorization Time Due Warning               | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
|          | Reserved                                     | 1 for active | 1bit |
| Reserved | 1 for active                                 | 1bit         |      |
| 0025     | Fuel Filter Maintenance Time Due Warn        | 1 for active | 1bit |
|          | Oil Separator Maintenance Time Due Warn      | 1 for active | 1bit |
|          | Air Filter Maintenance Time Due Warn         | 1 for active | 1bit |
|          | Lubrication Maintenance Time Due Warn        | 1 for active | 1bit |
|          | Engine Oil Filter Maintenance Time Due Warn  | 1 for active | 1bit |
|          | Engine Fuel Filter Maintenance Time Due Warn | 1 for active | 1bit |
|          | Engine Lubrication Maintenance Time Due      | 1 for active | 1bit |

| Address | Item   | Description  | Byte   |
|---------|--|--------------|--------|
|         | Warn   |              |        |
|         | Maintenance 8 Time Due Warn                        | 1 for active | 1bit   |
|         | Maintenance 9 Time Due Warn                        | 1 for active | 1bit   |
|         | Maintenance 10 Time Due Warn                       | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
| 0026    | Reserved   | 2Bytes       | 2Bytes |
| 0027    | Reserved   | 2Bytes       | 2Bytes |
| 0028    | Reserved   | 2Bytes       | 2Bytes |
| 0029    | Reserved   | 2Bytes       | 2Bytes |
| 0030    | Reserved   | 2Bytes       | 2Bytes |
| 0031    | Reserved   | 2Bytes       | 2Bytes |
| 0032    | Reserved   | 2Bytes       | 2Bytes |
| 0033    | Input 1 Indication                                 | 1 for active | 1bit   |
|         | Input 2 Indication                                 | 1 for active | 1bit   |
|         | Input 3 Indication                                 | 1 for active | 1bit   |
|         | Input 4 Indication                                 | 1 for active | 1bit   |
|         | Input 5 Indication                                 | 1 for active | 1bit   |
|         | Input 6 Indication                                 | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
|         | Reserved   | 1 for active | 1bit   |
| 0034    | Fuel Filter Maintenance Time Due Indication        | 1 for active | 1bit   |
|         | Oil Separator Maintenance Time Due Indication      | 1 for active | 1bit   |
|         | Air Filter Maintenance Time Due Indication         | 1 for active | 1bit   |
|         | Lubrication Maintenance Time Due Indication        | 1 for active | 1bit   |
|         | Engine Oil Filter Maintenance Time Due Indication  | 1 for active | 1bit   |
|         | Engine Fuel Filter Maintenance Time Due Indication | 1 for active | 1bit   |

| Address  | Item   | Description  | Byte   |
|----------|--|--------------|--------|
|          | Engine Lubrication Maintenance Time Due Indication | 1 for active | 1bit   |
|          | Maintenance 8 Time Due Indication                  | 1 for active | 1bit   |
|          | Maintenance 9 Time Due Indication                  | 1 for active | 1bit   |
|          | Maintenance 10 Time Due Indication                 | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
| 0035     | Emergency Input Status                             | 1 for active | 1bit   |
|          | Input 1 Status                                     | 1 for active | 1bit   |
|          | Input 2 Status                                     | 1 for active | 1bit   |
|          | Input 3 Status                                     | 1 for active | 1bit   |
|          | Input 4 Status                                     | 1 for active | 1bit   |
|          | Input 5 Status                                     | 1 for active | 1bit   |
|          | Input 6 Status                                     | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
| Reserved | 1 for active                                       | 1bit         |        |
| 0036     | Reserved   | 2Bytes       | 2Bytes |
| 0037     | Reserved   | 1 for active | 1bit   |
|          | Start Relay Output Status                          | 1 for active | 1bit   |
|          | Aux. Output 1 Status                               | 1 for active | 1bit   |
|          | Aux. Output 2 Status                               | 1 for active | 1bit   |
|          | Aux. Output 3 Status                               | 1 for active | 1bit   |
|          | Aux. Output 4 Status                               | 1 for active | 1bit   |
|          | Aux. Output 5 Status                               | 1 for active | 1bit   |
|          | Aux. Output 6 Status                               | 1 for active | 1bit   |
|          | Aux. Output 7 Status                               | 1 for active | 1bit   |
|          | Aux. Output 8 Status                               | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |
|          | Reserved   | 1 for active | 1bit   |

| Address  | Item                             | Description  | Byte   |
|----------|----------------------------------|--------------|--------|
| 0038     | Reserved                         | 2Bytes       | 2Bytes |
| 0039     | Reserved                         | 2Bytes       | 2Bytes |
| 0040     | Reserved                         | 2Bytes       | 2Bytes |
| 0041     | Load Valve Auto Control Output   | 1 for active | 1bit   |
|          | Load Status Output               | 1 for active | 1bit   |
|          | Load Rate High Protection Status | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Auto Drain Output                | 1 for active | 1bit   |
|          | Idle Running Status              | 1 for active | 1bit   |
|          | Shutdown Alarm Inhibit           | 1 for active | 1bit   |
|          | Instrument Mode Status           | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Remote Start Status              | 1 for active | 1bit   |
|          | Auto Start Inhibit               | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
| Reserved | 1 for active                     | 1bit         |        |
| 0042     | Alternate Config. 1 Active       | 1 for active | 1bit   |
|          | Alternate Config. 2 Active       | 1 for active | 1bit   |
|          | Alternate Config. 3 Active       | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
| 0043     | Maintenance Pre-alarm Lamp       | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Running Status Lamp              | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |
|          | Reserved                         | 1 for active | 1bit   |

| Address  | Item              | Description  | Byte   |
|----------|-------------------|--------------|--------|
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
| 0044     | DPF Fault         | 1 for active | 1bit   |
|          | DPF Request       | 1 for active | 1bit   |
|          | DPF Inhibit Lamp  | 1 for active | 1bit   |
|          | DPF Exhaust Lamp  | 1 for active | 1bit   |
|          | DPF Response Lamp | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
| Reserved | 1 for active      | 1bit         |        |
| 0045     | Input 1 Active    | 1 for active | 1bit   |
|          | Input 2 Active    | 1 for active | 1bit   |
|          | Input 3 Active    | 1 for active | 1bit   |
|          | Input 4 Active    | 1 for active | 1bit   |
|          | Input 5 Active    | 1 for active | 1bit   |
|          | Input 6 Active    | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
|          | Reserved          | 1 for active | 1bit   |
| Reserved | 1 for active      | 1bit         |        |
| 0046     | Reserved          | 2Bytes       | 2Bytes |
| 0047     | Reserved          | 2Bytes       | 2Bytes |
| 0048     | Reserved          | 2Bytes       | 2Bytes |
| 0049     | Reserved          | 2Bytes       | 2Bytes |
| 0050     | Engine Speed      | Unsigned     | 2Bytes |

| Address | Item                                | Description          | Byte   |
|---------|-------------------------------------|----------------------|--------|
| 0051    | Battery Voltage                     | Signed (*10)         | 2Bytes |
| 0052    | Charger Voltage                     | Signed (*10)         | 2Bytes |
| 0053    | Sensor 1 Resistance                 | Unsigned (*10)       | 2Bytes |
| 0054    | Sensor 1 Value (Water Temp.)        | Signed               | 2Bytes |
| 0055    | Sensor 2 Resistance                 | Unsigned (*10)       | 2Bytes |
| 0056    | Sensor 2 Value (Oil Press.)         | Signed               | 2Bytes |
| 0057    | Sensor 3 Resistance/Current/Voltage | Unsigned (*10)       | 2Bytes |
| 0058    | Sensor 3 Value (Fuel Level)         | Signed               | 2Bytes |
| 0059    | Sensor 4 Resistance/Current/Voltage | Unsigned (*10)       | 2Bytes |
| 0060    | Sensor 4 Value (Discharge Pressure) | Signed               | 2Bytes |
| 0061    | Sensor 5 Resistance                 | Unsigned (*10)       | 2Bytes |
| 0062    | Sensor 5 Value (Discharge Temp.)    | Signed               | 2Bytes |
| 0063    | Sensor 6 Current                    | Unsigned (*10)       | 2Bytes |
| 0064    | Sensor 6 Value (Flexible 1)         | Signed               | 2Bytes |
| 0065    | Sensor 7 Current                    | Unsigned (*10)       | 2Bytes |
| 0066    | Sensor 7 Value (Flexible 2)         | Signed               | 2Bytes |
| 0067    | Sensor 8 Resistance/Current/Voltage | Unsigned (*10)       | 2Bytes |
| 0068    | Sensor 8 Value (Flexible 3)         | Signed               | 2Bytes |
| 0069    | Sensor 9 Resistance/Current/Voltage | Unsigned (*10)       | 2Bytes |
| 0070    | Sensor 9 Value (Flexible 4)         | Signed               | 2Bytes |
| 0071    | Sensor 10 Resistance                | Unsigned (*10)       | 2Bytes |
| 0072    | Sensor 10 Value (Flexible 5)        | Signed               | 2Bytes |
| 0073    | Reserved                            | Unsigned (*10)       | 2Bytes |
| 0074    | Reserved                            | Signed               | 2Bytes |
| 0075    | SCR Inlet Temperature               | Unsigned (*10)       | 2Bytes |
| 0076    | SCR Outlet Temperature              | Signed               | 2Bytes |
| 0077    | Coolant Pressure                    | Signed               | 2Bytes |
| 0078    | Coolant Level                       | Signed               | 2Bytes |
| 0079    | Fuel Pressure                       | Signed               | 2Bytes |
| 0080    | Fuel Temperature                    | Signed               | 2Bytes |
| 0081    | Engine Oil Temperature              | Signed               | 2Bytes |
| 0082    | Inlet Temperature                   | Signed               | 2Bytes |
| 0083    | Turbo Pressure                      | Signed               | 2Bytes |
| 0084    | Exhaust Temperature                 | Signed               | 2Bytes |
| 0085    | Fuel Consumption                    | Signed               | 2Bytes |
| 0086    | Total Fuel Used (LSB)               | Signed               | 4Bytes |
| 0087    | Total Fuel Used (MSB)               |                      |        |
| 0088    | Reserved                            | Signed               | 2Bytes |
| 0089    | DPF Smoke Load Rate                 | Signed               | 2Bytes |
| 0090    | Engine load Rate                    | Signed               | 2Bytes |
| 0091    | Torque Percentage                   | Signed               | 2Bytes |
| 0092    | Water in Fuel Status                | Signed               | 2Bytes |
| 0093    | Urea Level                          | Signed               | 2Bytes |
| 0094    | Engine Status                       | Running Status Table | 2Bytes |

| Address | Item                                  | Description                   | Byte   |
|---------|---------------------------------------|-------------------------------|--------|
| 0095    | Engine Delay Value                    | Unsigned                      | 2Bytes |
| 0096    | Reserved                              | Unsigned                      | 2Bytes |
| 0097    | Reserved                              | Unsigned                      | 2Bytes |
| 0098    | Reserved                              | Unsigned                      | 2Bytes |
| 0099    | Reserved                              | Unsigned                      | 2Bytes |
| 0100    | Reserved                              | Unsigned                      | 2Bytes |
| 0101    | Total Running Hours                   | Unsigned                      | 2Bytes |
| 0102    | Total Running Minutes                 | Unsigned                      | 2Bytes |
| 0103    | Total Running Seconds                 | Unsigned                      | 2Bytes |
| 0104    | Total Start Times                     | Unsigned                      | 2Bytes |
| 0105    | Current Running Hours                 | Unsigned                      | 2Bytes |
| 0106    | Current Running Minutes               | Unsigned                      | 2Bytes |
| 0107    | Current Running Seconds               | Unsigned                      | 2Bytes |
| 0108    | Reserved                              | Unsigned                      | 2Bytes |
| 0109    | Reserved                              | Unsigned                      | 2Bytes |
| 0110    | Reserved                              | Unsigned                      | 2Bytes |
| 0111    | Reserved                              | Unsigned                      | 2Bytes |
| 0112    | Reserved                              | Unsigned                      | 2Bytes |
| 0113    | Controller Model                      | Unsigned                      | 2Bytes |
| 0114    | Controller Software Version           | Unsigned (*10)                | 2Bytes |
| 0115    | Controller Hardware Version           | Unsigned (*10)                | 2Bytes |
| 0116    | Release Time (Year)                   | Only reserve last two numbers | 2Bytes |
| 0117    | Release Time (Month)                  | Unsigned                      | 2Bytes |
| 0118    | Release Time (Day)                    | Unsigned                      | 2Bytes |
| 0119    | Reserved                              | Unsigned                      | 2Bytes |
| 0120    | Event Logs                            | Unsigned                      | 2Bytes |
| 0121    | Controller Time: Year                 | Only reserve last two numbers | 2Bytes |
| 0122    | Controller Time: Month                | Unsigned                      | 2Bytes |
| 0123    | Controller Time: Day                  | Unsigned                      | 2Bytes |
| 0124    | Controller Time: Week                 | Unsigned                      | 2Bytes |
| 0125    | Controller Time: Hour                 | Unsigned                      | 2Bytes |
| 0126    | Controller Time: Minute               | Unsigned                      | 2Bytes |
| 0127    | Controller Time: Second               | Unsigned                      | 2Bytes |
| 0128    | Reserved                              | Unsigned                      | 2Bytes |
| 0129    | Reserved                              | Unsigned                      | 2Bytes |
| 0130    | Reserved                              | Unsigned                      | 2Bytes |
| 0131    | Reserved                              | Unsigned                      | 2Bytes |
| 0132    | Reserved                              | Unsigned                      | 2Bytes |
| 0133    | Reserved                              | Unsigned                      | 2Bytes |
| 0134    | Reserved                              | Unsigned                      | 2Bytes |
| 0135    | Maintenance 1 Due Countdown (Hours)   | Unsigned                      | 2Bytes |
| 0136    | Maintenance 1 Due Countdown (Minutes) | Unsigned                      | 2Bytes |

| Address   | Item   | Description | Byte   |
|-----------|--|-------------|--------|
| 0137      | Maintenance 1 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0138      | Maintenance 2 Due Countdown (Hours)            | Unsigned    | 2Bytes |
| 0139      | Maintenance 2 Due Countdown (Minutes)          | Unsigned    | 2Bytes |
| 0140      | Maintenance 2 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0141      | Maintenance 3 Due Countdown (Hours)            | Unsigned    | 2Bytes |
| 0142      | Maintenance 3 Due Countdown (Minutes)          | Unsigned    | 2Bytes |
| 0143      | Maintenance 3 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0144      | Maintenance 4 Due Countdown (Hours)            | Unsigned    | 2Bytes |
| 0145      | Maintenance 4 Due Countdown (Minutes)          | Unsigned    | 2Bytes |
| 0146      | Maintenance 4 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0147      | Maintenance 5 Due Countdown (Hours)            | Unsigned    | 2Bytes |
| 0148      | Maintenance 5 Due Countdown (Minutes)          | Unsigned    | 2Bytes |
| 0149      | Maintenance 5 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0150      | Maintenance 6 Due Countdown (Hours)            | Unsigned    | 2Bytes |
| 0151      | Maintenance 6 Due Countdown (Minutes)          | Unsigned    | 2Bytes |
| 0152      | Maintenance 6 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0153      | Maintenance 7 Due Countdown (Hours)            | Unsigned    | 2Bytes |
| 0154      | Maintenance 7 Due Countdown (Minutes)          | Unsigned    | 2Bytes |
| 0155      | Maintenance 7 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0156      | Maintenance 8 Due Countdown (Hours)            | Unsigned    | 2Bytes |
| 0157      | Maintenance 8 Due Countdown (Minutes)          | Unsigned    | 2Bytes |
| 0158      | Maintenance 8 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0159      | Maintenance 9 Due Countdown (Hours)            | Unsigned    | 2Bytes |
| 0160      | Maintenance 9 Due Countdown (Minutes)          | Unsigned    | 2Bytes |
| 0161      | Maintenance 9 Due Countdown (Seconds)          | Unsigned    | 2Bytes |
| 0162      | Maintenance 10 Due Countdown (Hours)           | Unsigned    | 2Bytes |
| 0163      | Maintenance 10 Due Countdown (Minutes)         | Unsigned    | 2Bytes |
| 0164      | Maintenance 10 Due Countdown (Seconds)         | Unsigned    | 2Bytes |
| 0165      | MCUID MSB 1                                    | Unsigned    | 4Bytes |
| 0166      |  |             |        |
| 0167      | MCUID MSB 2                                    | Unsigned    | 4Bytes |
| 0168      |  |             |        |
| 0169      | MCUID LSB                                      | Unsigned    | 4Bytes |
| 0170      |  |             |        |
| 0171      | Reserved                                       | Unsigned    | 2Bytes |
| 0172      | Reserved                                       | Unsigned    | 2Bytes |
| 0173      | SCM Temp.                                      | Unsigned    | 2Bytes |
| 0174      | LCD Temp.                                      | Unsigned    | 2Bytes |
| 0175-0206 | Reserved                                       | Unsigned    | 2Bytes |
| 0207      | AIN8 Sensor 1 Resistance/Current/Voltage Value | Unsigned    | 2Bytes |
| 0208      | AIN8 Sensor 2 Resistance/Current/Voltage Value | Unsigned    | 2Bytes |

| Address | Item   | Description | Byte   |
|---------|--|-------------|--------|
| 0209    | AIN8 Sensor 3 Resistance/Current/Voltage Value | Unsigned    | 2Bytes |
| 0210    | AIN8 Sensor 4 Resistance/Current/Voltage Value | Unsigned    | 2Bytes |
| 0211    | AIN8 Sensor 5 Resistance/Current/Voltage Value | Unsigned    | 2Bytes |
| 0212    | AIN8 Sensor 6 Resistance/Current/Voltage Value | Unsigned    | 2Bytes |
| 0213    | AIN8 Sensor 7 Resistance/Current/Voltage Value | Unsigned    | 2Bytes |
| 0214    | AIN8 Sensor 8 Resistance/Current/Voltage Value | Unsigned    | 2Bytes |
| 0215    | AIN8 Sensor 1 Value                            | Signed      | 2Bytes |
| 0216    | AIN8 Sensor 2 Value                            | Signed      | 2Bytes |
| 0217    | AIN8 Sensor 3 Value                            | Signed      | 2Bytes |
| 0218    | AIN8 Sensor 4 Value                            | Signed      | 2Bytes |
| 0219    | AIN8 Sensor 5 Value                            | Signed      | 2Bytes |
| 0220    | AIN8 Sensor 6 Value                            | Signed      | 2Bytes |
| 0221    | AIN8 Sensor 7 Value                            | Signed      | 2Bytes |
| 0222    | AIN8 Sensor 8 Value                            | Signed      | 2Bytes |

**5.2 FUNCTION CODE 05H MAPPING COIL FIELD**

**Table 21 - Function Code 05H Mapping Data Field**

| Coil Data |                        |              |
|-----------|------------------------|--------------|
| Address   | Item                   | Description  |
| 0000      | Remote Start Key       | 1 for active |
| 0001      | Remote Stop Key        | 1 for active |
| 0002      | Remote Unload Key      | 1 for active |
| 0003      | Remote Onload Key      | 1 for active |
| 0004      | Remote Alarm Reset Key | 1 for active |
| 0005      | Remote Maintenance Key | 1 for active |
| 0006      | Reserved               | 1 for active |
| 0007      | Remote Up Key          | 1 for active |
| 0008      | Remote Down Key        | 1 for active |
| 0009      | Remote Confirm Key     | 1 for active |
| 0010      | Remote Return Key      | 1 for active |
| 0011      | Reserved               | 1 for active |
| 0012      | Reserved               | 1 for active |
| 0013      | Reserved               | 1 for active |
| 0014      | Reserved               | 1 for active |
| 0015      | Remote Rapid Stop      | 1 for active |
| 0016      | Reserved               | 1 for active |
| 0017      | Reserved               | 1 for active |

| Coil Data |                             |                              |
|-----------|-----------------------------|------------------------------|
| Address   | Item                        | Description                  |
| 0018      | Remote Unlock               | 1 for active                 |
| 0019      | Remote Lock                 | 1 for active                 |
| 0020      | Remote Output Port 1 Output | 1 for active; 0 for inactive |
| 0021      | Remote Output Port 2 Output | 1 for active; 0 for inactive |
| 0022      | Remote Output Port 3 Output | 1 for active; 0 for inactive |
| 0023      | Remote Output Port 4 Output | 1 for active; 0 for inactive |
| 0024      | Remote Output Port 5 Output | 1 for active; 0 for inactive |
| 0025      | Remote Output Port 6 Output | 1 for active; 0 for inactive |
| 0026      | Remote Output Port 7 Output | 1 for active; 0 for inactive |
| 0027      | Remote Output Port 8 Output | 1 for active; 0 for inactive |
| 0028      | Reserved                    | 1 for active; 0 for inactive |
| 0029      | Reserved                    | 1 for active; 0 for inactive |
| 0030      | Reset Maintenance 1 Time    | 1 for active                 |
| 0031      | Reset Maintenance 2 Time    | 1 for active                 |
| 0032      | Reset Maintenance 3 Time    | 1 for active                 |
| 0033      | Reset Maintenance 4 Time    | 1 for active                 |
| 0034      | Reset Maintenance 5 Time    | 1 for active                 |
| 0035      | Reset Maintenance 6 Time    | 1 for active                 |
| 0036      | Reset Maintenance 7 Time    | 1 for active                 |
| 0037      | Reset Maintenance 8 Time    | 1 for active                 |
| 0038      | Reset Maintenance 9 Time    | 1 for active                 |
| 0039      | Reset Maintenance 10 Time   | 1 for active                 |

**5.3 ENGINE RUNNING STATUS**

**Table 22 - Engine Running Status**

| No. | Item             | Range | Description                               |
|-----|------------------|-------|---|
| 0   | Standby          |       | No delay will be displayed in this status |
| 1   | Pre-heat         |       |   |
| 2   | Fuel Output      |       |   |
| 3   | Crank Delay      |       |   |
| 4   | Crank Rest       |       |   |
| 5   | Safety On        |       |   |
| 6   | Start Idle       |       |   |
| 7   | Warming Up       |       |   |
| 8   | Waiting for Load |       | No delay will be displayed in this status |
| 9   | Normal Running   |       | No delay will be displayed in this status |
| 10  | Cooling          |       |   |
| 11  | Stop Idle        |       |   |
| 12  | Energize to Stop |       |   |
| 13  | Wait Stop Time   |       |   |
| 14  | Failed to Stop   |       | No delay will be displayed in this status |
| 15  | After Stop Time  |       |   |